

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

15 psf Dead Load and 100 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
600S137-33	33	7-7 e	6-7 e	5-4 e	7-7 a	6-5 a	4-3 a	7-7 e	6-7 e	5-4 e	7-7 a	6-5 a	4-3 a
600S162-33	33	8-0 e	7-0 e	5-4 e	8-0 a	6-5 a	4-3 a	8-0 e	7-0 e	5-4 e	8-0 a	6-5 a	4-3 a
600S200-33	33	8-2 e	7-1 e	5-4 e	8-2 a	6-5 a	4-3 a	8-2 e	7-1 e	5-4 e	8-2 a	6-5 a	4-3 a
600S137-43	33	8-9 e	7-7 e	6-2 e	8-9 i	7-7 a	6-2 a	8-8 e	7-7 e	6-2 e	8-9 i	7-7 a	6-2 a
600S162-43	33	9-4 e	8-1 e	6-7 e	9-4 i	8-1 a	6-7 a	9-1 e	8-1 e	6-7 e	9-4 i	8-1 a	6-7 a
600S200-43	33	9-5 e	8-1 e	6-8 e	9-5 i	8-1 a	6-8 a	9-5 e	8-1 e	6-8 e	9-5 i	8-1 a	6-8 a
600S250-43	33	10-2 e	8-10 e	7-2 e	10-2 a	8-10 a	7-2 a	10-0 e	8-10 e	7-2 e	10-2 a	8-10 a	7-2 a
600S300-43	33	10-9 e	9-4 e	7-7 e	10-9 a	9-4 a	7-7 a	10-5 e	9-4 e	7-7 e	10-9 a	9-4 a	7-7 a
600S137-54	33	9-9	8-5	6-11 e	9-9 i	8-5 i	6-11 i	9-4	8-5	6-11 e	9-9 i	8-5 i	6-11 i
600S137-54	50	10-3	9-4	8-2 e	11-6 i	10-3 i	8-4 i	9-4	8-6	7-5	10-6 i	9-6 i	8-4 i
600S162-54	33	10-5	9-0 e	7-4 e	10-5 i	9-0 i	7-4 i	9-9	8-10 e	7-4 e	10-5 i	9-0 i	7-4 i
600S162-54	50	10-9	9-9	8-6 e	12-1 i	10-11 i	8-11 i	9-9	8-10	7-9 e	10-11 i	9-11 i	8-8 i
600S200-54	33	10-10	9-5 e	7-8 e	10-10 i	9-5 i	7-8 i	10-2	9-3 e	7-8 e	10-10 i	9-5 i	7-8 i
600S200-54	50	11-2	10-2	8-10 e	12-7 i	10-11 i	8-11 i	10-2	9-3	8-1 e	11-5 i	10-4 i	8-11 i
600S250-54	33	11-6	9-11 e	8-1 e	11-6 i	9-11 i	8-1 a	10-9	9-9 e	8-1 e	11-6 i	9-11 i	8-1 a
600S250-54	50	11-9	10-8	9-4 e	13-2 i	11-9 i	9-7 i	10-8	9-8	8-6 e	12-0 i	10-11 i	9-6 i
600S300-54	33	12-2 e	10-6 e	8-7 e	12-2 i	10-6 i	8-7 a	11-3	10-3 e	8-7 e	12-2 i	10-6 i	8-7 a
600S300-54	50	12-3	11-1	9-8 e	13-9 i	12-5 i	10-1 a	11-1	10-1	8-10 e	12-6 i	11-4 i	9-11 i
600S137-68	33	10-10	9-5	7-8	10-10	9-5 i	7-8 i	10-0	9-1	7-8	10-10	9-5 i	7-8 i
600S137-68	50	11-0	10-0	8-9	12-5	11-3	9-5 i	10-0	9-1	7-11	11-3	10-3	8-11 i
600S162-68	33	11-6	10-0	8-2	11-7	10-0 i	8-2 i	10-6	9-6	8-2	11-7	10-0 i	8-2 i
600S162-68	50	11-6	10-6	9-2	12-11	11-9	10-1 i	10-6	9-6	8-4	11-9	10-8	9-4 i
600S200-68	33	12-0	10-8	8-8	12-4 i	10-8 i	8-8 i	10-11	9-11	8-8	12-3 i	10-8 i	8-8 i
600S200-68	50	12-0	10-11	9-6	13-6	12-3 i	10-5 i	10-11	9-11	8-8	12-3	11-2	9-9 i
600S250-68	33	12-8	11-5	9-4	13-2 i	11-5 i	9-4 i	11-7	10-6	9-2	13-0 i	11-5 i	9-4 i
600S250-68	50	12-8	11-7	10-1	14-3	13-0 i	10-9 i	11-7	10-6	9-2	13-0	11-9	10-3 i
600S300-68	33	13-4	11-10	9-8 e	13-8 i	11-10 i	9-8 i	12-1	11-0	9-7 e	13-7 i	11-10 i	9-8 i
600S300-68	50	13-3	12-1	10-6	14-11	13-7 i	11-6 i	12-1	10-11	9-7	13-7	12-4 i	10-9 i
600S162-97	33	12-10	11-8	9-7	13-7	11-10	9-7	11-8	10-7	9-3	13-1	11-10	9-7
600S162-97	50	12-10	11-8	10-2	14-5	13-1	11-5	11-8	10-7	9-3	13-1	11-11	10-5
600S200-97	33	13-5	12-2	10-3	14-6	12-7	10-3	12-2	11-1	9-8	13-8	12-5	10-3
600S200-97	50	13-5	12-2	10-8	15-1	13-8	11-11	12-2	11-1	9-8	13-8	12-5	10-10
600S250-97	33	14-2	12-11	11-2	15-10	13-8	11-2	12-11	11-8	10-3	14-6	13-2	11-2
600S250-97	50	14-2	12-11	11-3	15-11	14-6	12-8	12-11	11-8	10-3	14-6	13-2	11-6
600S300-97	33	14-11	13-6	11-10	16-9	14-8	11-11	13-6	12-3	10-9	15-2	13-10	11-11
600S300-97	50	14-11	13-6	11-10	16-9	15-2	13-3	13-6	12-3	10-9	15-2	13-10	12-1

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

15 psf Dead Load and 100 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
800S137-33	33	7-11 e	5-11 e	3-11 e	6-4 a	4-9 a	3-2 a	7-11 e	5-11 e	3-11 e	6-4 a	4-9 a	3-2 a
800S162-33	33	7-11 e	5-11 e	3-11 e	6-4 a	4-9 a	3-2 a	7-11 e	5-11 e	3-11 e	6-4 a	4-9 a	3-2 a
800S200-33	33	7-11 e	5-11 e	3-11 e	6-4 a	4-9 a	3-2 a	7-11 e	5-11 e	3-11 e	6-4 a	4-9 a	3-2 a
800S137-43	33	10-10 e	9-4 e	7-8 e	10-10 a	9-4 a	7-0 a	10-10 e	9-4 e	7-8 e	10-10 a	9-4 a	7-0 a
800S162-43	33	11-5 e	9-11 e	8-1 e	11-5 a	9-11 a	7-0 a	11-5 e	9-11 e	8-1 e	11-5 a	9-11 a	7-0 a
800S200-43	33	11-4 e	9-10 e	8-0 e	11-4 a	9-10 a	7-0 a	11-4 e	9-10 e	8-0 e	11-4 a	9-10 a	7-0 a
800S250-43	33	12-2 e	10-6 e	8-7 e	12-2 a	10-6 a	7-0 a	12-2 e	10-6 e	8-7 e	12-2 a	10-6 a	7-0 a
800S300-43	33	12-10 e	11-1 e	8-9 e	12-10 a	10-6 a	7-0 a	12-10 e	11-1 e	8-9 e	12-10 a	10-6 a	7-0 a
800S137-54	33	12-0 e	10-5 e	8-6 e	12-0 i	10-5 i	8-6 a	11-10 e	10-5 e	8-6 e	12-0 i	10-5 i	8-6 a
800S137-54	50	13-0	11-10 e	10-4 e	14-7 i	12-8 i	10-4 a	11-10	10-9 e	9-5 e	13-3 i	12-1 i	10-4 a
800S162-54	33	12-9 e	11-1 e	9-0 e	12-9 i	11-1 a	9-0 a	12-3 e	11-1 e	9-0 e	12-9 i	11-1 a	9-0 a
800S162-54	50	13-6	12-3 e	10-9 e	15-2 i	13-5 i	11-0 a	12-3	11-2 e	9-9 e	13-10 i	12-6 i	10-11 a
800S200-54	33	13-3 e	11-6 e	9-4 e	13-3 i	11-6 a	9-4 a	12-9 e	11-6 e	9-4 e	13-3 i	11-6 a	9-4 a
800S200-54	50	14-1 e	12-9 e	10-9 e	15-3 i	13-3 i	10-9 a	12-9	11-7 e	10-1 e	14-4 i	13-0 i	10-9 a
800S250-54	33	13-11 e	12-1 e	9-10 e	13-11 i	12-1 a	9-10 a	13-5 e	12-1 e	9-10 e	13-11 i	12-1 a	9-10 a
800S250-54	50	14-9 e	13-4 e	11-6 e	16-3 i	14-1 a	11-6 a	13-4	12-2 e	10-7 e	15-0 i	13-8 i	11-6 a
800S300-54	33	14-9 e	12-9 e	10-5 e	14-9 a	12-9 a	10-5 a	14-0 e	12-9 e	10-5 e	14-9 a	12-9 a	10-5 a
800S300-54	50	15-3 e	13-11 e	12-0 e	17-0 i	14-8 a	12-0 a	13-11 e	12-7 e	11-0 e	15-7 i	14-2 a	12-0 a
800S137-68	33	13-5	11-7	9-6 e	13-5 i	11-7 i	9-6 i	12-9	11-7	9-6 e	13-5 i	11-7 i	9-6 i
800S137-68	50	14-0	12-9	11-1	15-9 i	14-3 i	11-8 i	12-9	11-7	10-1	14-3	13-0 i	11-4 i
800S162-68	33	14-3	12-4	10-1 e	14-3 i	12-4 i	10-1 i	13-3	12-0	10-1 e	14-3 i	12-4 i	10-1 i
800S162-68	50	14-7	13-3	11-7 e	16-4 i	14-10 i	12-5 i	13-3	12-0	10-6	14-10	13-6 i	11-9 i
800S200-68	33	15-0	13-0	10-7 e	15-0 i	13-0 i	10-7 i	13-9	12-6	10-7 e	15-0 i	13-0 i	10-7 i
800S200-68	50	15-1	13-9	12-0 e	17-0 i	15-5 i	12-9 i	13-9	12-6	10-11	15-5	14-0 i	12-3 i
800S250-68	33	15-11	13-10 e	11-4 e	16-0 i	13-10 i	11-4 i	14-5	13-2	11-4 e	16-0 i	13-10 i	11-4 i
800S250-68	50	15-11	14-5	12-7 e	17-10 i	16-1 i	13-2 i	14-5	13-2	11-6 e	16-3 i	14-9 i	12-10 i
800S300-68	33	16-7	14-4 e	11-8 e	16-7 i	14-4 i	11-8 i	15-1	13-9 e	11-8 e	16-7 i	14-4 i	11-8 i
800S300-68	50	16-7	15-1	13-2 e	18-7 i	16-11 i	13-11 i	15-1	13-8	11-11 e	16-11 i	15-4 i	13-5 i
800S162-97	33	16-3	14-6	11-10	16-9	14-6	11-10 i	14-9	13-5	11-8	16-7	14-6	11-10 i
800S162-97	50	16-3	14-9	12-11	18-3	16-7	14-6	14-9	13-5	11-8	16-7	15-1	13-2
800S200-97	33	16-10	15-4	12-7	17-9	15-5	12-7 i	15-4	13-11	12-2	17-3	15-5	12-7 i
800S200-97	50	16-10	15-4	13-5	18-11	17-3	15-0	15-4	13-11	12-2	17-3	15-8	13-8
800S250-97	33	17-9	16-2	13-7	19-3	16-8	13-7 i	16-2	14-8	12-10	18-2	16-6	13-7 i
800S250-97	50	17-9	16-2	14-1	20-0	18-2	15-10 i	16-2	14-8	12-10	18-2	16-6	14-5
800S300-97	33	18-7	16-11	14-5	20-5	17-8 i	14-5 i	16-11	15-4	13-5	19-0	17-3	14-5 i
800S300-97	50	18-7	16-11	14-9	20-11	19-0	16-7 i	16-11	15-4	13-5	19-0	17-3	15-1

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

15 psf Dead Load and 100 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
925S137-33	33	6-10 e	5-1 e	3-5 e	5-5 a	4-1 a	2-8 a	6-10 e	5-1 e	3-5 e	5-5 a	4-1 a	2-8 a
925S162-33	33	6-10 e	5-1 e	3-5 e	5-5 a	4-1 a	2-8 a	6-10 e	5-1 e	3-5 e	5-5 a	4-1 a	2-8 a
925S200-33	33	6-10 e	5-1 e	3-5 e	5-5 a	4-1 a	2-8 a	6-10 e	5-1 e	3-5 e	5-5 a	4-1 a	2-8 a
925S137-43	33	11-6 e	10-0 e	7-7 e	11-6 a	9-1 a	6-0 a	11-6 e	10-0 e	7-7 e	11-6 a	9-1 a	6-0 a
925S162-43	33	12-3 e	10-7 e	7-7 e	12-1 a	9-1 a	6-0 a	12-3 e	10-7 e	7-7 e	12-1 a	9-1 a	6-0 a
925S200-43	33	12-1 e	10-5 e	7-7 e	12-1 a	9-1 a	6-0 a	12-1 e	10-5 e	7-7 e	12-1 a	9-1 a	6-0 a
925S250-43	33	13-0 e	11-3 e	7-7 e	12-1 a	9-1 a	6-0 a	13-0 e	11-3 e	7-7 e	12-1 a	9-1 a	6-0 a
925S300-43	33	13-9 e	11-4 e	7-7 e	12-1 a	9-1 a	6-0 a	13-9 e	11-4 e	7-7 e	12-1 a	9-1 a	6-0 a
925S137-54	33	13-5 e	11-8 e	9-6 e	13-5 i	11-8 a	9-6 a	13-4 e	11-8 e	9-6 e	13-5 i	11-8 a	9-6 a
925S137-54	50	14-8 e	13-4 e	11-1 e	15-8 i	13-7 a	11-1 a	13-4 e	12-2 e	10-7 e	15-0 i	13-7 a	11-1 a
925S162-54	33	14-2 e	12-3 e	10-0 e	14-2 a	12-3 a	10-0 a	13-10 e	12-3 e	10-0 e	14-2 a	12-3 a	10-0 a
925S162-54	50	15-3 e	13-10 e	11-9 e	16-7 i	14-5 a	11-9 a	13-10 e	12-7 e	11-0 e	15-7 i	14-2 a	11-9 a
925S200-54	33	14-9 e	12-9 e	10-5 e	14-9 a	12-9 a	10-5 a	14-4 e	12-9 e	10-5 e	14-9 a	12-9 a	10-5 a
925S200-54	50	15-9 e	14-1 e	11-6 e	16-4 i	14-1 a	11-6 a	14-4 e	13-0 e	11-4 e	16-1 i	14-1 a	11-6 a
925S250-54	33	15-5 e	13-4 e	10-11 e	15-5 a	13-4 a	10-11 a	15-1 e	13-4 e	10-11 e	15-5 a	13-4 a	10-11 a
925S250-54	50	16-7 e	15-0 e	12-3 e	17-4 a	15-0 a	12-0 a	15-0 e	13-8 e	11-11 e	16-11 i	15-0 a	12-0 a
925S300-54	33	16-3 e	14-1 e	11-6 e	16-3 a	14-1 a	11-6 a	15-9 e	14-1 e	11-6 e	16-3 a	14-1 a	11-6 a
925S300-54	50	17-2 e	15-7 e	12-10 e	18-3 a	15-9 a	12-0 a	15-7 e	14-2 e	12-4 e	17-6 a	15-9 a	12-0 a
925S137-68	33	15-0	13-0 e	10-7 e	15-0 i	13-0 i	10-7 i	14-4	13-0 e	10-7 e	15-0 i	13-0 i	10-7 i
925S137-68	50	15-10	14-4	12-7 e	17-9 i	16-0 i	13-0 i	14-4	13-1	11-5 e	16-2 i	14-8 i	12-10 i
925S162-68	33	15-10	13-9 e	11-2 e	15-10 i	13-9 i	11-2 i	14-11	13-6 e	11-2 e	15-10 i	13-9 i	11-2 i
925S162-68	50	16-5	14-11	13-0 e	18-5 i	16-9 i	13-9 i	14-11	13-6	11-10 e	16-9 i	15-2 i	13-3 i
925S200-68	33	16-8	14-5 e	11-9 e	16-8 i	14-5 i	11-9 a	15-5	14-0 e	11-9 e	16-8 i	14-5 i	11-9 a
925S200-68	50	17-0	15-5	13-6 e	19-1 i	17-4 i	14-2 i	15-5	14-0	12-3 e	17-4 i	15-9 i	13-9 i
925S250-68	33	17-8 e	15-4 e	12-6 e	17-8 i	15-4 i	12-6 a	16-3	14-9 e	12-6 e	17-8 i	15-4 i	12-6 a
925S250-68	50	17-10	16-3	14-2 e	20-1 i	17-10 i	14-7 a	16-3	14-9	12-10 e	18-3 i	16-6 i	14-5 i
925S300-68	33	18-3 e	15-10 e	12-11 e	18-3 i	15-10 i	12-11 a	16-11	15-4 e	12-11 e	18-3 i	15-10 i	12-11 a
925S300-68	50	18-7	16-10 e	14-9 e	20-10 i	18-11 i	15-5 a	16-10	15-4	13-4 e	18-11 i	17-2 i	15-0 a
925S162-97	33	18-4	16-2	13-2	18-8	16-2	13-2 i	16-8	15-1	13-2	18-8	16-2	13-2 i
925S162-97	50	18-4	16-8	14-6	20-7	18-8	16-3 i	16-8	15-1	13-2	18-8	17-0	14-10
925S200-97	33	19-0	17-1	13-11	19-9	17-1	13-11 i	17-3	15-8	13-8	19-4	17-1	13-11 i
925S200-97	50	19-0	17-3	15-1	21-4	19-4	16-11 i	17-3	15-8	13-8	19-4	17-7	15-4 i
925S250-97	33	20-0	18-2	15-0	21-3	18-5 i	15-0 i	18-2	16-6	14-5	20-4	18-5 i	15-0 i
925S250-97	50	20-0	18-2	15-10	22-5	20-4	17-9 i	18-2	16-6	14-5	20-4	18-6	16-2 i
925S300-97	33	20-10	18-11	15-11	22-7	19-6 i	15-11 i	18-11	17-2	15-0	21-3	19-4 i	15-11 i
925S300-97	50	20-10	18-11	16-6	23-5	21-3	18-7 i	18-11	17-2	15-0	21-3	19-4	16-10 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

15 psf Dead Load and 100 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1000S137-33	33	6-3 e	4-8 e	3-1 e	5-0 a	3-9 a	2-6 a	6-3 e	4-8 e	3-1 e	5-0 a	3-9 a	2-6 a
1000S162-33	33	6-3 e	4-8 e	3-1 e	5-0 a	3-9 a	2-6 a	6-3 e	4-8 e	3-1 e	5-0 a	3-9 a	2-6 a
1000S200-33	33	6-3 e	4-8 e	3-1 e	5-0 a	3-9 a	2-6 a	6-3 e	4-8 e	3-1 e	5-0 a	3-9 a	2-6 a
1000S137-43	33	11-11 e	10-4 e	7-0 e	11-2 a	8-4 a	5-7 a	11-11 e	10-4 e	7-0 e	11-2 a	8-4 a	5-7 a
1000S162-43	33	12-8 e	10-6 e	7-0 e	11-2 a	8-4 a	5-7 a	12-8 e	10-6 e	7-0 e	11-2 a	8-4 a	5-7 a
1000S200-43	33	12-6 e	10-6 e	7-0 e	11-2 a	8-4 a	5-7 a	12-6 e	10-6 e	7-0 e	11-2 a	8-4 a	5-7 a
1000S250-43	33	13-6 e	10-6 e	7-0 e	11-2 a	8-4 a	5-7 a	13-6 e	10-6 e	7-0 e	11-2 a	8-4 a	5-7 a
1000S300-43	33	14-0 e	10-6 e	7-0 e	11-2 a	8-4 a	5-7 a	14-0 e	10-6 e	7-0 e	11-2 a	8-4 a	5-7 a
1000S137-54	33	14-3 e	12-4 e	10-1 e	14-3 a	12-4 a	10-1 a	14-3 e	12-4 e	10-1 e	14-3 a	12-4 a	10-1 a
1000S137-54	50	15-8 e	14-1 e	11-6 e	16-3 i	14-1 a	11-1 a	14-3 e	12-11 e	11-4 e	16-0 i	14-1 a	11-1 a
1000S162-54	33	15-0 e	13-0 e	10-7 e	15-0 a	13-0 a	10-7 a	14-9 e	13-0 e	10-7 e	15-0 a	13-0 a	10-7 a
1000S162-54	50	16-3 e	14-9 e	12-2 e	17-2 a	14-11 a	11-1 a	14-9 e	13-5 e	11-9 e	16-7 i	14-11 a	11-1 a
1000S200-54	33	15-7 e	13-6 e	11-0 e	15-7 a	13-6 a	11-0 a	15-3 e	13-6 e	11-0 e	15-7 a	13-6 a	11-0 a
1000S200-54	50	16-10 e	14-8 e	11-11 e	16-11 a	14-8 a	11-1 a	15-3 e	13-11 e	11-11 e	16-11 a	14-8 a	11-1 a
1000S250-54	33	16-1 e	13-11 e	11-4 e	16-1 a	13-11 a	11-1 a	16-0 e	13-11 e	11-4 e	16-1 a	13-11 a	11-1 a
1000S250-54	50	17-8 e	15-7 e	12-9 e	18-0 a	15-7 a	11-1 a	16-0 e	14-7 e	12-8 e	18-0 a	15-7 a	11-1 a
1000S300-54	33	16-11 e	14-8 e	11-11 e	16-11 a	14-8 a	11-1 a	16-8 e	14-8 e	11-11 e	16-11 a	14-8 a	11-1 a
1000S300-54	50	18-3 e	16-4 e	13-4 e	18-11 a	16-4 a	11-1 a	16-7 e	15-1 e	13-2 e	18-8 a	16-4 a	11-1 a
1000S137-68	33	15-11	13-9 e	11-3 e	15-11 i	13-9 i	11-3 a	15-4	13-9 e	11-3 e	15-11 i	13-9 i	11-3 a
1000S137-68	50	16-11	15-4	13-5 e	19-0 i	17-0 i	13-10 i	15-4	13-11	12-2 e	17-3 i	15-8 i	13-8 i
1000S162-68	33	16-9	14-6 e	11-10 e	16-9 i	14-6 i	11-10 a	15-11	14-5 e	11-10 e	16-9 i	14-6 i	11-10 a
1000S162-68	50	17-6	15-11 e	13-11 e	19-8 i	17-10 i	14-7 a	15-11	14-5	12-7 e	17-10 i	16-3 i	14-2 a
1000S200-68	33	17-8 e	15-3 e	12-6 e	17-8 i	15-3 i	12-6 a	16-5	14-11 e	12-6 e	17-8 i	15-3 i	12-6 a
1000S200-68	50	18-1	16-5 e	14-4 e	20-4 i	18-5 i	15-0 a	16-5	14-11	13-1 e	18-6 i	16-9 i	14-8 a
1000S250-68	33	18-8 e	16-2 e	13-2 e	18-8 i	16-2 i	13-2 a	17-3 e	15-8 e	13-2 e	18-8 i	16-2 i	13-2 a
1000S250-68	50	19-0	17-3 e	15-1 e	21-4 i	18-7 i	15-2 a	17-3	15-8	13-8 e	19-5 i	17-7 i	15-2 a
1000S300-68	33	19-4 e	16-9 e	13-8 e	19-4 i	16-9 i	13-8 a	18-0 e	16-4 e	13-8 e	19-4 i	16-9 i	13-8 a
1000S300-68	50	19-9	17-11 e	15-8 e	22-2 i	19-7 i	16-0 a	17-11	16-3 e	14-3 e	20-2 i	18-4 i	16-0 a
1000S162-97	33	19-7	17-2	14-0	19-10	17-2 i	14-0 i	17-9	16-2	14-0	19-10	17-2 i	14-0 i
1000S162-97	50	19-7	17-9	15-6	22-0	19-11	17-3 i	17-9	16-2	14-1	19-11	18-1	15-10 i
1000S200-97	33	20-3	18-1	14-9	20-10	18-1 i	14-9 i	18-5	16-8	14-7	20-8	18-1 i	14-9 i
1000S200-97	50	20-3	18-5	16-1	22-9	20-8	18-0 i	18-5	16-8	14-7	20-8	18-9	16-5 i
1000S250-97	33	21-3	19-4	15-10	22-5	19-5 i	15-10 i	19-4	17-6	15-4	21-8	19-5 i	15-10 i
1000S250-97	50	21-3	19-4	16-10	23-10	21-8	18-11 i	19-4	17-6	15-4	21-8	19-8	17-2 i
1000S300-97	33	22-2	20-2	16-10	23-9 i	20-7 i	16-10 i	20-2	18-3	16-0	22-7 i	20-6 i	16-10 i
1000S300-97	50	22-2	20-2	17-7	24-11	22-7	19-9 i	20-2	18-3	16-0	22-7	20-6	17-11 i

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

15 psf Dead Load and 100 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1125S137-33	33	5-7 e	4-2 e	2-9 e	4-5 a	3-4 a	2-2 a	5-7 e	4-2 e	2-9 e	4-5 a	3-4 a	2-2 a
1125S162-33	33	5-7 e	4-2 e	2-9 e	4-5 a	3-4 a	2-2 a	5-7 e	4-2 e	2-9 e	4-5 a	3-4 a	2-2 a
1125S200-33	33	5-7 e	4-2 e	2-9 e	4-5 a	3-4 a	2-2 a	5-7 e	4-2 e	2-9 e	4-5 a	3-4 a	2-2 a
1125S137-43	33	12-4 e	9-3 e	6-2 e	9-11 a	7-5 a	4-11 a	12-4 e	9-3 e	6-2 e	9-11 a	7-5 a	4-11 a
1125S162-43	33	12-4 e	9-3 e	6-2 e	9-11 a	7-5 a	4-11 a	12-4 e	9-3 e	6-2 e	9-11 a	7-5 a	4-11 a
1125S200-43	33	12-4 e	9-3 e	6-2 e	9-11 a	7-5 a	4-11 a	12-4 e	9-3 e	6-2 e	9-11 a	7-5 a	4-11 a
1125S250-43	33	12-4 e	9-3 e	6-2 e	9-11 a	7-5 a	4-11 a	12-4 e	9-3 e	6-2 e	9-11 a	7-5 a	4-11 a
1125S200-43	33	12-4 e	9-3 e	6-2 e	9-11 a	7-5 a	4-11 a	12-4 e	9-3 e	6-2 e	9-11 a	7-5 a	4-11 a
1125S137-54	33	15-0 e	13-0 e	10-7 e	15-0 a	13-0 a	9-10 a	15-0 e	13-0 e	10-7 e	15-0 a	13-0 a	9-10 a
1125S137-54	50	17-1 e	14-10 e	12-1 e	17-1 a	14-9 a	9-10 a	15-9 e	14-4 e	12-1 e	17-1 a	14-9 a	9-10 a
1125S162-54	33	15-10 e	13-9 e	11-2 e	15-10 a	13-9 a	9-10 a	15-10 e	13-9 e	11-2 e	15-10 a	13-9 a	9-10 a
1125S162-54	50	17-11 e	15-9 e	12-3 e	18-2 a	14-9 a	9-10 a	16-4 e	14-10 e	12-3 e	18-2 a	14-9 a	9-10 a
1125S200-54	33	16-4 e	14-2 e	11-7 e	16-4 a	14-2 a	9-10 a	16-4 e	14-2 e	11-7 e	16-4 a	14-2 a	9-10 a
1125S200-54	50	17-10 e	15-6 e	12-3 e	17-10 a	14-9 a	9-10 a	16-10 e	15-4 e	12-3 e	17-10 a	14-9 a	9-10 a
1125S250-54	33	17-0 e	14-8 e	12-0 e	17-0 a	14-8 a	9-10 a	17-0 e	14-8 e	12-0 e	17-0 a	14-8 a	9-10 a
1125S250-54	50	19-1 e	16-6 e	12-3 e	19-1 a	14-9 a	9-10 a	17-7 e	16-0 e	12-3 e	19-1 a	14-9 a	9-10 a
1125S300-54	33	17-10 e	15-6 e	12-3 e	17-10 a	14-9 a	9-10 a	17-10 e	15-6 e	12-3 e	17-10 a	14-9 a	9-10 a
1125S300-54	50	20-0 e	17-4 e	12-3 e	19-8 a	14-9 a	9-10 a	18-3 e	16-7 e	12-3 e	19-8 a	14-9 a	9-10 a
1125S137-68	33	17-5 e	15-1 e	12-4 e	17-5 i	15-1 i	12-4 a	17-0 e	15-1 e	12-4 e	17-5 i	15-1 i	12-4 a
1125S137-68	50	18-8	17-0 e	14-9 e	20-10 i	18-1 i	14-9 a	17-0	15-5 e	13-6 e	19-1 i	17-4 i	14-9 a
1125S162-68	33	18-4 e	15-11 e	13-0 e	18-4 i	15-11 i	13-0 a	17-7 e	15-11 e	13-0 e	18-4 i	15-11 i	13-0 a
1125S162-68	50	19-4	17-7 e	15-4 e	21-8 i	19-1 i	15-7 a	17-7	15-11 e	13-11 e	19-9 i	17-11 i	15-7 a
1125S200-68	33	19-3 e	16-8 e	13-7 e	19-3 i	16-8 a	13-7 a	18-2 e	16-6 e	13-7 e	19-3 i	16-8 a	13-7 a
1125S200-68	50	19-11	18-2 e	15-10 e	22-5 i	19-4 i	15-10 a	18-2	16-6 e	14-5 e	20-4 i	18-6 i	15-10 a
1125S250-68	33	20-4 e	17-7 e	14-4 e	20-4 i	17-7 a	14-4 a	19-0 e	17-3 e	14-4 e	20-4 i	17-7 a	14-4 a
1125S250-68	50	20-11 e	19-0 e	16-0 e	22-7 i	19-7 i	16-0 a	19-0	17-3 e	15-1 e	21-4 i	19-4 i	16-0 a
1125S300-68	33	21-0 e	18-2 e	14-10 e	21-0 i	18-2 a	14-10 a	19-9 e	17-11 e	14-10 e	21-0 i	18-2 a	14-10 a
1125S300-68	50	21-9 e	19-9 e	16-11 e	23-11 i	20-8 a	16-11 a	19-9	17-11 e	15-8 e	22-2 i	20-1 i	16-11 a
1125S162-97	33	21-7	18-9	15-4	21-8	18-9 i	15-4 i	19-7	17-10	15-4	21-8	18-9 i	15-4 i
1125S162-97	50	21-7	19-7	17-2	24-3	22-0	18-11 i	19-7	17-10	15-7	22-0	20-0	17-6 i
1125S200-97	33	22-4	19-9	16-1	22-9 i	19-9 i	16-1 i	20-3	18-5	16-1	22-9 i	19-9 i	16-1 i
1125S200-97	50	22-4	20-3	17-8	25-1	22-9 i	19-9 i	20-3	18-5	16-1	22-9	20-8	18-1 i
1125S250-97	33	23-4	21-2	17-3	24-5 i	21-2 i	17-3 i	21-3	19-3	16-10	23-10 i	21-2 i	17-3 i
1125S250-97	50	23-4	21-3	18-7	26-3	23-10 i	20-10 i	21-3	19-3	16-10	23-10	21-8	18-11 i
1125S300-97	33	24-4	22-1	18-3 e	25-10 i	22-4 i	18-3 i	22-1	20-1	17-6 e	24-10 i	22-4 i	18-3 i
1125S300-97	50	24-4	22-1	19-4	27-4	24-10 i	21-8 i	22-1	20-1	17-6	24-10	22-7 i	19-8 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

15 psf Dead Load and 100 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1200S137-33	33	5-2 e	3-11 e	2-7 e	4-2 a	3-1 a	2-1 a	5-2 e	3-11 e	2-7 e	4-2 a	3-1 a	2-1 a
1200S162-33	33	5-2 e	3-11 e	2-7 e	4-2 a	3-1 a	2-1 a	5-2 e	3-11 e	2-7 e	4-2 a	3-1 a	2-1 a
1200S200-33	33	5-2 e	3-11 e	2-7 e	4-2 a	3-1 a	2-1 a	5-2 e	3-11 e	2-7 e	4-2 a	3-1 a	2-1 a
1200S137-43	33	11-7 e	8-8 e	5-9 e	9-3 a	6-11 a	4-7 a	11-7 e	8-8 e	5-9 e	9-3 a	6-11 a	4-7 a
1200S162-43	33	11-7 e	8-8 e	5-9 e	9-3 a	6-11 a	4-7 a	11-7 e	8-8 e	5-9 e	9-3 a	6-11 a	4-7 a
1200S200-43	33	11-7 e	8-8 e	5-9 e	9-3 a	6-11 a	4-7 a	11-7 e	8-8 e	5-9 e	9-3 a	6-11 a	4-7 a
1200S250-43	33	11-7 e	8-8 e	5-9 e	9-3 a	6-11 a	4-7 a	11-7 e	8-8 e	5-9 e	9-3 a	6-11 a	4-7 a
1200S300-43	33	11-7 e	8-8 e	5-9 e	9-3 a	6-11 a	4-7 a	11-7 e	8-8 e	5-9 e	9-3 a	6-11 a	4-7 a
1200S137-54	33	15-5 e	13-4 e	10-11 e	15-5 a	13-4 a	9-2 a	15-5 e	13-4 e	10-11 e	15-5 a	13-4 a	9-2 a
1200S137-54	50	17-8 e	15-3 e	11-6 e	17-8 a	13-9 a	9-2 a	16-8 e	15-2 e	11-6 e	17-8 a	13-9 a	9-2 a
1200S162-54	33	16-4 e	14-1 e	11-6 e	16-4 a	13-9 a	9-2 a	16-4 e	14-1 e	11-6 e	16-4 a	13-9 a	9-2 a
1200S162-54	50	18-8 e	16-2 e	11-6 e	18-4 a	13-9 a	9-2 a	17-3 e	15-8 e	11-6 e	18-4 a	13-9 a	9-2 a
1200S200-54	33	16-10 e	14-7 e	11-6 e	16-10 a	13-9 a	9-2 a	16-10 e	14-7 e	11-6 e	16-10 a	13-9 a	9-2 a
1200S200-54	50	18-5 e	15-11 e	11-6 e	18-4 a	13-9 a	9-2 a	17-9 e	15-11 e	11-6 e	18-4 a	13-9 a	9-2 a
1200S250-54	33	17-6 e	15-1 e	11-6 e	17-6 a	13-9 a	9-2 a	17-6 e	15-1 e	11-6 e	17-6 a	13-9 a	9-2 a
1200S250-54	50	19-8 e	17-0 e	11-6 e	18-4 a	13-9 a	9-2 a	18-7 e	16-10 e	11-6 e	18-4 a	13-9 a	9-2 a
1200S300-54	33	18-5 e	15-11 e	11-6 e	18-4 a	13-9 a	9-2 a	18-5 e	15-11 e	11-6 e	18-4 a	13-9 a	9-2 a
1200S300-54	50	20-8 e	17-3 e	11-6 e	18-4 a	13-9 a	9-2 a	19-3 e	17-3 e	11-6 e	18-4 a	13-9 a	9-2 a
1200S137-68	33	18-4 e	15-11 e	13-0 e	18-4 i	15-11 a	13-0 a	17-11 e	15-11 e	13-0 e	18-4 i	15-11 a	13-0 a
1200S137-68	50	19-9 e	17-11 e	15-1 e	21-5 i	18-6 i	15-1 a	17-11 e	16-4 e	14-3 e	20-2 i	18-4 i	15-1 a
1200S162-68	33	19-3 e	16-8 e	13-8 e	19-3 i	16-8 a	13-8 a	18-6 e	16-8 e	13-8 e	19-3 i	16-8 a	13-8 a
1200S162-68	50	20-5 e	18-6 e	16-0 e	22-7 i	19-7 i	16-0 a	18-6 e	16-10 e	14-8 e	20-10 i	18-11 i	16-0 a
1200S200-68	33	20-2 e	17-6 e	14-3 e	20-2 i	17-6 a	14-3 a	19-1 e	17-4 e	14-3 e	20-2 i	17-6 a	14-3 a
1200S200-68	50	21-1 e	19-1 e	16-3 e	23-0 i	19-11 a	16-3 a	19-1 e	17-4 e	15-2 e	21-6 i	19-6 i	16-3 a
1200S250-68	33	21-3 e	18-5 e	15-1 e	21-3 a	18-5 a	15-1 a	20-0 e	18-2 e	15-1 e	21-3 a	18-5 a	15-1 a
1200S250-68	50	22-0 e	20-0 e	16-5 e	23-3 i	20-2 a	16-5 a	20-0 e	18-2 e	15-10 e	22-5 i	20-2 a	16-5 a
1200S300-68	33	21-11 e	19-0 e	15-6 e	21-11 a	19-0 a	15-6 a	20-9 e	18-11 e	15-6 e	21-11 a	19-0 a	15-6 a
1200S300-68	50	22-11 e	20-9 e	17-5 e	24-7 i	21-4 a	17-5 a	20-9 e	18-11 e	16-6 e	23-4 i	21-3 a	17-5 a
1200S162-97	33	22-10	19-9	16-1	22-10 i	19-9 i	16-1 i	20-9	18-10	16-1	22-10 i	19-9 i	16-1 i
1200S162-97	50	22-10	20-9	18-1	25-8	23-3 i	19-10 i	20-9	18-10	16-5	23-3	21-2	18-6 i
1200S200-97	33	23-7	20-8	16-11	23-11 i	20-8 i	16-11 i	21-5	19-5	16-11	23-11 i	20-8 i	16-11 i
1200S200-97	50	23-7	21-5	18-8	26-5	24-0 i	20-9 i	21-5	19-5	17-0	24-0	21-10	19-1 i
1200S250-97	33	24-8	22-2	18-1 e	25-7 i	22-2 i	18-1 i	22-5	20-4	17-9 e	25-2 i	22-2 i	18-1 i
1200S250-97	50	24-8	22-5	19-7	27-8	25-2 i	21-10 i	22-5	20-4	17-9	25-2	22-10 i	19-11 i
1200S300-97	33	25-8	23-3	19-1 e	27-0 i	23-5 i	19-1 i	23-3	21-2	18-6 e	26-2 i	23-5 i	19-1 i
1200S300-97	50	25-8	23-3	20-4	28-9	26-2 i	22-9 i	23-3	21-2	18-6	26-2	23-9 i	20-9 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

15 psf Dead Load and 100 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1400S137-33	33	4-5 e	3-4 e	2-2 e	3-6 a	2-8 a	1-9 a	4-5 e	3-4 e	2-2 e	3-6 a	2-8 a	1-9 a
1400S162-33	33	4-5 e	3-4 e	2-2 e	3-6 a	2-8 a	1-9 a	4-5 e	3-4 e	2-2 e	3-6 a	2-8 a	1-9 a
1400S200-33	33	4-5 e	3-4 e	2-2 e	3-6 a	2-8 a	1-9 a	4-5 e	3-4 e	2-2 e	3-6 a	2-8 a	1-9 a
1400S137-43	33	9-11 e	7-5 e	4-11 e	7-11 a	5-11 a	3-11 a	9-11 e	7-5 e	4-11 e	7-11 a	5-11 a	3-11 a
1400S162-43	33	9-11 e	7-5 e	4-11 e	7-11 a	5-11 a	3-11 a	9-11 e	7-5 e	4-11 e	7-11 a	5-11 a	3-11 a
1400S200-43	33	9-11 e	7-5 e	4-11 e	7-11 a	5-11 a	3-11 a	9-11 e	7-5 e	4-11 e	7-11 a	5-11 a	3-11 a
1400S250-43	33	9-11 e	7-5 e	4-11 e	7-11 a	5-11 a	3-11 a	9-11 e	7-5 e	4-11 e	7-11 a	5-11 a	3-11 a
1400S300-43	33	9-11 e	7-5 e	4-11 e	7-11 a	5-11 a	3-11 a	9-11 e	7-5 e	4-11 e	7-11 a	5-11 a	3-11 a
1400S137-54	33	16-6 e	14-3 e	9-9 e	15-8 a	11-9 a	7-10 a	16-6 e	14-3 e	9-9 e	15-8 a	11-9 a	7-10 a
1400S137-54	50	19-0 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a	18-7 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a
1400S162-54	33	17-6 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a	17-6 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a
1400S162-54	50	19-7 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a	19-2 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a
1400S200-54	33	18-0 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a	18-0 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a
1400S200-54	50	19-7 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a	19-7 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a
1400S250-54	33	18-9 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a	18-9 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a
1400S250-54	50	19-7 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a	19-7 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a
1400S300-54	33	19-7 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a	19-7 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a
1400S300-54	50	19-7 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a	19-7 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a
1400S137-68	33	19-11 e	17-3 e	14-1 e	19-11 a	17-3 a	14-1 a	19-11 e	17-3 e	14-1 e	19-11 a	17-3 a	14-1 a
1400S137-68	50	22-7 e	19-10 e	16-2 e	22-10 i	19-10 a	15-8 a	20-6 e	18-8 e	16-2 e	22-10 i	19-10 a	15-8 a
1400S162-68	33	20-11 e	18-2 e	14-10 e	20-11 a	18-2 a	14-10 a	20-11 e	18-2 e	14-10 e	20-11 a	18-2 a	14-10 a
1400S162-68	50	23-3 e	20-11 e	17-1 e	24-2 i	20-11 a	15-8 a	21-2 e	19-3 e	16-9 e	23-9 i	20-11 a	15-8 a
1400S200-68	33	21-11 e	18-11 e	15-6 e	21-11 a	18-11 a	15-6 a	21-9 e	18-11 e	15-6 e	21-11 a	18-11 a	15-6 a
1400S200-68	50	23-11 e	21-4 e	17-5 e	24-8 a	21-4 a	15-8 a	21-9 e	19-9 e	17-3 e	24-5 a	21-4 a	15-8 a
1400S250-68	33	23-0 e	19-11 e	16-3 e	23-0 a	19-11 a	15-8 a	22-8 e	19-11 e	16-3 e	23-0 a	19-11 a	15-8 a
1400S250-68	50	25-0 e	21-8 e	17-8 e	25-0 a	21-8 a	15-8 a	22-8 e	20-7 e	17-8 e	25-0 a	21-8 a	15-8 a
1400S300-68	33	23-5 e	20-4 e	16-7 e	23-5 a	20-4 a	15-8 a	23-5 e	20-4 e	16-7 e	23-5 a	20-4 a	15-8 a
1400S300-68	50	25-11 e	22-11 e	18-9 e	26-6 a	22-11 a	15-8 a	23-6 e	21-5 e	18-8 e	26-5 a	22-11 a	15-8 a
1400S162-97	33	25-9	22-3	18-2 e	25-9 i	22-3 i	18-2 i	23-8	21-6	18-2 e	25-9 i	22-3 i	18-2 i
1400S162-97	50	26-1	23-8	20-8 e	29-3 i	26-7 i	22-5 i	23-8	21-6	18-9	26-7	24-2 i	21-1 i
1400S200-97	33	26-10	23-3	19-0 e	26-11 i	23-3 i	19-0 i	24-4	22-1	19-0 e	26-11 i	23-3 i	19-0 i
1400S200-97	50	26-10	24-4	21-3 e	30-1 i	27-4 i	23-4 i	24-4	22-1	19-4	27-4	24-10 i	21-8 i
1400S250-97	33	28-0	24-10 e	20-3 e	28-8 i	24-10 i	20-3 i	25-5	23-1	20-2 e	28-6 i	24-10 i	20-3 i
1400S250-97	50	28-0	25-5	22-2 e	31-5 i	28-6 i	24-6 i	25-5	23-1	20-2	28-6 i	25-11 i	22-8 i
1400S300-97	33	29-0	26-1 e	21-4 e	30-2 i	26-1 i	21-4 i	26-4	23-11	20-11 e	29-7 i	26-1 i	21-4 i
1400S300-97	50	29-0	26-4	23-0 e	32-7 i	29-7 i	25-5 i	26-4	23-11	20-11 e	29-7 i	26-11 i	23-6 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 20 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
600S137-33	33	14-11 e	12-11 e	10-6 e	14-11 i	12-11 i	10-6 a	13-8	12-5 e	10-6 e	14-11 i	12-11 i	10-6 a
600S162-33	33	15-8 e	13-8 e	11-2 e	15-9 i	13-8 i	11-2 a	14-3	12-11 e	11-2 e	15-9 i	13-8 i	11-2 a
600S200-33	33	16-0 e	13-10 e	11-4 e	16-0 i	13-10 i	11-4 a	14-10 e	13-6 e	11-4 e	16-0 i	13-10 i	11-4 a
600S137-43	33	16-5	14-10	12-2	17-2	14-10 i	12-2 i	14-11	13-6	11-10	16-8	14-10 i	12-2 i
600S162-43	33	17-1	15-6	12-11	18-4	15-10 i	12-11 i	15-6	14-1	12-4	17-5	15-10 i	12-11 i
600S200-43	33	17-10	15-11	13-0	18-5	15-11 i	13-0 i	16-2	14-8	12-10	18-2	15-11 i	13-0 i
600S250-43	33	18-10	17-1	14-1 e	19-11 i	17-3 i	14-1 i	17-1	15-6	13-7	19-2	17-3 i	14-1 i
600S300-43	33	19-7	17-10	14-11 e	21-1 i	18-3 i	14-11 i	17-10	16-2	14-1 e	20-0 i	18-2 i	14-11 i
600S137-54	33	17-7	16-0	13-6	19-2	16-7	13-6	16-0	14-6	12-8	17-11	16-4	13-6
600S137-54	50	17-7	16-0	13-11	19-9	17-11	15-8	16-0	14-6	12-8	17-11	16-4	14-3
600S162-54	33	18-4	16-8	14-5	20-5	17-8	14-5	16-8	15-2	13-3	18-9	17-0	14-5
600S162-54	50	18-4	16-8	14-7	20-7	18-9	16-4	16-8	15-2	13-3	18-9	17-0	14-10
600S200-54	33	19-2	17-5	15-1	21-4	18-6	15-1 i	17-5	15-9	13-9	19-6	17-9	15-1 i
600S200-54	50	19-2	17-5	15-2	21-6	19-6	17-1	17-5	15-9	13-9	19-6	17-9	15-6
600S250-54	33	20-3	18-5	15-11	22-6	19-6	15-11 i	18-5	16-8	14-7	20-8	18-9	15-11 i
600S250-54	50	20-1	18-3	16-0	22-7	20-6	17-11	18-3	16-7	14-6	20-6	18-8	16-3
600S300-54	33	21-2	19-3	16-10	23-10	20-8	16-10 i	19-3	17-6	15-3	21-8	19-8	16-10 i
600S300-54	50	20-11	19-0	16-7	23-6	21-4	18-8	19-0	17-3	15-1	21-4	19-5	16-11
600S137-68	33	18-11	17-2	15-0	21-3	18-5	15-1	17-2	15-7	13-7	19-3	17-6	15-1
600S137-68	50	18-11	17-2	15-0	21-3	19-3	16-10	17-2	15-7	13-7	19-3	17-6	15-4
600S162-68	33	19-9	17-11	15-8	22-2	19-8	16-1	17-11	16-3	14-3	20-2	18-3	16-0
600S162-68	50	19-9	17-11	15-8	22-2	20-2	17-7	17-11	16-3	14-3	20-2	18-3	16-0
600S200-68	33	20-7	18-8	16-4	23-1	20-11	17-1	18-8	17-0	14-10	21-0	19-1	16-8
600S200-68	50	20-7	18-8	16-4	23-1	21-0	18-4	18-8	17-0	14-10	21-0	19-1	16-8
600S250-68	33	21-9	19-9	17-3	24-5	22-2	18-3	19-9	17-11	15-8	22-2	20-2	17-7
600S250-68	50	21-9	19-9	17-3	24-5	22-2	19-5	19-9	17-11	15-8	22-2	20-2	17-7
600S300-68	33	22-10	20-9	18-1	25-7	23-2	18-11	20-9	18-10	16-5	23-3	21-2	18-6
600S300-68	50	22-9	20-8	18-0	25-6	23-2	20-3	20-8	18-9	16-5	23-2	21-1	18-5
600S162-97	33	22-0	20-0	17-5	24-8	22-5	18-11	20-0	18-2	15-10	22-5	20-4	17-10
600S162-97	50	22-0	20-0	17-5	24-8	22-5	19-7	20-0	18-2	15-10	22-5	20-4	17-10
600S200-97	33	22-11	20-10	18-2	25-9	23-5	20-1	20-10	18-11	16-6	23-5	21-3	18-7
600S200-97	50	22-11	20-10	18-2	25-9	23-5	20-5	20-10	18-11	16-6	23-5	21-3	18-7
600S250-97	33	24-3	22-1	19-3	27-3	24-9	21-8	22-1	20-0	17-6	24-9	22-6	19-8
600S250-97	50	24-3	22-1	19-3	27-3	24-9	21-8	22-1	20-0	17-6	24-9	22-6	19-8
600S300-97	33	25-6	23-2	20-3	28-7	26-0	22-8	23-2	21-0	18-4	26-0	23-7	20-7
600S300-97	50	25-6	23-2	20-3	28-7	26-0	22-8	23-2	21-0	18-4	26-0	23-7	20-7

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 20 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
800S137-33	33	17-0 e	14-9 e	12-0 e	17-0 a	14-9 a	12-0 a	17-0 e	14-9 e	12-0 e	17-0 a	14-9 a	12-0 a
800S162-33	33	18-1 e	15-8 e	12-9 e	18-1 a	15-8 a	12-2 a	18-0 e	15-8 e	12-9 e	18-1 a	15-8 a	12-2 a
800S200-33	33	18-4 e	15-10 e	12-11 e	18-4 a	15-10 a	12-2 a	18-4 e	15-10 e	12-11 e	18-4 a	15-10 a	12-2 a
800S137-43	33	20-9	18-4	15-0 e	21-2 i	18-4 i	15-0 i	18-10	17-1	14-11 e	21-2 i	18-4 i	15-0 i
800S162-43	33	21-7	19-5 e	15-10 e	22-5 i	19-5 i	15-10 i	19-7	17-9	15-6 e	22-0 i	19-5 i	15-10 i
800S200-43	33	22-2	19-3 e	15-8 e	22-2 i	19-3 i	15-8 i	20-4	18-5	15-8 e	22-2 i	19-3 i	15-8 i
800S250-43	33	23-6	20-8 e	16-10 e	23-11 i	20-8 i	16-10 a	21-4	19-5 e	16-10 e	23-11 i	20-8 i	16-10 a
800S300-43	33	24-6	21-10 e	17-10 e	25-2 i	21-10 i	17-10 a	22-3	20-2 e	17-8 e	25-0 i	21-10 i	17-10 a
800S137-54	33	22-3	20-3	16-8	23-7	20-5	16-8 i	20-3	18-5	16-1	22-9	20-5	16-8 i
800S137-54	50	22-3	20-3	17-8	25-0	22-9	19-10 i	20-3	18-5	16-1	22-9	20-8	18-0
800S162-54	33	23-2	21-1	17-8	25-0	21-8 i	17-8 i	21-1	19-1	16-8	23-8	21-6 i	17-8 i
800S162-54	50	23-2	21-1	18-5	26-0	23-8	20-8 i	21-1	19-1	16-8	23-8	21-6	18-9 i
800S200-54	33	24-0	21-10	18-5	26-0	22-6 i	18-5 i	21-10	19-10	17-4	24-6	22-3 i	18-5 i
800S200-54	50	24-0	21-10	19-1	27-0	24-6	21-2 i	21-10	19-10	17-4	24-6	22-3	19-5 i
800S250-54	33	25-4	23-0	19-4	27-4	23-8 i	19-4 i	23-0	20-11	18-3	25-10	23-5 i	19-4 i
800S250-54	50	25-2	22-11	20-0	28-4	25-8	22-5 i	22-11	20-10	18-2	25-8	23-4	20-5 i
800S300-54	33	26-5	24-0	20-5	28-11 i	25-0 i	20-5 i	24-0	21-10	19-1	27-0	24-6 i	20-5 i
800S300-54	50	26-2	23-9	20-9	29-4	26-8	23-4 i	23-9	21-7	18-10	26-8	24-3	21-2 i
800S137-68	33	24-0	21-9	18-7	26-4	22-9	18-7	21-9	19-9	17-3	24-5	22-2	18-7
800S137-68	50	24-0	21-9	19-0	26-11	24-5	21-4	21-9	19-9	17-3	24-5	22-2	19-5
800S162-68	33	24-11	22-8	19-9	27-11	24-2	19-9	22-8	20-7	17-11	25-5	23-1	19-9
800S162-68	50	24-11	22-8	19-9	28-0	25-5	22-2	22-8	20-7	17-11	25-5	23-1	20-2
800S200-68	33	25-10	23-6	20-6	29-1	26-5	23-1	23-6	21-4	18-8	26-5	24-0	20-10
800S200-68	50	25-10	23-6	20-6	29-1	26-5	23-1	23-6	21-4	18-8	26-5	24-0	20-11
800S250-68	33	27-3	24-9	21-7	30-7	27-2	22-2 i	24-9	22-6	19-8	27-9	25-3	22-1
800S250-68	50	27-3	24-9	21-7	30-7	27-9	24-3	24-9	22-6	19-8	27-9	25-3	22-1
800S300-68	33	28-6	25-10	22-7	32-0	28-1	22-11 i	25-10	23-6	20-6	29-0	26-5	22-11 i
800S300-68	50	28-4	25-9	22-6	31-10	28-11	25-3	25-9	23-5	20-5	28-11	26-3	22-11
800S162-97	33	27-10	25-3	22-1	31-3	28-4	23-3	25-3	22-11	20-0	28-4	25-9	22-6
800S162-97	50	27-10	25-3	22-1	31-3	28-4	24-9	25-3	22-11	20-0	28-4	25-9	22-6
800S200-97	33	28-11	26-3	22-11	32-5	29-6	24-7	26-3	23-10	20-10	29-6	26-9	23-4
800S200-97	50	28-11	26-3	22-11	32-5	29-6	25-9	26-3	23-10	20-10	29-6	26-9	23-4
800S250-97	33	30-5	27-8	24-2	34-2	31-1	26-7	27-8	25-1	21-11	31-1	28-2	24-8
800S250-97	50	30-5	27-8	24-2	34-2	31-1	27-1	27-8	25-1	21-11	31-1	28-2	24-8
800S300-97	33	31-10	28-11	25-3	35-9	32-6	28-4	28-11	26-3	22-11	32-6	29-6	25-9
800S300-97	50	31-10	28-11	25-3	35-9	32-6	28-4	28-11	26-3	22-11	32-6	29-6	25-9

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 20 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
925S137-33	33	18-3 e	15-9 e	12-11 e	18-3 a	15-8 a	10-5 a	18-3 e	15-9 e	12-11 e	18-3 a	15-8 a	10-5 a
925S162-33	33	19-5 e	16-9 e	13-1 e	19-5 a	15-8 a	10-5 a	19-5 e	16-9 e	13-1 e	19-5 a	15-8 a	10-5 a
925S200-33	33	19-8 e	17-0 e	13-1 e	19-8 a	15-8 a	10-5 a	19-8 e	17-0 e	13-1 e	19-8 a	15-8 a	10-5 a
925S137-43	33	22-8	19-7 e	16-0 e	22-8 i	19-7 i	16-0 a	21-3	19-4 e	16-0 e	22-8 i	19-7 i	16-0 a
925S162-43	33	24-0 e	20-10 e	17-0 e	24-0 i	20-10 i	17-0 a	22-1	20-0 e	17-0 e	24-0 i	20-10 i	17-0 a
925S200-43	33	23-8 e	20-6 e	16-9 e	23-8 i	20-6 i	16-9 a	22-10	20-6 e	16-9 e	23-8 i	20-6 i	16-9 a
925S250-43	33	25-7 e	22-1 e	18-1 e	25-7 i	22-1 i	18-1 a	24-0 e	21-9 e	18-1 e	25-7 i	22-1 i	18-1 a
925S300-43	33	27-0 e	23-5 e	19-1 e	27-0 i	23-5 i	19-1 a	24-11 e	22-8 e	19-1 e	27-0 i	23-5 a	19-1 a
925S137-54	33	25-2	22-10	18-7	26-4	22-10 i	18-7 i	22-10	20-9	18-2	25-8	22-10 i	18-7 i
925S137-54	50	25-2	22-10	20-0	28-3	25-8	21-9 i	22-10	20-9	18-2	25-8	23-4	20-4 i
925S162-54	33	26-1	23-9	19-8	27-10 i	24-1 i	19-8 i	23-9	21-7	18-10	26-8	24-1 i	19-8 i
925S162-54	50	26-1	23-9	20-9	29-4	26-8	23-0 i	23-9	21-7	18-10	26-8	24-2	21-2 i
925S200-54	33	27-0	24-7	20-5 e	28-10 i	25-0 i	20-5 i	24-7	22-4	19-6	27-7 i	25-0 i	20-5 i
925S200-54	50	27-0	24-7	21-5	30-4	27-7 i	22-7 i	24-7	22-4	19-6	27-7 i	25-1	21-10 i
925S250-54	33	28-5	25-9	21-5 e	30-3 i	26-2 i	21-5 i	25-9	23-5	20-5 e	28-11 i	26-2 i	21-5 i
925S250-54	50	28-4	25-9	22-6	31-10	28-11 i	24-1 i	25-9	23-4	20-5	28-11 i	26-3	22-11 i
925S300-54	33	29-7	26-11	22-7 e	31-11 i	27-8 i	22-7 i	26-11	24-5	21-4 e	30-2 i	27-5 i	22-7 i
925S300-54	50	29-4	26-8	23-4	33-0	30-0 i	25-3 i	26-8	24-3	21-2	30-0	27-3 i	23-9 i
925S137-68	33	27-1	24-7	20-9	29-5	25-5	20-9	24-7	22-4	19-6	27-7	25-1	20-9
925S137-68	50	27-1	24-7	21-6	30-5	27-7	24-1	24-7	22-4	19-6	27-7	25-1	21-11
925S162-68	33	28-1	25-6	21-11	31-1	26-11	21-11 i	25-6	23-2	20-3	28-8	26-0	21-11 i
925S162-68	50	28-1	25-6	22-3	31-6	28-8	25-0	25-6	23-2	20-3	28-8	26-0	22-9
925S200-68	33	29-1	26-5	23-1	32-8	28-3	23-1 i	26-5	24-0	21-0	29-8	26-11	23-1 i
925S200-68	50	29-1	26-5	23-1	32-8	29-8	25-11	26-5	24-0	21-0	29-8	26-11	23-6
925S250-68	33	30-7	27-9	24-3	34-4	30-0	24-6 i	27-9	25-3	22-0	31-2	28-4	24-6 i
925S250-68	50	30-7	27-9	24-3	34-4	31-2	27-3	27-9	25-3	22-0	31-2	28-4	24-9
925S300-68	33	31-11	29-0	25-4	35-10	31-0	25-4 i	29-0	26-4	23-0	32-6	29-7	25-4 i
925S300-68	50	31-9	28-10	25-2	35-8	32-5	28-3	28-10	26-2	22-11	32-5	29-5	25-8
925S162-97	33	31-4	28-6	24-11	35-3	31-9	25-11	28-6	25-11	22-7	32-0	29-1	25-5
925S162-97	50	31-4	28-6	24-11	35-3	32-0	27-11	28-6	25-11	22-7	32-0	29-1	25-5
925S200-97	33	32-6	29-6	25-9	36-6	33-2	27-4	29-6	26-10	23-5	33-2	30-1	26-4
925S200-97	50	32-6	29-6	25-9	36-6	33-2	28-11	29-6	26-10	23-5	33-2	30-1	26-4
925S250-97	33	34-2	31-0	27-1	38-4	34-10	29-5	31-0	28-2	24-7	34-10	31-8	27-8
925S250-97	50	34-2	31-0	27-1	38-4	34-10	30-5	31-0	28-2	24-7	34-10	31-8	27-8
925S300-97	33	35-8	32-5	28-4	40-1	36-5	31-3	32-5	29-5	25-8	36-5	33-1	28-10
925S300-97	50	35-8	32-5	28-4	40-1	36-5	31-9	32-5	29-5	25-8	36-5	33-1	28-10

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 20 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1000S137-33	33	18-11 e	16-5 e	12-1 e	18-11 a	14-6 a	9-8 a	18-11 e	16-5 e	12-1 e	18-11 a	14-6 a	9-8 a
1000S162-33	33	20-2 e	17-5 e	12-1 e	19-4 a	14-6 a	9-8 a	20-2 e	17-5 e	12-1 e	19-4 a	14-6 a	9-8 a
1000S200-33	33	20-5 e	17-8 e	12-1 e	19-4 a	14-6 a	9-8 a	20-5 e	17-8 e	12-1 e	19-4 a	14-6 a	9-8 a
1000S137-43	33	23-5 e	20-3 e	16-7 e	23-5 i	20-3 i	16-7 a	22-9 e	20-3 e	16-7 e	23-5 i	20-3 i	16-7 a
1000S162-43	33	24-10 e	21-6 e	17-7 e	24-10 i	21-6 i	17-7 a	23-6 e	21-4 e	17-7 e	24-10 i	21-6 i	17-7 a
1000S200-43	33	24-7 e	21-3 e	17-4 e	24-7 i	21-3 i	17-4 a	24-4 e	21-3 e	17-4 e	24-7 i	21-3 i	17-4 a
1000S250-43	33	26-6 e	22-11 e	18-9 e	26-6 i	22-11 a	18-9 a	25-6 e	22-11 e	18-9 e	26-6 i	22-11 a	18-9 a
1000S300-43	33	28-0 e	24-3 e	19-10 e	28-0 i	24-3 a	19-10 a	26-6 e	24-1 e	19-10 e	28-0 i	24-3 a	19-10 a
1000S137-54	33	26-11	24-3	19-9 e	28-0 i	24-3 i	19-9 i	24-5	22-2	19-5 e	27-5 i	24-3 i	19-9 i
1000S137-54	50	26-11	24-5	21-4	30-2	27-5 i	22-6 i	24-5	22-2	19-5	27-5	24-11	21-9 i
1000S162-54	33	27-10	25-4	20-10 e	29-6 i	25-6 i	20-10 i	25-4	23-0	20-1 e	28-5 i	25-6 i	20-10 i
1000S162-54	50	27-10	25-4	22-1	31-3	28-5 i	23-10 i	25-4	23-0	20-1	28-5	25-10	22-6 i
1000S200-54	33	28-10	26-2	21-7 e	30-6 i	26-5 i	21-7 i	26-2	23-9	20-9 e	29-5 i	26-5 i	21-7 i
1000S200-54	50	28-10	26-2	22-10	32-4	28-8 i	23-5 i	26-2	23-9	20-9	29-5	26-8 i	23-4 i
1000S250-54	33	30-2	27-4	22-4 e	31-7 i	27-4 i	22-4 i	27-5	24-11	21-9 e	30-10 i	27-4 i	22-4 i
1000S250-54	50	30-2	27-5	23-11	33-11	30-7 i	25-0 i	27-5	24-11	21-9	30-9	28-0 i	24-5 i
1000S300-54	33	31-6	28-7 e	23-5 e	33-2 i	28-9 i	23-5 i	28-7	26-0	22-8 e	32-1 i	28-9 i	23-5 i
1000S300-54	50	31-3	28-5	24-10 e	35-1 i	31-11 i	26-2 i	28-5	25-10	22-6	31-11	29-0 i	25-4 i
1000S137-68	33	28-11	26-3	22-1	31-2	27-0	22-1 i	26-3	23-10	20-10	29-6	26-10	22-1 i
1000S137-68	50	28-11	26-3	22-11	32-6	29-6	25-9	26-3	23-10	20-10	29-6	26-10	23-5
1000S162-68	33	30-0	27-3	23-3	32-11	28-6	23-3 i	27-3	24-9	21-7	30-7	27-9	23-3 i
1000S162-68	50	30-0	27-3	23-9	33-8	30-7	26-8	27-3	24-9	21-7	30-7	27-9	24-3
1000S200-68	33	31-0	28-2	24-5	34-7	29-11	24-5 i	28-2	25-7	22-4	31-7	28-9	24-5 i
1000S200-68	50	31-0	28-2	24-7	34-10	31-7	27-7	28-2	25-7	22-4	31-7	28-9	25-1
1000S250-68	33	32-6	29-6	25-10	36-6	31-9 i	25-11 i	29-6	26-10	23-5	33-2	30-2	25-11 i
1000S250-68	50	32-6	29-6	25-10	36-6	33-2	29-0 i	29-6	26-10	23-5	33-2	30-2	26-4
1000S300-68	33	33-11	30-9	26-9	37-10	32-9 i	26-9 i	30-9	28-0	24-5	34-7	31-5	26-9 i
1000S300-68	50	33-9	30-8	26-10	37-11	34-6	30-1 i	30-8	27-11	24-4	34-6	31-4	27-4
1000S162-97	33	33-6	30-5	26-7	37-7	33-8	27-6	30-5	27-7	24-2	34-2	31-0	27-1
1000S162-97	50	33-6	30-5	26-7	37-7	34-2	29-10	30-5	27-7	24-2	34-2	31-0	27-1
1000S200-97	33	34-8	31-6	27-6	38-11	35-4	28-11	31-6	28-7	25-0	35-4	32-1	28-0
1000S200-97	50	34-8	31-6	27-6	38-11	35-4	30-10	31-6	28-7	25-0	35-4	32-1	28-0
1000S250-97	33	36-4	33-0	28-10	40-10	37-1	31-1	33-0	30-0	26-3	37-1	33-8	29-5
1000S250-97	50	36-4	33-0	28-10	40-10	37-1	32-5	33-0	30-0	26-3	37-1	33-8	29-5
1000S300-97	33	37-11	34-5	30-1	42-7	38-8	32-11	34-5	31-4	27-4	38-8	35-2	30-8
1000S300-97	50	37-11	34-5	30-1	42-7	38-8	33-10	34-5	31-4	27-4	38-8	35-2	30-8

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 20 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1125S137-33	33	20-0 e	16-0 e	10-8 e	17-1 a	12-10 a	8-6 a	20-0 e	16-0 e	10-8 e	17-1 a	12-10 a	8-6 a
1125S162-33	33	21-4 e	16-0 e	10-8 e	17-1 a	12-10 a	8-6 a	21-4 e	16-0 e	10-8 e	17-1 a	12-10 a	8-6 a
1125S200-33	33	21-5 e	16-0 e	10-8 e	17-1 a	12-10 a	8-6 a	21-5 e	16-0 e	10-8 e	17-1 a	12-10 a	8-6 a
1125S137-43	33	24-8 e	21-4 e	17-5 e	24-8 i	21-4 a	17-5 a	24-8 e	21-4 e	17-5 e	24-8 i	21-4 a	17-5 a
1125S162-43	33	26-3 e	22-9 e	18-7 e	26-3 i	22-9 a	18-7 a	25-11 e	22-9 e	18-7 e	26-3 i	22-9 a	18-7 a
1125S200-43	33	25-11 e	22-6 e	18-4 e	25-11 i	22-6 a	18-4 a	25-11 e	22-6 e	18-4 e	25-11 i	22-6 a	18-4 a
1125S250-43	33	28-0 e	24-3 e	19-10 e	28-0 a	24-3 a	19-0 a	28-0 e	24-3 e	19-10 e	28-0 a	24-3 a	19-0 a
1125S300-43	33	29-8 e	25-8 e	21-0 e	29-8 a	25-8 a	19-0 a	29-2 e	25-8 e	21-0 e	29-8 a	25-8 a	19-0 a
1125S137-54	33	29-5	25-6	20-10 e	29-5 i	25-6 i	20-10 i	27-0	24-6	20-10 e	29-5 i	25-6 i	20-10 i
1125S137-54	50	29-9	27-0	23-7 e	33-5	29-1 i	23-8 i	27-0	24-6	21-5	30-4	27-7 i	23-8 i
1125S162-54	33	30-9	26-11 e	22-0 e	31-1 i	26-11 i	22-0 i	27-11	25-4	22-0 e	31-1 i	26-11 i	22-0 i
1125S162-54	50	30-9	27-11	24-5 e	34-6 i	30-10 i	25-2 i	27-11	25-4	22-2	31-4	28-6 i	24-10 i
1125S200-54	33	31-9	27-9 e	22-8 e	32-0 i	27-9 i	22-8 i	28-10	26-2	22-8 e	32-0 i	27-9 i	22-8 i
1125S200-54	50	31-9	28-10	24-9 e	35-0 i	30-4 i	24-9 i	28-10	26-2	22-10 e	32-4	29-5 i	24-9 i
1125S250-54	33	33-2	28-10 e	23-6 e	33-3 i	28-10 i	23-6 i	30-2	27-5 e	23-6 e	33-3 i	28-10 i	23-6 i
1125S250-54	50	33-2	30-2	26-4 e	37-3 i	32-4 i	26-5 i	30-2	27-5	23-11 e	33-10 i	30-9 i	26-5 i
1125S300-54	33	34-6	30-4 e	24-9 e	35-0 i	30-4 i	24-9 a	31-5	28-6 e	24-9 e	35-0 i	30-4 i	24-9 a
1125S300-54	50	34-4	31-2	27-3 e	38-7 i	34-0 i	27-9 i	31-2	28-4	24-9 e	35-0 i	31-10 i	27-9 i
1125S137-68	33	32-0	29-1	24-2	34-3	29-7	24-2 i	29-1	26-5	23-1	32-8	29-7	24-2 i
1125S137-68	50	32-0	29-1	25-5	35-11	32-8	28-6 i	29-1	26-5	23-1	32-8	29-8	25-11
1125S162-68	33	33-1	30-1	25-5	36-0	31-2 i	25-5 i	30-1	27-4	23-10	33-9	30-8	25-5 i
1125S162-68	50	33-1	30-1	26-3	37-2	33-9	29-6 i	30-1	27-4	23-10	33-9	30-8	26-9
1125S200-68	33	34-2	31-0	26-8	37-8	32-8 i	26-8 i	31-0	28-2	24-7	34-10	31-8 i	26-8 i
1125S200-68	50	34-2	31-0	27-1	38-4	34-10	30-5 i	31-0	28-2	24-7	34-10	31-8	27-8 i
1125S250-68	33	35-9	32-6	28-2	39-10	34-6 i	28-2 i	32-6	29-6	25-9	36-6	33-2 i	28-2 i
1125S250-68	50	35-9	32-6	28-4	40-2	36-6	31-4 i	32-6	29-6	25-9	36-6	33-2	28-11 i
1125S300-68	33	37-2	33-10	29-1	41-1 i	35-7 i	29-1 i	33-10	30-8	26-10	37-11	34-6 i	29-1 i
1125S300-68	50	37-2	33-9	29-6	41-9	37-11	33-1 i	33-9	30-8	26-9	37-11	34-5	30-1 i
1125S162-97	33	37-0	33-7	29-4	41-6	36-10	30-1	33-7	30-6	26-8	37-9	34-3	29-11
1125S162-97	50	37-0	33-7	29-4	41-6	37-9	32-11	33-7	30-6	26-8	37-9	34-3	29-11
1125S200-97	33	38-2	34-8	30-4	42-11	38-8	31-7	34-8	31-6	27-6	38-11	35-5	30-11
1125S200-97	50	38-2	34-8	30-4	42-11	38-11	34-0	34-8	31-6	27-6	38-11	35-5	30-11
1125S250-97	33	40-0	36-4	31-9	44-11	40-10	33-10	36-4	33-0	28-10	40-10	37-1	32-5
1125S250-97	50	40-0	36-4	31-9	44-11	40-10	35-8	36-4	33-0	28-10	40-10	37-1	32-5
1125S300-97	33	41-8	37-10	33-1	46-9	42-6	35-9	37-10	34-4	30-0	42-6	38-7	33-9
1125S300-97	50	41-8	37-10	33-1	46-9	42-6	37-1	37-10	34-4	30-0	42-6	38-7	33-9

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 20 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1200S137-33	33	20-0 e	15-0 e	10-0 e	16-0 a	12-0 a	8-0 a	20-0 e	15-0 e	10-0 e	16-0 a	12-0 a	8-0 a
1200S162-33	33	20-0 e	15-0 e	10-0 e	16-0 a	12-0 a	8-0 a	20-0 e	15-0 e	10-0 e	16-0 a	12-0 a	8-0 a
1200S200-33	33	20-0 e	15-0 e	10-0 e	16-0 a	12-0 a	8-0 a	20-0 e	15-0 e	10-0 e	16-0 a	12-0 a	8-0 a
1200S137-43	33	25-5 e	22-0 e	18-0 e	25-5 a	22-0 a	17-9 a	25-5 e	22-0 e	18-0 e	25-5 a	22-0 a	17-9 a
1200S162-43	33	27-1 e	23-5 e	19-1 e	27-1 a	23-5 a	17-9 a	27-1 e	23-5 e	19-1 e	27-1 a	23-5 a	17-9 a
1200S200-43	33	26-9 e	23-2 e	18-11 e	26-9 a	23-2 a	17-9 a	26-9 e	23-2 e	18-11 e	26-9 a	23-2 a	17-9 a
1200S250-43	33	28-11 e	25-0 e	20-5 e	28-11 a	25-0 a	17-9 a	28-11 e	25-0 e	20-5 e	28-11 a	25-0 a	17-9 a
1200S300-43	33	30-8 e	26-6 e	21-8 e	30-8 a	26-6 a	17-9 a	30-8 e	26-6 e	21-8 e	30-8 a	26-6 a	17-9 a
1200S137-54	33	30-3	26-2 e	21-5 e	30-3 i	26-2 i	21-5 i	28-7	25-11 e	21-5 e	30-3 i	26-2 i	21-5 i
1200S137-54	50	31-5	28-7	24-5 e	34-7 i	29-11 i	24-5 i	28-7	25-11	22-8 e	32-1	29-1 i	24-5 i
1200S162-54	33	32-0	27-8 e	22-7 e	32-0 i	27-8 i	22-7 i	29-6	26-9 e	22-7 e	32-0 i	27-8 i	22-7 i
1200S162-54	50	32-5	29-6	25-9 e	36-5 i	31-9 i	25-11 i	29-6	26-9	23-5 e	33-1 i	30-1 i	25-11 i
1200S200-54	33	32-11	28-6 e	23-3 e	32-11 i	28-6 i	23-3 a	30-5	27-7 e	23-3 e	32-11 i	28-6 i	23-3 a
1200S200-54	50	33-6	30-5	25-6 e	36-1 i	31-3 i	25-6 i	30-5	27-7	24-1 e	34-2 i	31-0 i	25-6 i
1200S250-54	33	34-3	29-8 e	24-2 e	34-3 i	29-8 i	24-2 a	31-9	28-10 e	24-2 e	34-3 i	29-8 i	24-2 a
1200S250-54	50	35-0	31-9	27-3 e	38-7 i	33-5 i	27-3 i	31-9	28-10	25-3 e	35-8 i	32-5 i	27-3 i
1200S300-54	33	36-1 e	31-3 e	25-6 e	36-1 i	31-3 i	25-6 a	33-0	30-0 e	25-6 e	36-1 i	31-3 i	25-6 a
1200S300-54	50	36-3	32-11 e	28-8 e	40-6 i	35-1 i	28-8 i	32-11	29-11	26-2 e	37-0 i	33-7 i	28-8 i
1200S137-68	33	33-10	30-9	25-5	36-0	31-2 i	25-5 i	30-9	27-11	24-4	34-6	31-2 i	25-5 i
1200S137-68	50	33-10	30-9	26-10	38-0	34-6	29-8 i	30-9	27-11	24-4	34-6	31-4	27-4 i
1200S162-68	33	34-11	31-9	26-9	37-10	32-9 i	26-9 i	31-9	28-10	25-2	35-8	32-4 i	26-9 i
1200S162-68	50	34-11	31-9	27-9	39-3	35-8	31-1 i	31-9	28-10	25-2	35-8	32-4	28-3 i
1200S200-68	33	36-0	32-9	27-11	39-7	34-3 i	27-11 i	32-9	29-9	26-0	36-9	33-5 i	27-11 i
1200S200-68	50	36-0	32-9	28-7	40-5	36-9	31-10 i	32-9	29-9	26-0	36-9	33-5	29-2 i
1200S250-68	33	37-8	34-3	29-6	41-9 i	36-2 i	29-6 i	34-3	31-1	27-2	38-5	34-11 i	29-6 i
1200S250-68	50	37-8	34-3	29-11	42-4	38-5	32-3 i	34-3	31-1	27-2	38-5	34-11	30-6 i
1200S300-68	33	39-2	35-7	30-4 e	42-11 i	37-2 i	30-4 i	35-7	32-4	28-3	39-11	36-4 i	30-4 i
1200S300-68	50	39-2	35-7	31-1	44-0	39-11	34-1 i	35-7	32-4	28-3	39-11	36-4	31-8 i
1200S162-97	33	39-1	35-6	31-0	43-10	38-8	31-7	35-6	32-3	28-2	39-10	36-2	31-7
1200S162-97	50	39-1	35-6	31-0	43-10	39-10	34-10	35-6	32-3	28-2	39-10	36-2	31-7
1200S200-97	33	40-4	36-7	32-0	45-3	40-7	33-1	36-7	33-3	29-1	41-1	37-4	32-7
1200S200-97	50	40-4	36-7	32-0	45-3	41-1	35-11	36-7	33-3	29-1	41-1	37-4	32-7
1200S250-97	33	42-2	38-4	33-5	47-4	43-0	35-5	38-4	34-10	30-5	43-0	39-1	34-1
1200S250-97	50	42-2	38-4	33-5	47-4	43-0	37-7	38-4	34-10	30-5	43-0	39-1	34-1
1200S300-97	33	43-10	39-10	34-10	49-3	44-9	37-5	39-10	36-2	31-7	44-9	40-8	35-6
1200S300-97	50	43-10	39-10	34-10	49-3	44-9	39-1	39-10	36-2	31-7	44-9	40-8	35-6

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 20 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1400S137-33	33	17-1 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a	17-1 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a
1400S162-33	33	17-1 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a	17-1 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a
1400S200-33	33	17-1 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a	17-1 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a
1400S137-43	33	27-4 e	23-8 e	19-0 e	27-4 a	22-9 a	15-2 a	27-4 e	23-8 e	19-0 e	27-4 a	22-9 a	15-2 a
1400S162-43	33	29-1 e	25-2 e	19-0 e	29-1 a	22-9 a	15-2 a	29-1 e	25-2 e	19-0 e	29-1 a	22-9 a	15-2 a
1400S200-43	33	28-10 e	25-0 e	19-0 e	28-10 a	22-9 a	15-2 a	28-10 e	25-0 e	19-0 e	28-10 a	22-9 a	15-2 a
1400S250-43	33	31-2 e	27-0 e	19-0 e	30-5 a	22-9 a	15-2 a	31-2 e	27-0 e	19-0 e	30-5 a	22-9 a	15-2 a
1400S300-43	33	33-1 e	28-6 e	19-0 e	30-5 a	22-9 a	15-2 a	33-1 e	28-6 e	19-0 e	30-5 a	22-9 a	15-2 a
1400S137-54	33	32-4 e	28-0 e	22-10 e	32-4 i	28-0 i	22-10 a	32-4 e	28-0 e	22-10 e	32-4 i	28-0 i	22-10 a
1400S137-54	50	35-0	31-10 e	26-3 e	37-2 i	32-2 i	26-3 a	31-10	28-11	25-3 e	35-8 i	32-2 i	26-3 a
1400S162-54	33	34-3 e	29-8 e	24-2 e	34-3 i	29-8 i	24-2 a	33-7 e	29-8 e	24-2 e	34-3 i	29-8 i	24-2 a
1400S162-54	50	36-1	32-10 e	27-11 e	39-5 i	34-2 i	27-11 a	32-10	29-10 e	26-0 e	36-10 i	33-6 i	27-11 a
1400S200-54	33	35-4 e	30-7 e	25-0 e	35-4 i	30-7 i	25-0 a	34-7 e	30-7 e	25-0 e	35-4 i	30-7 i	25-0 a
1400S200-54	50	37-8	33-8 e	27-6 e	38-11 i	33-8 i	27-6 a	34-2	31-1 e	27-2 e	38-5 i	33-8 i	27-6 a
1400S250-54	33	36-9 e	31-10 e	26-0 e	36-9 i	31-10 a	26-0 a	36-0 e	31-10 e	26-0 e	36-9 i	31-10 a	26-0 a
1400S250-54	50	39-4 e	35-8 e	29-5 e	41-7 i	36-0 i	29-5 a	35-8	32-5 e	28-4 e	40-1 i	36-0 i	29-5 a
1400S300-54	33	38-10 e	33-7 e	27-5 e	38-10 i	33-7 a	27-5 a	37-5 e	33-7 e	27-5 e	38-10 i	33-7 a	27-5 a
1400S300-54	50	40-10 e	37-1 e	30-11 e	43-8 i	37-10 i	30-1 a	37-1	33-8 e	29-5 e	41-8 i	37-10 i	30-1 a
1400S137-68	33	38-8	33-10	27-7	39-1 i	33-10 i	27-7 i	35-1	31-11	27-7	39-1 i	33-10 i	27-7 i
1400S137-68	50	38-8	35-1	30-8	43-5	38-10 i	31-8 i	35-1	31-11	27-10	39-5	35-10	31-4 i
1400S162-68	33	39-10	35-6	29-0 e	41-0 i	35-6 i	29-0 i	36-2	32-11	28-9 e	40-8 i	35-6 i	29-0 i
1400S162-68	50	39-10	36-2	31-7	44-9	40-8 i	33-6 i	36-2	32-11	28-9	40-8	36-11	32-3 i
1400S200-68	33	41-0	37-2	30-4 e	42-11 i	37-2 i	30-4 i	37-3	33-10	29-7 e	41-10 i	37-2 i	30-4 i
1400S200-68	50	41-0	37-3	32-6	46-0	41-10 i	34-2 i	37-3	33-10	29-7	41-10	38-0	33-2 i
1400S250-68	33	42-9	38-10	31-10 e	45-0 i	39-0 i	31-10 i	38-10	35-3	30-10 e	43-7 i	39-0 i	31-10 i
1400S250-68	50	42-9	38-10	33-11	48-0	42-5 i	34-8 i	38-10	35-3	30-10	43-7	39-7 i	34-7 i
1400S300-68	33	44-4	39-9	32-6 e	45-11 i	39-9 i	32-6 i	40-3	36-7	32-0 e	45-3 i	39-9 i	32-6 i
1400S300-68	50	44-4	40-3	35-2 e	49-9	44-11 i	36-8 i	40-3	36-7	32-0	45-3	41-1 i	35-11 i
1400S162-97	33	44-7	40-6	35-4	50-0	43-8	35-8	40-6	36-9	32-2	45-6	41-4	35-8
1400S162-97	50	44-7	40-6	35-4	50-0	45-6	39-9	40-6	36-9	32-2	45-6	41-4	36-1
1400S200-97	33	45-11	41-8	36-5	51-6	45-7	37-3	41-8	37-10	33-1	46-10	42-6	37-2
1400S200-97	50	45-11	41-8	36-5	51-6	46-10	40-11	41-8	37-10	33-1	46-10	42-6	37-2
1400S250-97	33	47-10	43-6	38-0	53-9	48-7	39-8	43-6	39-6	34-6	48-10	44-4	38-9
1400S250-97	50	47-10	43-6	38-0	53-9	48-10	42-8	43-6	39-6	34-6	48-10	44-4	38-9
1400S300-97	33	49-8	45-1	39-5	55-9	50-8	41-9 i	45-1	41-0	35-10	50-8	46-0	40-2
1400S300-97	50	49-8	45-1	39-5	55-9	50-8	44-3	45-1	41-0	35-10	50-8	46-0	40-2

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 30 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
600S137-33	33	12-11 e	11-2 e	9-1 e	12-11 i	11-2 a	9-1 a	11-11 e	10-10 e	9-1 e	12-11 i	11-2 a	9-1 a
600S162-33	33	13-8 e	11-10 e	9-8 e	13-8 i	11-10 a	9-8 a	12-5 e	11-4 e	9-8 e	13-8 i	11-10 a	9-8 a
600S200-33	33	13-10 e	12-0 e	9-9 e	13-10 i	12-0 a	9-9 a	13-0 e	11-9 e	9-9 e	13-10 i	12-0 a	9-9 a
600S137-43	33	14-4	12-10	10-6 e	14-10 i	12-10 i	10-6 i	13-0	11-10	10-4	14-7	12-10 i	10-6 i
600S162-43	33	14-11	13-7	11-2 e	15-10 i	13-9 i	11-2 i	13-7	12-4	10-9 e	15-3 i	13-9 i	11-2 i
600S200-43	33	15-7	13-10	11-3 e	15-11 i	13-10 i	11-3 i	14-1	12-10	11-2 e	15-10 i	13-10 i	11-3 i
600S250-43	33	16-5	14-11	12-2 e	17-3 i	14-11 i	12-2 i	14-11	13-7	11-10 e	16-9 i	14-11 i	12-2 i
600S300-43	33	17-1	15-7 e	12-11 e	18-3 i	15-10 i	12-11 i	15-7	14-1	12-4 e	17-6 i	15-10 i	12-11 i
600S137-54	33	15-4	13-11	11-8	16-7	14-4	11-8 i	13-11	12-8	11-1	15-8	14-3	11-8 i
600S137-54	50	15-4	13-11	12-2	17-3	15-8	13-8	13-11	12-8	11-1	15-8	14-3	12-5
600S162-54	33	16-0	14-7	12-6	17-8	15-3	12-6 i	14-7	13-3	11-7	16-4	14-10	12-6 i
600S162-54	50	16-0	14-7	12-9	18-0	16-4	14-3	14-7	13-3	11-7	16-4	14-10	13-0
600S200-54	33	16-9	15-2	13-1	18-6	16-0	13-1 i	15-2	13-9	12-0	17-1	15-6	13-1 i
600S200-54	50	16-9	15-2	13-3	18-9	17-1	14-11 i	15-2	13-9	12-0	17-1	15-6	13-6
600S250-54	33	17-8	16-1	13-9	19-6	16-10 i	13-9 i	16-1	14-7	12-9	18-0	16-4	13-9 i
600S250-54	50	17-7	16-0	13-11	19-9	17-11	15-8 i	16-0	14-6	12-8	17-11	16-3	14-3
600S300-54	33	18-6	16-10	14-7	20-8	17-11 i	14-7 i	16-10	15-3	13-4	18-11	17-2 i	14-7 i
600S300-54	50	18-3	16-7	14-6	20-6	18-8	16-3 i	16-7	15-1	13-2	18-8	16-11	14-9 i
600S137-68	33	16-6	15-0	13-0	18-5	15-11	13-0	15-0	13-7	11-11	16-10	15-4	13-0
600S137-68	50	16-6	15-0	13-1	18-6	16-10	14-8	15-0	13-7	11-11	16-10	15-4	13-4
600S162-68	33	17-3	15-8	13-8	19-4	17-0	13-11	15-8	14-3	12-5	17-7	16-0	13-11
600S162-68	50	17-3	15-8	13-8	19-4	17-7	15-4	15-8	14-3	12-5	17-7	16-0	13-11
600S200-68	33	18-0	16-4	14-3	20-2	18-1	14-9	16-4	14-10	12-11	18-4	16-8	14-6
600S200-68	50	18-0	16-4	14-3	20-2	18-4	16-0	16-4	14-10	12-11	18-4	16-8	14-6
600S250-68	33	19-0	17-3	15-1	21-4	19-5	15-10	17-3	15-8	13-8	19-5	17-7	15-5
600S250-68	50	19-0	17-3	15-1	21-4	19-5	16-11	17-3	15-8	13-8	19-5	17-7	15-5
600S300-68	33	19-11	18-1	15-10	22-5	20-1	16-5	18-1	16-5	14-4	20-4	18-6	16-1
600S300-68	50	19-10	18-0	15-9	22-4	20-3	17-8	18-0	16-5	14-4	20-3	18-5	16-1
600S162-97	33	19-2	17-5	15-3	21-7	19-7	16-4	17-5	15-10	13-10	19-7	17-10	15-6
600S162-97	50	19-2	17-5	15-3	21-7	19-7	17-1	17-5	15-10	13-10	19-7	17-10	15-6
600S200-97	33	20-0	18-2	15-11	22-6	20-5	17-5	18-2	16-6	14-5	20-5	18-7	16-3
600S200-97	50	20-0	18-2	15-11	22-6	20-5	17-10	18-2	16-6	14-5	20-5	18-7	16-3
600S250-97	33	21-3	19-3	16-10	23-10	21-8	18-11	19-3	17-6	15-3	21-8	19-8	17-2
600S250-97	50	21-3	19-3	16-10	23-10	21-8	18-11	19-3	17-6	15-3	21-8	19-8	17-2
600S300-97	33	22-3	20-3	17-8	25-0	22-8	19-10	20-3	18-4	16-0	22-8	20-7	18-0
600S300-97	50	22-3	20-3	17-8	25-0	22-8	19-10	20-3	18-4	16-0	22-8	20-7	18-0

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 30 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
800S137-33	33	14-9 e	12-9 e	10-5 e	14-9 a	12-9 a	9-1 a	14-9 e	12-9 e	10-5 e	14-9 a	12-9 a	9-1 a
800S162-33	33	15-8 e	13-7 e	11-1 e	15-8 a	13-7 a	9-1 a	15-8 e	13-7 e	11-1 e	15-8 a	13-7 a	9-1 a
800S200-33	33	15-10 e	13-9 e	11-2 e	15-10 a	13-8 a	9-1 a	15-10 e	13-9 e	11-2 e	15-10 a	13-8 a	9-1 a
800S137-43	33	18-1	15-11 e	13-0 e	18-4 i	15-11 i	13-0 a	16-5	14-11 e	13-0 e	18-4 i	15-11 i	13-0 a
800S162-43	33	18-10 e	16-10 e	13-9 e	19-5 i	16-10 i	13-9 a	17-1	15-6 e	13-7 e	19-2 i	16-10 i	13-9 a
800S200-43	33	19-3 e	16-8 e	13-7 e	19-3 i	16-8 i	13-7 a	17-9	16-1 e	13-7 e	19-3 i	16-8 i	13-7 a
800S250-43	33	20-7 e	17-11 e	14-7 e	20-8 i	17-11 i	14-7 a	18-8 e	16-11 e	14-7 e	20-8 i	17-11 i	14-7 a
800S300-43	33	21-4 e	18-11 e	15-5 e	21-10 i	18-11 a	15-5 a	19-5 e	17-8 e	15-5 e	21-10 i	18-11 a	15-5 a
800S137-54	33	19-6	17-8	14-5	20-5	17-8 i	14-5 i	17-8	16-1	14-0	19-10	17-8 i	14-5 i
800S137-54	50	19-6	17-8	15-5	21-10	19-10	17-4 i	17-8	16-1	14-0	19-10	18-0	15-9 i
800S162-54	33	20-3	18-5	15-4	21-8 i	18-9 i	15-4 i	18-5	16-8	14-7	20-8	18-9 i	15-4 i
800S162-54	50	20-3	18-5	16-1	22-9	20-8	18-0 i	18-5	16-8	14-7	20-8	18-9	16-4 i
800S200-54	33	21-0	19-1	15-11 e	22-6 i	19-6 i	15-11 i	19-1	17-4	15-2	21-5 i	19-5 i	15-11 i
800S200-54	50	21-0	19-1	16-8	23-7	21-5 i	18-4 i	19-1	17-4	15-2	21-5	19-5	17-0 i
800S250-54	33	22-1	20-1	16-9 e	23-8 i	20-6 i	16-9 i	20-1	18-3	15-11 e	22-7 i	20-6 i	16-9 i
800S250-54	50	22-0	20-0	17-6	24-9	22-5 i	19-6 i	20-0	18-2	15-10	22-5	20-5	17-10 i
800S300-54	33	23-1	21-0	17-8 e	25-0 i	21-8 i	17-8 i	21-0	19-1	16-8 e	23-7 i	21-5 i	17-8 i
800S300-54	50	22-10	20-9	18-1	25-8	23-4 i	20-4 i	20-9	18-10	16-6	23-4	21-2 i	18-6 i
800S137-68	33	20-11	19-0	16-1	22-9	19-9	16-1	19-0	17-3	15-1	21-4	19-5	16-1
800S137-68	50	20-11	19-0	16-7	23-6	21-4	18-8	19-0	17-3	15-1	21-4	19-5	16-11
800S162-68	33	21-9	19-9	17-1	24-2	20-11	17-1 i	19-9	17-11	15-8	22-2	20-2	17-1 i
800S162-68	50	21-9	19-9	17-3	24-5	22-2	19-5	19-9	17-11	15-8	22-2	20-2	17-7
800S200-68	33	22-7	20-6	17-11	25-4	22-1	18-0 i	20-6	18-8	16-3	23-1	20-11	18-0 i
800S200-68	50	22-7	20-6	17-11	25-4	23-1	20-2	20-6	18-8	16-3	23-1	20-11	18-3
800S250-68	33	23-9	21-7	18-10	26-9	23-6	19-2 i	21-7	19-8	17-2	24-3	22-1	19-2 i
800S250-68	50	23-9	21-7	18-10	26-9	24-3	21-2	21-7	19-8	17-2	24-3	22-1	19-3
800S300-68	33	24-10	22-7	19-9	27-11	24-4	19-10 i	22-7	20-6	17-11	25-4	23-0	19-10 i
800S300-68	50	24-9	22-6	19-8	27-10	25-3	22-1	22-6	20-5	17-10	25-3	22-11	20-0
800S162-97	33	24-3	22-1	19-3	27-3	24-8	20-1	22-1	20-0	17-6	24-9	22-6	19-8
800S162-97	50	24-3	22-1	19-3	27-3	24-9	21-8	22-1	20-0	17-6	24-9	22-6	19-8
800S200-97	33	25-3	22-11	20-0	28-4	25-9	21-4	22-11	20-10	18-2	25-9	23-4	20-5
800S200-97	50	25-3	22-11	20-0	28-4	25-9	22-6	22-11	20-10	18-2	25-9	23-4	20-5
800S250-97	33	26-7	24-2	21-1	29-10	27-1	23-8	24-2	21-11	19-2	27-1	24-8	21-6
800S250-97	50	26-7	24-2	21-1	29-10	27-1	23-8	24-2	21-11	19-2	27-1	24-8	21-6
800S300-97	33	27-10	25-3	22-1	31-3	28-4	24-6	25-3	22-11	20-0	28-4	25-9	22-6
800S300-97	50	27-10	25-3	22-1	31-3	28-4	24-9	25-3	22-11	20-0	28-4	25-9	22-6

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 30 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
925S137-33	33	15-9 e	13-8 e	9-9 e	15-8 a	11-9 a	7-10 a	15-9 e	13-8 e	9-9 e	15-8 a	11-9 a	7-10 a
925S162-33	33	16-9 e	14-6 e	9-9 e	15-8 a	11-9 a	7-10 a	16-9 e	14-6 e	9-9 e	15-8 a	11-9 a	7-10 a
925S200-33	33	17-0 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a	17-0 e	14-8 e	9-9 e	15-8 a	11-9 a	7-10 a
925S137-43	33	19-7 e	17-0 e	13-10 e	19-7 i	17-0 i	13-10 a	18-7 e	16-10 e	13-10 e	19-7 i	17-0 i	13-10 a
925S162-43	33	20-10 e	18-0 e	14-8 e	20-10 i	18-0 a	14-8 a	19-3 e	17-6 e	14-8 e	20-10 i	18-0 a	14-8 a
925S200-43	33	20-6 e	17-9 e	14-6 e	20-6 i	17-9 a	14-6 a	19-11 e	17-9 e	14-6 e	20-6 i	17-9 a	14-6 a
925S250-43	33	22-1 e	19-2 e	15-8 e	22-1 i	19-2 a	15-8 a	20-11 e	19-0 e	15-8 e	22-1 i	19-2 a	15-8 a
925S300-43	33	23-5 e	20-3 e	16-6 e	23-5 a	20-3 a	16-6 a	21-9 e	19-9 e	16-6 e	23-5 a	20-3 a	16-6 a
925S137-54	33	22-0	19-9	16-1 e	22-10 i	19-9 i	16-1 i	20-0	18-2	15-10 e	22-5 i	19-9 i	16-1 i
925S137-54	50	22-0	20-0	17-5	24-8	22-5 i	18-10 i	20-0	18-2	15-10	22-5	20-4 i	17-9 i
925S162-54	33	22-10	20-9	17-0 e	24-1 i	20-10 i	17-0 i	20-9	18-10	16-5 e	23-3 i	20-10 i	17-0 i
925S162-54	50	22-10	20-9	18-1	25-7	23-3 i	19-11 i	20-9	18-10	16-5	23-3	21-2 i	18-5 i
925S200-54	33	23-7	21-5	17-8 e	25-0 i	21-8 i	17-8 i	21-5	19-6	17-0 e	24-1 i	21-8 i	17-8 i
925S200-54	50	23-7	21-5	18-9 e	26-6	23-11 i	19-7 i	21-5	19-6	17-0	24-1	21-10 i	19-1 i
925S250-54	33	24-9	22-6 e	18-6 e	26-2 i	22-8 i	18-6 i	22-6	20-5	17-10 e	25-3 i	22-8 i	18-6 i
925S250-54	50	24-9	22-6	19-7 e	27-9 i	25-3 i	20-10 i	22-6	20-5	17-10	25-3	22-11 i	20-0 i
925S300-54	33	25-10	23-6 e	19-6 e	27-8 i	23-11 i	19-6 i	23-6	21-4	18-8 e	26-5 i	23-11 i	19-6 i
925S300-54	50	25-8	23-4	20-4 e	28-10 i	26-2 i	21-10 i	23-4	21-2	18-6	26-2	23-9 i	20-9 i
925S137-68	33	23-8	21-6	18-0	25-5	22-0	18-0 i	21-6	19-6	17-0	24-1	21-11	18-0 i
925S137-68	50	23-8	21-6	18-9	26-7	24-1	21-1	21-6	19-6	17-0	24-1	21-11	19-2
925S162-68	33	24-6	22-3	19-0	26-11	23-3	19-0 i	22-3	20-3	17-8	25-0	22-9	19-0 i
925S162-68	50	24-6	22-3	19-6	27-7	25-0	21-10 i	22-3	20-3	17-8	25-0	22-9	19-10
925S200-68	33	25-5	23-1	20-0	28-3	24-6 i	20-0 i	23-1	21-0	18-4	25-11	23-6	20-0 i
925S200-68	50	25-5	23-1	20-2	28-6	25-11	22-8 i	23-1	21-0	18-4	25-11	23-6	20-7
925S250-68	33	26-8	24-3	21-2	30-0	26-0 i	21-3 i	24-3	22-0	19-3	27-3	24-9 i	21-3 i
925S250-68	50	26-8	24-3	21-2	30-0	27-3	23-9 i	24-3	22-0	19-3	27-3	24-9	21-7
925S300-68	33	27-10	25-4	21-11	31-0	26-10 i	21-11 i	25-4	23-0	20-1	28-5	25-10 i	21-11 i
925S300-68	50	27-9	25-2	22-0	31-2	28-3	24-8 i	25-2	22-11	20-0	28-3	25-8	22-5 i
925S162-97	33	27-5	24-11	21-9	30-9	27-6	22-5	24-11	22-7	19-9	27-11	25-5	22-2
925S162-97	50	27-5	24-11	21-9	30-9	27-11	24-5	24-11	22-7	19-9	27-11	25-5	22-2
925S200-97	33	28-5	25-9	22-6	31-10	28-11	23-8	25-9	23-5	20-5	28-11	26-4	23-0
925S200-97	50	28-5	25-9	22-6	31-10	28-11	25-3	25-9	23-5	20-5	28-11	26-4	23-0
925S250-97	33	29-10	27-1	23-8	33-6	30-5	25-6	27-1	24-7	21-6	30-5	27-8	24-2
925S250-97	50	29-10	27-1	23-8	33-6	30-5	26-7	27-1	24-7	21-6	30-5	27-8	24-2
925S300-97	33	31-2	28-4	24-9	35-0	31-9	27-0	28-4	25-8	22-5	31-9	28-10	25-3
925S300-97	50	31-2	28-4	24-9	35-0	31-9	27-9	28-4	25-8	22-5	31-9	28-10	25-3

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 30 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1000S137-33	33	16-5 e	13-7 e	9-0 e	14-6 a	10-10 a	7-3 a	16-5 e	13-7 e	9-0 e	14-6 a	10-10 a	7-3 a
1000S162-33	33	17-5 e	13-7 e	9-0 e	14-6 a	10-10 a	7-3 a	17-5 e	13-7 e	9-0 e	14-6 a	10-10 a	7-3 a
1000S200-33	33	17-8 e	13-7 e	9-0 e	14-6 a	10-10 a	7-3 a	17-8 e	13-7 e	9-0 e	14-6 a	10-10 a	7-3 a
1000S137-43	33	20-3 e	17-7 e	14-4 e	20-3 i	17-7 a	14-4 a	19-10 e	17-7 e	14-4 e	20-3 i	17-7 a	14-4 a
1000S162-43	33	21-6 e	18-8 e	15-3 e	21-6 i	18-8 a	15-3 a	20-6 e	18-8 e	15-3 e	21-6 i	18-8 a	15-3 a
1000S200-43	33	21-3 e	18-5 e	15-0 e	21-3 i	18-5 a	15-0 a	21-3 e	18-5 e	15-0 e	21-3 i	18-5 a	15-0 a
1000S250-43	33	22-11 e	19-10 e	16-3 e	22-11 a	19-10 a	16-1 a	22-3 e	19-10 e	16-3 e	22-11 a	19-10 a	16-1 a
1000S300-43	33	24-3 e	21-0 e	17-2 e	24-3 a	21-0 a	16-1 a	23-2 e	21-0 e	17-2 e	24-3 a	21-0 a	16-1 a
1000S137-54	33	23-6	21-0	17-1 e	24-3 i	21-0 i	17-1 i	21-4	19-5	16-11 e	23-11 i	21-0 i	17-1 i
1000S137-54	50	23-6	21-4	18-8 e	26-4 i	23-10 i	19-6 i	21-4	19-5	16-11	23-11	21-9 i	19-0 i
1000S162-54	33	24-4	22-1 e	18-0 e	25-6 i	22-1 i	18-0 i	22-1	20-1	17-6 e	24-10 i	22-1 i	18-0 i
1000S162-54	50	24-4	22-1	19-4 e	27-4 i	24-10 i	20-8 i	22-1	20-1	17-6	24-10	22-6 i	19-8 i
1000S200-54	33	25-2	22-10 e	18-8 e	26-5 i	22-10 i	18-8 i	22-10	20-9	18-2 e	25-8 i	22-10 i	18-8 i
1000S200-54	50	25-2	22-10	19-11 e	28-3 i	24-10 i	20-3 i	22-10	20-9	18-2 e	25-8	23-4 i	20-3 i
1000S250-54	33	26-5	23-8 e	19-4 e	27-4 i	23-8 i	19-4 a	24-0	21-9 e	19-0 e	26-11 i	23-8 i	19-4 a
1000S250-54	50	26-4	23-11	20-11 e	29-7 i	26-6 i	21-7 i	23-11	21-9	19-0 e	26-11 i	24-5 i	21-4 i
1000S300-54	33	27-6	24-10 e	20-4 e	28-9 i	24-10 i	20-4 a	25-0	22-8 e	19-10 e	28-0 i	24-10 i	20-4 a
1000S300-54	50	27-4	24-10	21-8 e	30-8 i	27-9 i	22-8 i	24-10	22-6	19-8 e	27-10 i	25-4 i	22-1 i
1000S137-68	33	25-3	22-11	19-1	27-0	23-5	19-1 i	22-11	20-10	18-2	25-9	23-5	19-1 i
1000S137-68	50	25-3	22-11	20-0	28-4	25-9	22-6 i	22-11	20-10	18-2	25-9	23-5	20-5
1000S162-68	33	26-2	23-9	20-2	28-6	24-8 i	20-2 i	23-9	21-7	18-10	26-8	24-3 i	20-2 i
1000S162-68	50	26-2	23-9	20-9	29-5	26-8	23-4 i	23-9	21-7	18-10	26-8	24-3	21-2
1000S200-68	33	27-1	24-7	21-2	29-11	25-11 i	21-2 i	24-7	22-4	19-6	27-7	25-1 i	21-2 i
1000S200-68	50	27-1	24-7	21-6	30-5	27-7	24-1 i	24-7	22-4	19-6	27-7	25-1	21-11 i
1000S250-68	33	28-5	25-10	22-5	31-9 i	27-6 i	22-5 i	25-10	23-5	20-6	29-0	26-4 i	22-5 i
1000S250-68	50	28-5	25-10	22-6	31-11	29-0	25-4 i	25-10	23-5	20-6	29-0	26-4	23-0 i
1000S300-68	33	29-7	26-11	23-2	32-9 i	28-4 i	23-2 i	26-11	24-5	21-4	30-2	27-5 i	23-2 i
1000S300-68	50	29-6	26-10	23-5	33-2	30-1	26-3 i	26-10	24-4	21-3	30-1	27-4	23-11 i
1000S162-97	33	29-3	26-7	23-2	32-10	29-2	23-9	26-7	24-2	21-1	29-10	27-1	23-8
1000S162-97	50	29-3	26-7	23-2	32-10	29-10	26-1	26-7	24-2	21-1	29-10	27-1	23-8
1000S200-97	33	30-3	27-6	24-0	34-0	30-8	25-0	27-6	25-0	21-10	30-10	28-0	24-6
1000S200-97	50	30-3	27-6	24-0	34-0	30-10	27-0	27-6	25-0	21-10	30-10	28-0	24-6
1000S250-97	33	31-9	28-10	25-2	35-8	32-5	26-11	28-10	26-3	22-11	32-5	29-5	25-9
1000S250-97	50	31-9	28-10	25-2	35-8	32-5	28-4	28-10	26-3	22-11	32-5	29-5	25-9
1000S300-97	33	33-2	30-1	26-3	37-2	33-10	28-6	30-1	27-4	23-11	33-10	30-8	26-10
1000S300-97	50	33-2	30-1	26-3	37-2	33-10	29-6	30-1	27-4	23-11	33-10	30-8	26-10

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 30 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1125S137-33	33	16-0 e	12-0 e	8-0 e	12-10 a	9-7 a	6-5 a	16-0 e	12-0 e	8-0 e	12-10 a	9-7 a	6-5 a
1125S162-33	33	16-0 e	12-0 e	8-0 e	12-10 a	9-7 a	6-5 a	16-0 e	12-0 e	8-0 e	12-10 a	9-7 a	6-5 a
1125S200-33	33	16-0 e	12-0 e	8-0 e	12-10 a	9-7 a	6-5 a	16-0 e	12-0 e	8-0 e	12-10 a	9-7 a	6-5 a
1125S137-43	33	21-4 e	18-6 e	15-1 e	21-4 a	18-6 a	14-3 a	21-4 e	18-6 e	15-1 e	21-4 a	18-6 a	14-3 a
1125S162-43	33	22-9 e	19-8 e	16-1 e	22-9 a	19-8 a	14-3 a	22-8 e	19-8 e	16-1 e	22-9 a	19-8 a	14-3 a
1125S200-43	33	22-6 e	19-5 e	15-11 e	22-6 a	19-5 a	14-3 a	22-6 e	19-5 e	15-11 e	22-6 a	19-5 a	14-3 a
1125S250-43	33	24-3 e	21-0 e	17-2 e	24-3 a	21-0 a	14-3 a	24-3 e	21-0 e	17-2 e	24-3 a	21-0 a	14-3 a
1125S300-43	33	25-8 e	22-3 e	17-10 e	25-8 a	21-4 a	14-3 a	25-5 e	22-3 e	17-10 e	25-8 a	21-4 a	14-3 a
1125S137-54	33	25-6	22-1 e	18-0 e	25-6 i	22-1 i	18-0 a	23-7	21-5 e	18-0 e	25-6 i	22-1 i	18-0 a
1125S137-54	50	26-0	23-7	20-6 e	29-1 i	25-2 i	20-6 i	23-7	21-5	18-9 e	26-6 i	24-1 i	20-6 i
1125S162-54	33	26-10	23-4 e	19-0 e	26-11 i	23-4 i	19-0 a	24-5	22-2 e	19-0 e	26-11 i	23-4 i	19-0 a
1125S162-54	50	26-10	24-5	21-4 e	30-2 i	26-8 i	21-9 i	24-5	22-2	19-4 e	27-5 i	24-10 i	21-9 i
1125S200-54	33	27-8 e	24-0 e	19-7 e	27-9 i	24-0 i	19-7 a	25-2	22-10 e	19-7 e	27-9 i	24-0 i	19-7 a
1125S200-54	50	27-8	25-2	21-5 e	30-4 i	26-3 i	21-5 i	25-2	22-10	20-0 e	28-3 i	25-8 i	21-5 i
1125S250-54	33	28-10 e	24-11 e	20-4 e	28-10 i	24-11 i	20-4 a	26-4	23-11 e	20-4 e	28-10 i	24-11 i	20-4 a
1125S250-54	50	29-0	26-4 e	22-10 e	32-4 i	28-0 i	22-10 a	26-4	23-11	20-11 e	29-7 i	26-10 i	22-10 a
1125S300-54	33	30-2 e	26-3 e	21-5 e	30-4 i	26-3 i	21-5 a	27-5 e	24-11 e	21-5 e	30-4 i	26-3 i	21-5 a
1125S300-54	50	30-0	27-3 e	23-10 e	33-8 i	29-5 i	24-0 a	27-3	24-9	21-7 e	30-7 i	27-10 i	24-0 a
1125S137-68	33	27-11	25-5	20-11	29-7	25-8 i	20-11 i	25-5	23-1	20-2	28-6	25-8 i	20-11 i
1125S137-68	50	27-11	25-5	22-2	31-4	28-6	24-11 i	25-5	23-1	20-2	28-6	25-11	22-7 i
1125S162-68	33	28-11	26-3	22-0	31-2 i	27-0 i	22-0 i	26-3	23-10	20-10	29-6	26-9 i	22-0 i
1125S162-68	50	28-11	26-3	22-11	32-5	29-6	25-9 i	26-3	23-10	20-10	29-6	26-9	23-5 i
1125S200-68	33	29-10	27-1	23-1	32-8 i	28-3 i	23-1 i	27-1	24-7	21-6	30-5	27-8 i	23-1 i
1125S200-68	50	29-10	27-1	23-8	33-6	30-5	26-7 i	27-1	24-7	21-6	30-5	27-8	24-2 i
1125S250-68	33	31-3	28-4	24-4 e	34-6 i	29-10 i	24-4 i	28-4	25-9	22-6	31-10 i	28-11 i	24-4 i
1125S250-68	50	31-3	28-4	24-9	35-1	31-10 i	27-1 i	28-4	25-9	22-6	31-10	28-11	25-3 i
1125S300-68	33	32-6	29-6	25-2 e	35-7 i	30-10 i	25-2 i	29-6	26-10	23-5 e	33-2 i	30-1 i	25-2 i
1125S300-68	50	32-5	29-6	25-9	36-5	33-1 i	28-8 i	29-6	26-9	23-5	33-1	30-1	26-3 i
1125S162-97	33	32-3	29-4	25-7	36-3	31-10	26-0	29-4	26-8	23-3	32-11	29-11	26-0
1125S162-97	50	32-3	29-4	25-7	36-3	32-11	28-9	29-4	26-8	23-3	32-11	29-11	26-2
1125S200-97	33	33-4	30-4	26-6	37-5	33-6	27-4	30-4	27-6	24-0	34-0	30-11	27-0
1125S200-97	50	33-4	30-4	26-6	37-5	34-0	29-9	30-4	27-6	24-0	34-0	30-11	27-0
1125S250-97	33	34-11	31-9	27-9	39-3	35-8	29-3	31-9	28-10	25-2	35-8	32-5	28-3
1125S250-97	50	34-11	31-9	27-9	39-3	35-8	31-2	31-9	28-10	25-2	35-8	32-5	28-3
1125S300-97	33	36-5	33-1	28-10	40-10	37-1	30-11	33-1	30-0	26-3	37-1	33-9	29-5
1125S300-97	50	36-5	33-1	28-10	40-10	37-1	32-5	33-1	30-0	26-3	37-1	33-9	29-5

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 30 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span		Two Equal Spans			
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		Spacing (in.) o.c.			
		12	16	24	12	16	24	12	16	24	12	16	24
1200S137-33	33	15-0 e	11-3 e	7-6 e	12-0 a	9-0 a	6-0 a	15-0 e	11-3 e	7-6 e	12-0 a	9-0 a	6-0 a
1200S162-33	33	15-0 e	11-3 e	7-6 e	12-0 a	9-0 a	6-0 a	15-0 e	11-3 e	7-6 e	12-0 a	9-0 a	6-0 a
1200S200-33	33	15-0 e	11-3 e	7-6 e	12-0 a	9-0 a	6-0 a	15-0 e	11-3 e	7-6 e	12-0 a	9-0 a	6-0 a
1200S137-43	33	22-0 e	19-1 e	15-7 e	22-0 a	19-1 a	13-4 a	22-0 e	19-1 e	15-7 e	22-0 a	19-1 a	13-4 a
1200S162-43	33	23-5 e	20-3 e	16-7 e	23-5 a	20-0 a	13-4 a	23-5 e	20-3 e	16-7 e	23-5 a	20-0 a	13-4 a
1200S200-43	33	23-2 e	20-1 e	16-4 e	23-2 a	20-0 a	13-4 a	23-2 e	20-1 e	16-4 e	23-2 a	20-0 a	13-4 a
1200S250-43	33	25-0 e	21-8 e	16-8 e	25-0 a	20-0 a	13-4 a	25-0 e	21-8 e	16-8 e	25-0 a	20-0 a	13-4 a
1200S300-43	33	26-6 e	23-0 e	16-8 e	26-6 a	20-0 a	13-4 a	26-6 e	23-0 e	16-8 e	26-6 a	20-0 a	13-4 a
1200S137-54	33	26-2 e	22-8 e	18-6 e	26-2 i	22-8 i	18-6 a	24-11	22-8 e	18-6 e	26-2 i	22-8 i	18-6 a
1200S137-54	50	27-5	24-11 e	21-2 e	29-11 i	25-11 i	21-2 i	24-11	22-8	19-9 e	28-0 i	25-5 i	21-2 i
1200S162-54	33	27-8 e	24-0 e	19-7 e	27-8 i	24-0 i	19-7 a	25-9	23-5 e	19-7 e	27-8 i	24-0 i	19-7 a
1200S162-54	50	28-4	25-9 e	22-5 e	31-9 i	27-6 i	22-5 a	25-9	23-5	20-5 e	28-11 i	26-3 i	22-5 a
1200S200-54	33	28-6 e	24-8 e	20-2 e	28-6 i	24-8 i	20-2 a	26-7 e	24-1 e	20-2 e	28-6 i	24-8 i	20-2 a
1200S200-54	50	29-3	26-7 e	22-1 e	31-3 i	27-1 i	22-1 a	26-7	24-1	21-1 e	29-10 i	27-1 i	22-1 a
1200S250-54	33	29-8 e	25-8 e	20-11 e	29-8 i	25-8 i	20-11 a	27-9 e	25-3 e	20-11 e	29-8 i	25-8 i	20-11 a
1200S250-54	50	30-7	27-9 e	23-7 e	33-5 i	28-11 i	23-7 a	27-9	25-3 e	22-0 e	31-2 i	28-4 i	23-7 a
1200S300-54	33	31-3 e	27-1 e	22-1 e	31-3 i	27-1 a	22-1 a	28-10 e	26-2 e	22-1 e	31-3 i	27-1 a	22-1 a
1200S300-54	50	31-8	28-9 e	24-9 e	35-1 i	30-4 i	24-9 a	28-9	26-2 e	22-10 e	32-4 i	29-4 i	24-9 a
1200S137-68	33	29-6	26-10	22-0	31-2 i	27-0 i	22-0 i	26-10	24-4	21-3	30-2	27-0 i	22-0 i
1200S137-68	50	29-6	26-10	23-5	33-2	30-2	25-8 i	26-10	24-4	21-3	30-2	27-4	23-11 i
1200S162-68	33	30-6	27-9	23-2 e	32-9 i	28-4 i	23-2 i	27-9	25-2	22-0	31-1 i	28-3 i	23-2 i
1200S162-68	50	30-6	27-9	24-2	34-3	31-1 i	27-1 i	27-9	25-2	22-0	31-1	28-3	24-8 i
1200S200-68	33	31-6	28-7	24-2 e	34-3 i	29-8 i	24-2 i	28-7	26-0	22-8 e	32-1 i	29-2 i	24-2 i
1200S200-68	50	31-6	28-7	25-0	35-4	32-1 i	27-7 i	28-7	26-0	22-8	32-1	29-2	25-6 i
1200S250-68	33	32-11	29-11	25-6 e	36-2 i	31-3 i	25-6 i	29-11	27-2	23-9 e	33-7 i	30-6 i	25-6 i
1200S250-68	50	32-11	29-11	26-1	36-11	33-7 i	27-11 i	29-11	27-2	23-9	33-7	30-6 i	26-8 i
1200S300-68	33	34-3	31-1	26-3 e	37-2 i	32-2 i	26-3 i	31-1	28-3	24-8 e	34-11 i	31-8 i	26-3 i
1200S300-68	50	34-3	31-1	27-2	38-5	34-11 i	29-6 i	31-1	28-3	24-8	34-11	31-8 i	27-8 i
1200S162-97	33	34-1	31-0	27-1	38-4	33-6	27-4	31-0	28-2	24-7	34-10	31-7	27-4
1200S162-97	50	34-1	31-0	27-1	38-4	34-10	30-5	31-0	28-2	24-7	34-10	31-7	27-7
1200S200-97	33	35-2	32-0	27-11	39-6	35-1	28-8	32-0	29-1	25-4	35-11	32-7	28-6
1200S200-97	50	35-2	32-0	27-11	39-6	35-11	31-4	32-0	29-1	25-4	35-11	32-7	28-6
1200S250-97	33	36-10	33-5	29-3	41-4	37-7	30-8	33-5	30-5	26-6	37-7	34-1	29-10
1200S250-97	50	36-10	33-5	29-3	41-4	37-7	32-10	33-5	30-5	26-6	37-7	34-1	29-10
1200S300-97	33	38-4	34-10	30-5	43-0	39-1	32-5 i	34-10	31-7	27-7	39-1	35-6	31-0
1200S300-97	50	38-4	34-10	30-5	43-0	39-1	34-2	34-10	31-7	27-7	39-1	35-6	31-0

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 30 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1400S137-33	33	12-10 e	9-7 e	6-5 e	10-3 a	7-8 a	5-1 a	12-10 e	9-7 e	6-5 e	10-3 a	7-8 a	5-1 a
1400S162-33	33	12-10 e	9-7 e	6-5 e	10-3 a	7-8 a	5-1 a	12-10 e	9-7 e	6-5 e	10-3 a	7-8 a	5-1 a
1400S200-33	33	12-10 e	9-7 e	6-5 e	10-3 a	7-8 a	5-1 a	12-10 e	9-7 e	6-5 e	10-3 a	7-8 a	5-1 a
1400S137-43	33	23-8 e	20-6 e	14-3 e	22-9 a	17-1 a	11-4 a	23-8 e	20-6 e	14-3 e	22-9 a	17-1 a	11-4 a
1400S162-43	33	25-2 e	21-4 e	14-3 e	22-9 a	17-1 a	11-4 a	25-2 e	21-4 e	14-3 e	22-9 a	17-1 a	11-4 a
1400S200-43	33	25-0 e	21-4 e	14-3 e	22-9 a	17-1 a	11-4 a	25-0 e	21-4 e	14-3 e	22-9 a	17-1 a	11-4 a
1400S250-43	33	27-0 e	21-4 e	14-3 e	22-9 a	17-1 a	11-4 a	27-0 e	21-4 e	14-3 e	22-9 a	17-1 a	11-4 a
1400S300-43	33	28-6 e	21-4 e	14-3 e	22-9 a	17-1 a	11-4 a	28-6 e	21-4 e	14-3 e	22-9 a	17-1 a	11-4 a
1400S137-54	33	28-0 e	24-3 e	19-10 e	28-0 i	24-3 a	19-10 a	28-0 e	24-3 e	19-10 e	28-0 i	24-3 a	19-10 a
1400S137-54	50	30-7 e	27-9 e	22-9 e	32-2 i	27-10 i	22-7 a	27-9 e	25-3 e	22-0 e	31-2 i	27-10 i	22-7 a
1400S162-54	33	29-8 e	25-8 e	20-11 e	29-8 i	25-8 a	20-11 a	29-4 e	25-8 e	20-11 e	29-8 i	25-8 a	20-11 a
1400S162-54	50	31-7 e	28-8 e	24-2 e	34-2 i	29-7 a	22-7 a	28-8 e	26-0 e	22-9 e	32-2 i	29-3 a	22-7 a
1400S200-54	33	30-7 e	26-6 e	21-7 e	30-7 i	26-6 a	21-7 a	30-2 e	26-6 e	21-7 e	30-7 i	26-6 a	21-7 a
1400S200-54	50	32-11 e	29-2 e	23-10 e	33-8 i	29-2 a	22-7 a	29-10 e	27-2 e	23-8 e	33-6 i	29-2 a	22-7 a
1400S250-54	33	31-10 e	27-7 e	22-6 e	31-10 a	27-7 a	22-6 a	31-6 e	27-7 e	22-6 e	31-10 a	27-7 a	22-6 a
1400S250-54	50	34-4 e	31-2 e	25-5 e	36-0 i	31-2 a	22-7 a	31-2 e	28-4 e	24-9 e	35-0 i	31-2 a	22-7 a
1400S300-54	33	33-7 e	29-1 e	23-9 e	33-7 a	29-1 a	22-7 a	32-8 e	29-1 e	23-9 e	33-7 a	29-1 a	22-7 a
1400S300-54	50	35-8 e	32-5 e	26-9 e	37-10 i	32-9 a	22-7 a	32-5 e	29-5 e	25-8 e	36-4 i	32-9 a	22-7 a
1400S137-68	33	33-9	29-4	23-11 e	33-10 i	29-4 i	23-11 i	30-8	27-10	23-11 e	33-10 i	29-4 i	23-11 i
1400S137-68	50	33-9	30-8	26-10 e	37-11	33-7 i	27-5 i	30-8	27-10	24-4	34-5	31-4 i	27-4 i
1400S162-68	33	34-10	30-9	25-1 e	35-6 i	30-9 i	25-1 i	31-7	28-9	25-1 e	35-6 i	30-9 i	25-1 i
1400S162-68	50	34-10	31-7	27-7 e	39-1 i	35-6 i	29-0 i	31-7	28-9	25-1	35-6	32-3 i	28-2 i
1400S200-68	33	35-10	32-2 e	26-3 e	37-2 i	32-2 i	26-3 i	32-6	29-7	25-10 e	36-6 i	32-2 i	26-3 i
1400S200-68	50	35-10	32-6	28-5 e	40-2 i	36-3 i	29-7 i	32-6	29-7	25-10	36-6	33-2 i	29-0 i
1400S250-68	33	37-4	33-9 e	27-6 e	39-0 i	33-9 i	27-6 i	33-11	30-10	26-11 e	38-1 i	33-9 i	27-6 i
1400S250-68	50	37-4	33-11	29-7 e	41-11 i	36-9 i	30-0 i	33-11	30-10	26-11 e	38-1	34-7 i	30-0 i
1400S300-68	33	38-9	34-5 e	28-1 e	39-9 i	34-5 i	28-1 a	35-2	32-0 e	27-11 e	39-6 i	34-5 i	28-1 a
1400S300-68	50	38-9	35-2	30-9 e	43-6 i	38-11 i	31-9 i	35-2	32-0	27-11 e	39-6 i	35-11 i	31-4 i
1400S162-97	33	38-11	35-4	30-10	43-8	37-10	30-10 i	35-4	32-2	28-1	39-9	36-1	30-10 i
1400S162-97	50	38-11	35-4	30-11	43-9	39-9	34-8	35-4	32-2	28-1	39-9	36-1	31-6
1400S200-97	33	40-1	36-5	31-10	45-0	39-6	32-3 i	36-5	33-1	28-11	40-11	37-2	32-3 i
1400S200-97	50	40-1	36-5	31-10	45-0	40-11	35-8	36-5	33-1	28-11	40-11	37-2	32-5
1400S250-97	33	41-10	38-0	33-2	46-11	42-1	34-4 i	38-0	34-6	30-2	42-8	38-9	33-10 i
1400S250-97	50	41-10	38-0	33-2	46-11	42-8	37-3	38-0	34-6	30-2	42-8	38-9	33-10
1400S300-97	33	43-5	39-5	34-5	48-9	44-3	36-2 i	39-5	35-10	31-3	44-3	40-2	35-1 i
1400S300-97	50	43-5	39-5	34-5	48-9	44-3	38-8	39-5	35-10	31-3	44-3	40-2	35-1

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 40 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
600S137-33	33	11-6 e	10-0 e	8-2 e	11-6 i	10-0 a	8-2 a	10-10 e	9-10 e	8-2 e	11-6 i	10-0 a	8-2 a
600S162-33	33	12-3 e	10-7 e	8-8 e	12-3 a	10-7 a	8-8 a	11-4 e	10-3 e	8-8 e	12-3 a	10-7 a	8-8 a
600S200-33	33	12-5 e	10-9 e	8-9 e	12-5 a	10-9 a	8-9 a	11-9 e	10-8 e	8-9 e	12-5 a	10-9 a	8-9 a
600S137-43	33	13-0	11-6	9-5 e	13-4 i	11-6 i	9-5 i	11-10	10-9	9-4 e	13-3 i	11-6 i	9-5 i
600S162-43	33	13-7	12-3	10-0 e	14-2 i	12-3 i	10-0 i	12-4	11-2	9-9 e	13-10 i	12-3 i	10-0 i
600S200-43	33	14-1	12-4	10-1 e	14-3 i	12-4 i	10-1 i	12-10	11-8	10-1 e	14-3 i	12-4 i	10-1 i
600S250-43	33	14-11	13-4 e	10-11 e	15-5 i	13-4 i	10-11 i	13-7	12-4	10-9 e	15-3 i	13-4 i	10-11 i
600S300-43	33	15-7	14-1 e	11-7 e	16-4 i	14-2 i	11-7 a	14-1	12-10 e	11-2 e	15-10 i	14-2 i	11-7 a
600S137-54	33	13-11	12-8	10-5	14-10	12-10	10-5 i	12-8	11-6	10-1	14-3	12-10	10-5 i
600S137-54	50	13-11	12-8	11-1	15-8	14-3	12-5 i	12-8	11-6	10-1	14-3	12-11	11-3
600S162-54	33	14-7	13-3	11-2	15-9	13-8 i	11-2 i	13-3	12-0	10-6	14-10	13-6 i	11-2 i
600S162-54	50	14-7	13-3	11-7	16-4	14-10	13-0 i	13-3	12-0	10-6	14-10	13-6	11-9
600S200-54	33	15-2	13-9	11-8	16-6	14-3 i	11-8 i	13-9	12-6	10-11	15-6	14-1 i	11-8 i
600S200-54	50	15-2	13-9	12-0	17-1	15-6	13-6 i	13-9	12-6	10-11	15-6	14-1	12-3 i
600S250-54	33	16-1	14-7	12-4	17-5	15-1 i	12-4 i	14-7	13-3	11-7	16-4	14-10 i	12-4 i
600S250-54	50	16-0	14-6	12-8	17-11	16-3	14-3 i	14-6	13-2	11-6	16-3	14-9	12-11 i
600S300-54	33	16-10	15-3	13-1	18-6 i	16-0 i	13-1 i	15-3	13-11	12-1	17-2	15-7 i	13-1 i
600S300-54	50	16-7	15-1	13-2	18-8	16-11	14-9 i	15-1	13-8	12-0	16-11	15-5	13-5 i
600S137-68	33	15-0	13-7	11-8	16-6	14-3	11-8	13-7	12-4	10-10	15-4	13-11	11-8
600S137-68	50	15-0	13-7	11-11	16-10	15-4	13-4	13-7	12-4	10-10	15-4	13-11	12-2
600S162-68	33	15-8	14-3	12-5	17-7	15-3	12-5	14-3	12-11	11-3	16-0	14-6	12-5
600S162-68	50	15-8	14-3	12-5	17-7	16-0	13-11	14-3	12-11	11-3	16-0	14-6	12-8
600S200-68	33	16-4	14-10	12-11	18-4	16-2	13-2	14-10	13-6	11-9	16-8	15-1	13-2
600S200-68	50	16-4	14-10	12-11	18-4	16-8	14-6	14-10	13-6	11-9	16-8	15-1	13-2
600S250-68	33	17-3	15-8	13-8	19-5	17-4	14-2 i	15-8	14-3	12-5	17-7	16-0	14-0 i
600S250-68	50	17-3	15-8	13-8	19-5	17-7	15-5	15-8	14-3	12-5	17-7	16-0	14-0
600S300-68	33	18-1	16-5	14-4	20-4	18-0	14-8 i	16-5	14-11	13-0	18-6	16-9	14-8 i
600S300-68	50	18-0	16-5	14-4	20-3	18-5	16-1	16-5	14-11	13-0	18-5	16-9	14-7
600S162-97	33	17-5	15-10	13-10	19-7	17-10	14-7	15-10	14-5	12-7	17-10	16-2	14-1
600S162-97	50	17-5	15-10	13-10	19-7	17-10	15-6	15-10	14-5	12-7	17-10	16-2	14-1
600S200-97	33	18-2	16-6	14-5	20-5	18-7	15-7	16-6	15-0	13-1	18-7	16-10	14-9
600S200-97	50	18-2	16-6	14-5	20-5	18-7	16-3	16-6	15-0	13-1	18-7	16-10	14-9
600S250-97	33	19-3	17-6	15-3	21-8	19-8	17-0	17-6	15-11	13-11	19-8	17-10	15-7
600S250-97	50	19-3	17-6	15-3	21-8	19-8	17-2	17-6	15-11	13-11	19-8	17-10	15-7
600S300-97	33	20-3	18-4	16-0	22-8	20-7	18-0	18-4	16-8	14-7	20-7	18-9	16-4
600S300-97	50	20-3	18-4	16-0	22-8	20-7	18-0	18-4	16-8	14-7	20-7	18-9	16-4

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 40 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
800S137-33	33	13-2 e	11-5 e	9-1 e	13-2 a	10-11 a	7-3 a	13-2 e	11-5 e	9-1 e	13-2 a	10-11 a	7-3 a
800S162-33	33	14-0 e	12-1 e	9-1 e	14-0 a	10-11 a	7-3 a	14-0 e	12-1 e	9-1 e	14-0 a	10-11 a	7-3 a
800S200-33	33	14-2 e	12-3 e	9-1 e	14-2 a	10-11 a	7-3 a	14-2 e	12-3 e	9-1 e	14-2 a	10-11 a	7-3 a
800S137-43	33	16-5 e	14-2 e	11-7 e	16-5 i	14-2 i	11-7 a	14-11 e	13-7 e	11-7 e	16-5 i	14-2 i	11-7 a
800S162-43	33	17-1 e	15-1 e	12-3 e	17-5 i	15-1 a	12-3 a	15-6 e	14-1 e	12-3 e	17-5 i	15-1 a	12-3 a
800S200-43	33	17-2 e	14-11 e	12-2 e	17-2 i	14-11 a	12-2 a	16-1 e	14-8 e	12-2 e	17-2 i	14-11 a	12-2 a
800S250-43	33	18-6 e	16-0 e	13-1 e	18-6 i	16-0 a	13-1 a	16-11 e	15-5 e	13-1 e	18-6 i	16-0 a	13-1 a
800S300-43	33	19-5 e	16-11 e	13-9 e	19-6 i	16-11 a	13-9 a	17-8 e	16-0 e	13-9 e	19-6 i	16-11 a	13-9 a
800S137-54	33	17-8	15-10	12-11 e	18-3 i	15-10 i	12-11 i	16-1	14-7	12-9 e	18-0 i	15-10 i	12-11 i
800S137-54	50	17-8	16-1	14-0	19-10	18-0 i	15-9 i	16-1	14-7	12-9	18-0	16-5	14-4 i
800S162-54	33	18-5	16-8	13-8 e	19-4 i	16-9 i	13-8 i	16-8	15-2	13-3 e	18-9 i	16-9 i	13-8 i
800S162-54	50	18-5	16-8	14-7	20-8	18-9 i	16-4 i	16-8	15-2	13-3	18-9	17-0 i	14-10 i
800S200-54	33	19-1	17-4	14-3 e	20-2 i	17-5 i	14-3 i	17-4	15-9	13-9 e	19-5 i	17-5 i	14-3 i
800S200-54	50	19-1	17-4	15-2	21-5	19-5 i	16-4 i	17-4	15-9	13-9	19-5	17-8 i	15-5 i
800S250-54	33	20-1	18-3	14-11 e	21-2 i	18-4 i	14-11 i	18-3	16-7	14-6 e	20-6 i	18-4 i	14-11 i
800S250-54	50	20-0	18-2	15-10 e	22-5 i	20-5 i	17-5 i	18-2	16-6	14-5	20-5	18-6 i	16-2 i
800S300-54	33	21-0	19-1 e	15-10 e	22-5 i	19-5 i	15-10 i	19-1	17-4	15-1 e	21-5 i	19-5 i	15-10 i
800S300-54	50	20-9	18-10	16-6 e	23-4 i	21-2 i	18-3 i	18-10	17-1	14-11	21-2	19-3 i	16-10 i
800S137-68	33	19-0	17-3	14-5	20-5	17-8	14-5 i	17-3	15-8	13-8	19-5	17-7	14-5 i
800S137-68	50	19-0	17-3	15-1	21-4	19-5	16-11	17-3	15-8	13-8	19-5	17-7	15-5
800S162-68	33	19-9	17-11	15-3	21-7	18-8	15-3 i	17-11	16-4	14-3	20-2	18-4	15-3 i
800S162-68	50	19-9	17-11	15-8	22-2	20-2	17-7	17-11	16-4	14-3	20-2	18-4	16-0
800S200-68	33	20-6	18-8	16-1	22-10	19-9	16-1 i	18-8	16-11	14-9	20-11	19-0	16-1 i
800S200-68	50	20-6	18-8	16-3	23-1	20-11	18-3 i	18-8	16-11	14-9	20-11	19-0	16-7
800S250-68	33	21-7	19-8	17-2	24-3	21-0 i	17-2 i	19-8	17-10	15-7	22-1	20-0 i	17-2 i
800S250-68	50	21-7	19-8	17-2	24-3	22-1	19-3 i	19-8	17-10	15-7	22-1	20-0	17-6
800S300-68	33	22-7	20-6	17-9	25-2	21-9 i	17-9 i	20-6	18-8	16-3	23-0	20-11 i	17-9 i
800S300-68	50	22-6	20-5	17-10	25-3	22-11	20-0 i	20-5	18-7	16-3	22-11	20-10	18-2 i
800S162-97	33	22-1	20-0	17-6	24-9	22-1	18-0	20-0	18-2	15-11	22-6	20-5	17-10
800S162-97	50	22-1	20-0	17-6	24-9	22-6	19-8	20-0	18-2	15-11	22-6	20-5	17-10
800S200-97	33	22-11	20-10	18-2	25-9	23-4	19-1	20-10	18-11	16-6	23-4	21-3	18-7
800S200-97	50	22-11	20-10	18-2	25-9	23-4	20-5	20-10	18-11	16-6	23-4	21-3	18-7
800S250-97	33	24-2	21-11	19-2	27-1	24-8	20-7	21-11	19-11	17-5	24-8	22-5	19-7
800S250-97	50	24-2	21-11	19-2	27-1	24-8	21-6	21-11	19-11	17-5	24-8	22-5	19-7
800S300-97	33	25-3	22-11	20-0	28-4	25-9	21-11	22-11	20-10	18-2	25-9	23-5	20-5
800S300-97	50	25-3	22-11	20-0	28-4	25-9	22-6	22-11	20-10	18-2	25-9	23-5	20-5

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 40 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
925S137-33	33	14-1 e	11-9 e	7-10 e	12-6 a	9-5 a	6-3 a	14-1 e	11-9 e	7-10 e	12-6 a	9-5 a	6-3 a
925S162-33	33	15-0 e	11-9 e	7-10 e	12-6 a	9-5 a	6-3 a	15-0 e	11-9 e	7-10 e	12-6 a	9-5 a	6-3 a
925S200-33	33	15-3 e	11-9 e	7-10 e	12-6 a	9-5 a	6-3 a	15-3 e	11-9 e	7-10 e	12-6 a	9-5 a	6-3 a
925S137-43	33	17-6 e	15-2 e	12-5 e	17-6 i	15-2 a	12-5 a	16-10 e	15-2 e	12-5 e	17-6 i	15-2 a	12-5 a
925S162-43	33	18-7 e	16-1 e	13-2 e	18-7 a	16-1 a	13-2 a	17-6 e	15-11 e	13-2 e	18-7 a	16-1 a	13-2 a
925S200-43	33	18-4 e	15-11 e	13-0 e	18-4 a	15-11 a	13-0 a	18-1 e	15-11 e	13-0 e	18-4 a	15-11 a	13-0 a
925S250-43	33	19-9 e	17-1 e	14-0 e	19-9 a	17-1 a	13-11 a	19-0 e	17-1 e	14-0 e	19-9 a	17-1 a	13-11 a
925S300-43	33	20-11 e	18-1 e	14-9 e	20-11 a	18-1 a	13-11 a	19-9 e	18-0 e	14-9 e	20-11 a	18-1 a	13-11 a
925S137-54	33	20-0	17-8	14-5 e	20-5 i	17-8 i	14-5 i	18-2	16-6	14-5 e	20-4 i	17-8 i	14-5 i
925S137-54	50	20-0	18-2	15-10 e	22-5 i	20-4 i	16-10 i	18-2	16-6	14-5	20-4	18-6 i	16-2 i
925S162-54	33	20-9	18-8 e	15-3 e	21-7 i	18-8 i	15-3 i	18-10	17-1	14-11 e	21-2 i	18-8 i	15-3 i
925S162-54	50	20-9	18-10	16-5 e	23-3 i	21-2 i	17-10 i	18-10	17-1	14-11 e	21-2	19-2 i	16-9 i
925S200-54	33	21-5	19-4 e	15-10 e	22-4 i	19-4 i	15-10 a	19-6	17-8	15-5 e	21-10 i	19-4 i	15-10 a
925S200-54	50	21-5	19-6	17-0 e	24-1 i	21-5 i	17-6 i	19-6	17-8	15-5 e	21-10 i	19-10 i	17-4 i
925S250-54	33	22-6	20-3 e	16-7 e	23-5 i	20-3 i	16-7 a	20-5	18-7 e	16-3 e	23-0 i	20-3 i	16-7 a
925S250-54	50	22-6	20-5	17-10 e	25-3 i	22-10 i	18-8 i	20-5	18-6	16-2 e	22-11 i	20-10 i	18-2 i
925S300-54	33	23-6	21-4 e	17-6 e	24-9 i	21-5 i	17-6 a	21-4	19-5 e	16-11 e	24-0 i	21-5 i	17-6 a
925S300-54	50	23-4	21-2	18-6 e	26-2 i	23-9 i	19-6 i	21-2	19-3	16-9 e	23-9 i	21-7 i	18-10 i
925S137-68	33	21-6	19-6	16-1	22-9	19-8 i	16-1 i	19-6	17-9	15-6	21-11	19-8 i	16-1 i
925S137-68	50	21-6	19-6	17-0	24-1	21-11	19-2 i	19-6	17-9	15-6	21-11	19-11	17-5 i
925S162-68	33	22-3	20-3	17-0	24-1	20-10 i	17-0 i	20-3	18-5	16-1	22-9	20-8 i	17-0 i
925S162-68	50	22-3	20-3	17-8	25-0	22-9	19-10 i	20-3	18-5	16-1	22-9	20-8	18-0 i
925S200-68	33	23-1	21-0	17-11	25-4	21-11 i	17-11 i	21-0	19-1	16-8	23-6	21-5 i	17-11 i
925S200-68	50	23-1	21-0	18-4	25-11	23-6	20-7 i	21-0	19-1	16-8	23-6	21-5	18-8 i
925S250-68	33	24-3	22-0	19-0	26-10 i	23-3 i	19-0 i	22-0	20-0	17-6	24-9	22-6 i	19-0 i
925S250-68	50	24-3	22-0	19-3	27-3	24-9	21-7 i	22-0	20-0	17-6	24-9	22-6	19-7 i
925S300-68	33	25-4	23-0	19-7	27-9 i	24-0 i	19-7 i	23-0	20-10	18-3	25-10 i	23-5 i	19-7 i
925S300-68	50	25-2	22-11	20-0	28-3	25-8	22-5 i	22-11	20-9	18-2	25-8	23-4	20-5 i
925S162-97	33	24-11	22-7	19-9	27-11	24-7	20-1	22-7	20-6	17-11	25-5	23-1	20-1
925S162-97	50	24-11	22-7	19-9	27-11	25-5	22-2	22-7	20-6	17-11	25-5	23-1	20-2
925S200-97	33	25-9	23-5	20-5	28-11	25-11	21-2	23-5	21-3	18-7	26-4	23-11	20-10
925S200-97	50	25-9	23-5	20-5	28-11	26-4	23-0	23-5	21-3	18-7	26-4	23-11	20-10
925S250-97	33	27-1	24-7	21-6	30-5	27-8	22-10	24-7	22-4	19-6	27-8	25-1	21-11
925S250-97	50	27-1	24-7	21-6	30-5	27-8	24-2	24-7	22-4	19-6	27-8	25-1	21-11
925S300-97	33	28-4	25-8	22-5	31-9	28-10	24-2	25-8	23-4	20-5	28-10	26-3	22-11
925S300-97	50	28-4	25-8	22-5	31-9	28-10	25-3	25-8	23-4	20-5	28-10	26-3	22-11

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 40 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1000S137-33	33	14-6 e	10-10 e	7-3 e	11-7 a	8-8 a	5-9 a	14-6 e	10-10 e	7-3 e	11-7 a	8-8 a	5-9 a
1000S162-33	33	14-6 e	10-10 e	7-3 e	11-7 a	8-8 a	5-9 a	14-6 e	10-10 e	7-3 e	11-7 a	8-8 a	5-9 a
1000S200-33	33	14-6 e	10-10 e	7-3 e	11-7 a	8-8 a	5-9 a	14-6 e	10-10 e	7-3 e	11-7 a	8-8 a	5-9 a
1000S137-43	33	18-2 e	15-8 e	12-10 e	18-2 a	15-8 a	12-10 a	18-0 e	15-8 e	12-10 e	18-2 a	15-8 a	12-10 a
1000S162-43	33	19-3 e	16-8 e	13-7 e	19-3 a	16-8 a	12-10 a	18-8 e	16-8 e	13-7 e	19-3 a	16-8 a	12-10 a
1000S200-43	33	19-0 e	16-6 e	13-5 e	19-0 a	16-6 a	12-10 a	19-0 e	16-6 e	13-5 e	19-0 a	16-6 a	12-10 a
1000S250-43	33	20-6 e	17-9 e	14-6 e	20-6 a	17-9 a	12-10 a	20-3 e	17-9 e	14-6 e	20-6 a	17-9 a	12-10 a
1000S300-43	33	21-8 e	18-10 e	15-4 e	21-8 a	18-10 a	12-10 a	21-1 e	18-10 e	15-4 e	21-8 a	18-10 a	12-10 a
1000S137-54	33	21-4	18-9 e	15-4 e	21-8 i	18-9 i	15-4 a	19-5	17-7 e	15-4 e	21-8 i	18-9 i	15-4 a
1000S137-54	50	21-4	19-5	16-11 e	23-11 i	21-4 i	17-5 i	19-5	17-7	15-4 e	21-9 i	19-9 i	17-3 i
1000S162-54	33	22-1	19-9 e	16-2 e	22-10 i	19-9 i	16-2 a	20-1	18-3 e	15-11 e	22-6 i	19-9 i	16-2 a
1000S162-54	50	22-1	20-1	17-6 e	24-10 i	22-6 i	18-5 i	20-1	18-3	15-11 e	22-6 i	20-6 i	17-11 i
1000S200-54	33	22-10 e	20-5 e	16-8 e	23-7 i	20-5 i	16-8 a	20-9	18-10 e	16-6 e	23-4 i	20-5 i	16-8 a
1000S200-54	50	22-10	20-9	18-1 e	25-8 i	22-2 i	18-1 i	20-9	18-10	16-6 e	23-4 i	21-2 i	18-1 i
1000S250-54	33	24-0 e	21-2 e	17-3 e	24-5 i	21-2 i	17-3 a	21-9	19-9 e	17-3 e	24-5 i	21-2 i	17-3 a
1000S250-54	50	23-11	21-9 e	19-0 e	26-11 i	23-8 i	19-4 a	21-9	19-9	17-3 e	24-5 i	22-2 i	19-4 a
1000S300-54	33	25-0 e	22-3 e	18-2 e	25-8 i	22-3 i	18-2 a	22-8	20-7 e	18-0 e	25-6 i	22-3 i	18-2 a
1000S300-54	50	24-10	22-6 e	19-8 e	27-10 i	24-10 i	20-3 a	22-6	20-6	17-11 e	25-4 i	23-0 i	20-1 a
1000S137-68	33	22-11	20-10	17-1	24-2	20-11 i	17-1 i	20-10	18-11	16-6	23-5	20-11 i	17-1 i
1000S137-68	50	22-11	20-10	18-2	25-9	23-5	20-5 i	20-10	18-11	16-6	23-5	21-3	18-7 i
1000S162-68	33	23-9	21-7	18-0	25-6 i	22-1 i	18-0 i	21-7	19-7	17-2	24-3	22-0 i	18-0 i
1000S162-68	50	23-9	21-7	18-10	26-8	24-3	21-2 i	21-7	19-7	17-2	24-3	22-0	19-3 i
1000S200-68	33	24-7	22-4	18-11	26-9 i	23-2 i	18-11 i	22-4	20-4	17-9	25-1	22-9 i	18-11 i
1000S200-68	50	24-7	22-4	19-6	27-7	25-1	21-11 i	22-4	20-4	17-9	25-1	22-9	19-11 i
1000S250-68	33	25-10	23-5	20-1 e	28-4 i	24-7 i	20-1 i	23-5	21-3	18-7	26-4 i	23-11 i	20-1 i
1000S250-68	50	25-10	23-5	20-6	29-0	26-4 i	23-0 i	23-5	21-3	18-7	26-4	23-11	20-11 i
1000S300-68	33	26-11	24-5	20-8 e	29-4 i	25-4 i	20-8 i	24-5	22-2	19-5 e	27-5 i	24-11 i	20-8 i
1000S300-68	50	26-10	24-4	21-3	30-1	27-4 i	23-11 i	24-4	22-1	19-4	27-4	24-10	21-8 i
1000S162-97	33	26-7	24-2	21-1	29-10	26-1	21-3	24-2	21-11	19-2	27-1	24-7	21-3
1000S162-97	50	26-7	24-2	21-1	29-10	27-1	23-8	24-2	21-11	19-2	27-1	24-7	21-6
1000S200-97	33	27-6	25-0	21-10	30-10	27-5	22-5	25-0	22-8	19-10	28-0	25-6	22-3
1000S200-97	50	27-6	25-0	21-10	30-10	28-0	24-6	25-0	22-8	19-10	28-0	25-6	22-3
1000S250-97	33	28-10	26-3	22-11	32-5	29-5	24-1	26-3	23-10	20-10	29-5	26-9	23-4
1000S250-97	50	28-10	26-3	22-11	32-5	29-5	25-9	26-3	23-10	20-10	29-5	26-9	23-4
1000S300-97	33	30-1	27-4	23-11	33-10	30-8	25-6	27-4	24-10	21-8	30-8	27-11	24-4
1000S300-97	50	30-1	27-4	23-11	33-10	30-8	26-10	27-4	24-10	21-8	30-8	27-11	24-4

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 40 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1125S137-33	33	12-10 e	9-7 e	6-5 e	10-3 a	7-8 a	5-1 a	12-10 e	9-7 e	6-5 e	10-3 a	7-8 a	5-1 a
1125S162-33	33	12-10 e	9-7 e	6-5 e	10-3 a	7-8 a	5-1 a	12-10 e	9-7 e	6-5 e	10-3 a	7-8 a	5-1 a
1125S200-33	33	12-10 e	9-7 e	6-5 e	10-3 a	7-8 a	5-1 a	12-10 e	9-7 e	6-5 e	10-3 a	7-8 a	5-1 a
1125S137-43	33	19-1 e	16-7 e	13-6 e	19-1 a	16-7 a	11-5 a	19-1 e	16-7 e	13-6 e	19-1 a	16-7 a	11-5 a
1125S162-43	33	20-4 e	17-7 e	14-3 e	20-4 a	17-1 a	11-5 a	20-4 e	17-7 e	14-3 e	20-4 a	17-1 a	11-5 a
1125S200-43	33	20-1 e	17-5 e	14-2 e	20-1 a	17-1 a	11-5 a	20-1 e	17-5 e	14-2 e	20-1 a	17-1 a	11-5 a
1125S250-43	33	21-8 e	18-9 e	14-3 e	21-8 a	17-1 a	11-5 a	21-8 e	18-9 e	14-3 e	21-8 a	17-1 a	11-5 a
1125S300-43	33	23-0 e	19-11 e	14-3 e	22-10 a	17-1 a	11-5 a	23-0 e	19-11 e	14-3 e	22-10 a	17-1 a	11-5 a
1125S137-54	33	22-10 e	19-9 e	16-1 e	22-10 i	19-9 i	16-1 a	21-5	19-6 e	16-1 e	22-10 i	19-9 i	16-1 a
1125S137-54	50	23-7	21-5 e	18-4 e	26-0 i	22-6 i	18-4 a	21-5	19-6	17-0 e	24-1 i	21-10 i	18-4 a
1125S162-54	33	24-1 e	20-10 e	17-0 e	24-1 i	20-10 i	17-0 a	22-2 e	20-1 e	17-0 e	24-1 i	20-10 i	17-0 a
1125S162-54	50	24-5	22-2 e	19-4 e	27-5 i	23-10 i	19-6 a	22-2	20-1	17-7 e	24-10 i	22-7 i	19-6 a
1125S200-54	33	24-10 e	21-6 e	17-6 e	24-10 i	21-6 i	17-6 a	22-10 e	20-9 e	17-6 e	24-10 i	21-6 i	17-6 a
1125S200-54	50	25-2	22-10 e	19-2 e	27-1 i	23-6 i	19-2 a	22-10	20-9 e	18-2 e	25-8 i	23-4 i	19-2 a
1125S250-54	33	25-9 e	22-4 e	18-2 e	25-9 i	22-4 a	18-2 a	23-11 e	21-9 e	18-2 e	25-9 i	22-4 a	18-2 a
1125S250-54	50	26-4	23-11 e	20-5 e	28-11 i	25-1 i	20-5 a	23-11	21-9 e	19-0 e	26-10 i	24-5 i	20-5 a
1125S300-54	33	27-1 e	23-6 e	19-2 e	27-1 i	23-6 a	19-2 a	24-11 e	22-7 e	19-2 e	27-1 i	23-6 a	19-2 a
1125S300-54	50	27-3 e	24-9 e	21-6 e	30-5 i	26-4 i	21-6 a	24-9	22-6 e	19-8 e	27-10 i	25-3 i	21-6 a
1125S137-68	33	25-5	22-11	18-9 e	26-6 i	22-11 i	18-9 i	23-1	20-11	18-3	25-11 i	22-11 i	18-9 i
1125S137-68	50	25-5	23-1	20-2	28-6	25-11 i	22-4 i	23-1	20-11	18-3	25-11	23-6	20-6 i
1125S162-68	33	26-3	23-10	19-8 e	27-10 i	24-1 i	19-8 i	23-10	21-8	18-11 e	26-9 i	24-1 i	19-8 i
1125S162-68	50	26-3	23-10	20-10	29-6	26-9 i	23-5 i	23-10	21-8	18-11	26-9	24-4	21-3 i
1125S200-68	33	27-1	24-7	20-8 e	29-2 i	25-3 i	20-8 i	24-7	22-4	19-6 e	27-8 i	25-1 i	20-8 i
1125S200-68	50	27-1	24-7	21-6	30-5	27-8 i	24-0 i	24-7	22-4	19-6	27-8	25-1 i	21-11 i
1125S250-68	33	28-4	25-9	21-10 e	30-10 i	26-8 i	21-10 i	25-9	23-5	20-5 e	28-11 i	26-3 i	21-10 i
1125S250-68	50	28-4	25-9	22-6	31-10	28-11 i	24-3 i	25-9	23-5	20-5	28-11	26-3 i	22-11 i
1125S300-68	33	29-6	26-10	22-6 e	31-10 i	27-7 i	22-6 i	26-10	24-4	21-3 e	30-1 i	27-4 i	22-6 i
1125S300-68	50	29-6	26-9	23-5 e	33-1 i	30-1 i	25-7 i	26-9	24-4	21-3	30-1	27-4 i	23-10 i
1125S162-97	33	29-4	26-8	23-3	32-11	28-6	23-3	26-8	24-2	21-2	29-11	27-2	23-3
1125S162-97	50	29-4	26-8	23-3	32-11	29-11	26-2	26-8	24-2	21-2	29-11	27-2	23-9
1125S200-97	33	30-4	27-6	24-0	34-0	29-11	24-5	27-6	25-0	21-10	30-11	28-1	24-5
1125S200-97	50	30-4	27-6	24-0	34-0	30-11	27-0	27-6	25-0	21-10	30-11	28-1	24-6
1125S250-97	33	31-9	28-10	25-2	35-8	32-1	26-2 i	28-10	26-2	22-11	32-5	29-5	25-8 i
1125S250-97	50	31-9	28-10	25-2	35-8	32-5	28-3	28-10	26-2	22-11	32-5	29-5	25-8 i
1125S300-97	33	33-1	30-0	26-3	37-1	33-9	27-8 i	30-0	27-3	23-10	33-9	30-7	26-9 i
1125S300-97	50	33-1	30-0	26-3	37-1	33-9	29-5	30-0	27-3	23-10	33-9	30-7	26-9

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 40 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1200S137-33	33	12-0 e	9-0 e	6-0 e	9-7 a	7-2 a	4-9 a	12-0 e	9-0 e	6-0 e	9-7 a	7-2 a	4-9 a
1200S162-33	33	12-0 e	9-0 e	6-0 e	9-7 a	7-2 a	4-9 a	12-0 e	9-0 e	6-0 e	9-7 a	7-2 a	4-9 a
1200S200-33	33	12-0 e	9-0 e	6-0 e	9-7 a	7-2 a	4-9 a	12-0 e	9-0 e	6-0 e	9-7 a	7-2 a	4-9 a
1200S137-43	33	19-8 e	17-1 e	13-4 e	19-8 a	16-0 a	10-8 a	19-8 e	17-1 e	13-4 e	19-8 a	16-0 a	10-8 a
1200S162-43	33	20-11 e	18-2 e	13-4 e	20-11 a	16-0 a	10-8 a	20-11 e	18-2 e	13-4 e	20-11 a	16-0 a	10-8 a
1200S200-43	33	20-9 e	17-11 e	13-4 e	20-9 a	16-0 a	10-8 a	20-9 e	17-11 e	13-4 e	20-9 a	16-0 a	10-8 a
1200S250-43	33	22-5 e	19-5 e	13-4 e	21-4 a	16-0 a	10-8 a	22-5 e	19-5 e	13-4 e	21-4 a	16-0 a	10-8 a
1200S300-43	33	23-9 e	20-0 e	13-4 e	21-4 a	16-0 a	10-8 a	23-9 e	20-0 e	13-4 e	21-4 a	16-0 a	10-8 a
1200S137-54	33	23-5 e	20-3 e	16-7 e	23-5 i	20-3 i	16-7 a	22-8 e	20-3 e	16-7 e	23-5 i	20-3 i	16-7 a
1200S137-54	50	24-11	22-8 e	18-11 e	26-9 i	23-2 i	18-11 a	22-8	20-7 e	18-0 e	25-5 i	23-1 i	18-11 a
1200S162-54	33	24-9 e	21-5 e	17-6 e	24-9 i	21-5 a	17-6 a	23-5 e	21-3 e	17-6 e	24-9 i	21-5 a	17-6 a
1200S162-54	50	25-9	23-5 e	20-1 e	28-5 i	24-7 i	20-1 a	23-5	21-3 e	18-7 e	26-3 i	23-10 i	20-1 a
1200S200-54	33	25-6 e	22-1 e	18-0 e	25-6 i	22-1 a	18-0 a	24-1 e	21-11 e	18-0 e	25-6 i	22-1 a	18-0 a
1200S200-54	50	26-7 e	24-1 e	19-9 e	28-0 i	24-2 i	19-9 a	24-1	21-11 e	19-2 e	27-1 i	24-2 i	19-9 a
1200S250-54	33	26-6 e	22-11 e	18-9 e	26-6 i	22-11 a	18-9 a	25-3 e	22-11 e	18-9 e	26-6 i	22-11 a	18-9 a
1200S250-54	50	27-9 e	25-3 e	21-1 e	29-10 i	25-10 i	21-1 a	25-3	22-11 e	20-0 e	28-4 i	25-9 i	21-1 a
1200S300-54	33	27-11 e	24-2 e	19-9 e	27-11 a	24-2 a	19-9 a	26-2 e	23-10 e	19-9 e	27-11 a	24-2 a	19-9 a
1200S300-54	50	28-9 e	26-2 e	22-2 e	31-4 i	27-2 a	21-2 a	26-2 e	23-9 e	20-9 e	29-4 i	26-8 a	21-2 a
1200S137-68	33	26-10	24-2	19-8 e	27-11 i	24-2 i	19-8 i	24-4	22-2	19-4 e	27-4 i	24-2 i	19-8 i
1200S137-68	50	26-10	24-4	21-3	30-2	27-4 i	22-11 i	24-4	22-2	19-4	27-4	24-10 i	21-9 i
1200S162-68	33	27-9	25-2	20-8 e	29-3 i	25-4 i	20-8 i	25-2	22-10	20-0 e	28-3 i	25-4 i	20-8 i
1200S162-68	50	27-9	25-2	22-0	31-1	28-3 i	24-3 i	25-2	22-10	20-0	28-3	25-8 i	22-5 i
1200S200-68	33	28-7	26-0	21-8 e	30-7 i	26-6 i	21-8 i	26-0	23-7	20-7 e	29-2 i	26-6 i	21-8 i
1200S200-68	50	28-7	26-0	22-8 e	32-1	29-2 i	24-8 i	26-0	23-7	20-7	29-2	26-6 i	23-2 i
1200S250-68	33	29-11	27-2 e	22-10 e	32-4 i	28-0 i	22-10 i	27-2	24-8	21-7 e	30-6 i	27-8 i	22-10 i
1200S250-68	50	29-11	27-2	23-9 e	33-7 i	30-6 i	25-0 i	27-2	24-8	21-7	30-6	27-8 i	24-2 i
1200S300-68	33	31-1	28-3 e	23-6 e	33-3 i	28-9 i	23-6 i	28-3	25-8	22-5 e	31-8 i	28-9 i	23-6 i
1200S300-68	50	31-1	28-3	24-8 e	34-11 i	31-8 i	26-5 i	28-3	25-8	22-5	31-8	28-10 i	25-2 i
1200S162-97	33	31-0	28-2	24-5	34-7	30-0	24-5	28-2	25-7	22-4	31-7	28-9	24-5
1200S162-97	50	31-0	28-2	24-7	34-10	31-7	27-7	28-2	25-7	22-4	31-7	28-9	25-1
1200S200-97	33	32-0	29-1	25-4	35-11	31-5	25-8 i	29-1	26-5	23-1	32-7	29-8	25-8 i
1200S200-97	50	32-0	29-1	25-4	35-11	32-7	28-6	29-1	26-5	23-1	32-7	29-8	25-11
1200S250-97	33	33-5	30-5	26-6	37-7	33-7	27-5 i	30-5	27-7	24-1	34-1	31-0	27-1 i
1200S250-97	50	33-5	30-5	26-6	37-7	34-1	29-10	30-5	27-7	24-1	34-1	31-0	27-1
1200S300-97	33	34-10	31-7	27-7	39-1	35-6	28-11 i	31-7	28-9	25-1	35-6	32-3	28-2 i
1200S300-97	50	34-10	31-7	27-7	39-1	35-6	31-0	31-7	28-9	25-1	35-6	32-3	28-2

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 40 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1400S137-33	33	10-3 e	7-8 e	5-1 e	8-2 a	6-2 a	4-1 a	10-3 e	7-8 e	5-1 e	8-2 a	6-2 a	4-1 a
1400S162-33	33	10-3 e	7-8 e	5-1 e	8-2 a	6-2 a	4-1 a	10-3 e	7-8 e	5-1 e	8-2 a	6-2 a	4-1 a
1400S200-33	33	10-3 e	7-8 e	5-1 e	8-2 a	6-2 a	4-1 a	10-3 e	7-8 e	5-1 e	8-2 a	6-2 a	4-1 a
1400S137-43	33	21-2 e	17-1 e	11-4 e	18-3 a	13-8 a	9-1 a	21-2 e	17-1 e	11-4 e	18-3 a	13-8 a	9-1 a
1400S162-43	33	22-6 e	17-1 e	11-4 e	18-3 a	13-8 a	9-1 a	22-6 e	17-1 e	11-4 e	18-3 a	13-8 a	9-1 a
1400S200-43	33	22-4 e	17-1 e	11-4 e	18-3 a	13-8 a	9-1 a	22-4 e	17-1 e	11-4 e	18-3 a	13-8 a	9-1 a
1400S250-43	33	22-9 e	17-1 e	11-4 e	18-3 a	13-8 a	9-1 a	22-9 e	17-1 e	11-4 e	18-3 a	13-8 a	9-1 a
1400S300-43	33	22-9 e	17-1 e	11-4 e	18-3 a	13-8 a	9-1 a	22-9 e	17-1 e	11-4 e	18-3 a	13-8 a	9-1 a
1400S137-54	33	25-1 e	21-8 e	17-8 e	25-1 a	21-8 a	17-8 a	25-1 e	21-8 e	17-8 e	25-1 a	21-8 a	17-8 a
1400S137-54	50	27-9 e	24-11 e	20-4 e	28-9 i	24-11 a	18-0 a	25-3 e	22-11 e	20-0 e	28-4 i	24-11 a	18-0 a
1400S162-54	33	26-6 e	22-11 e	18-9 e	26-6 a	22-11 a	18-0 a	26-6 e	22-11 e	18-9 e	26-6 a	22-11 a	18-0 a
1400S162-54	50	28-8 e	26-0 e	21-7 e	30-7 i	26-5 a	18-0 a	26-0 e	23-8 e	20-8 e	29-3 i	26-5 a	18-0 a
1400S200-54	33	27-4 e	23-8 e	19-4 e	27-4 a	23-8 a	18-0 a	27-4 e	23-8 e	19-4 e	27-4 a	23-8 a	18-0 a
1400S200-54	50	29-10 e	26-1 e	21-3 e	30-2 i	26-1 a	18-0 a	27-2 e	24-8 e	21-3 e	30-2 i	26-1 a	18-0 a
1400S250-54	33	28-6 e	24-8 e	20-1 e	28-6 a	24-8 a	18-0 a	28-6 e	24-8 e	20-1 e	28-6 a	24-8 a	18-0 a
1400S250-54	50	31-2 e	27-10 e	22-7 e	32-2 a	27-1 a	18-0 a	28-4 e	25-9 e	22-6 e	31-10 a	27-1 a	18-0 a
1400S300-54	33	30-1 e	26-0 e	21-3 e	30-1 a	26-0 a	18-0 a	29-8 e	26-0 e	21-3 e	30-1 a	26-0 a	18-0 a
1400S300-54	50	32-5 e	29-4 e	22-7 e	33-10 a	27-1 a	18-0 a	29-5 e	26-9 e	22-7 e	33-0 a	27-1 a	18-0 a
1400S137-68	33	30-3	26-2 e	21-5 e	30-3 i	26-2 i	21-5 i	27-10	25-4 e	21-5 e	30-3 i	26-2 i	21-5 i
1400S137-68	50	30-8	27-10	24-4 e	34-5 i	30-1 i	24-6 i	27-10	25-4	22-1 e	31-4 i	28-5 i	24-6 i
1400S162-68	33	31-7	27-6 e	22-6 e	31-9 i	27-6 i	22-6 e	28-9	26-1 e	22-6 e	31-9 i	27-6 i	22-6 e
1400S162-68	50	31-7	28-9	25-1 e	35-6 i	31-9 i	25-11 i	28-9	26-1	22-9 e	32-3 i	29-4 i	25-7 i
1400S200-68	33	32-6	28-9 e	23-6 e	33-3 i	28-9 i	23-6 a	29-7	26-10 e	23-5 e	33-2 i	28-9 i	23-6 a
1400S200-68	50	32-6	29-7	25-10 e	36-6 i	32-5 i	26-5 i	29-7	26-10	23-5 e	33-2 i	30-2 i	26-4 i
1400S250-68	33	33-11 e	30-2 e	24-8 e	34-10 i	30-2 i	24-8 a	30-10	28-0 e	24-5 e	34-7 i	30-2 i	24-8 a
1400S250-68	50	33-11	30-10	26-10 e	38-0 i	32-10 i	26-10 i	30-10	28-0	24-5 e	34-7 i	31-5 i	26-10 i
1400S300-68	33	35-2 e	30-10 e	25-2 e	35-7 i	30-10 i	25-2 a	32-0	29-0 e	25-2 e	35-7 i	30-10 i	25-2 a
1400S300-68	50	35-2	32-0 e	27-11 e	39-6 i	34-10 i	28-5 a	32-0	29-0	25-4 e	35-11 i	32-7 i	28-5 a
1400S162-97	33	35-4	32-2	27-7	39-1	33-10	27-7 i	32-2	29-2	25-6	36-1	32-9	27-7 i
1400S162-97	50	35-4	32-2	28-1	39-9	36-1	31-6	32-2	29-2	25-6	36-1	32-9	28-7
1400S200-97	33	36-5	33-1	28-10	40-10	35-4	28-10 i	33-1	30-1	26-3	37-2	33-9	28-10 i
1400S200-97	50	36-5	33-1	28-11	40-11	37-2	32-5	33-1	30-1	26-3	37-2	33-9	29-6
1400S250-97	33	38-0	34-6	30-2	42-8	37-8 i	30-9 i	34-6	31-4	27-4	38-9	35-2	30-9 i
1400S250-97	50	38-0	34-6	30-2	42-8	38-9	33-10 i	34-6	31-4	27-4	38-9	35-2	30-9
1400S300-97	33	39-5	35-10	31-3	44-3	39-7 i	32-4 i	35-10	32-6	28-5	40-2	36-6 i	31-11 i
1400S300-97	50	39-5	35-10	31-3	44-3	40-2	35-1 i	35-10	32-6	28-5	40-2	36-6	31-11

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 50 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
600S137-33	33	10-6 e	9-1 e	7-5 e	10-6 a	9-1 a	7-5 a	10-1 e	9-1 e	7-5 e	10-6 a	9-1 a	7-5 a
600S162-33	33	11-2 e	9-8 e	7-10 e	11-2 a	9-8 a	7-10 a	10-6 e	9-6 e	7-10 e	11-2 a	9-8 a	7-10 a
600S200-33	33	11-4 e	9-9 e	8-0 e	11-4 a	9-9 a	8-0 a	10-11 e	9-9 e	8-0 e	11-4 a	9-9 a	8-0 a
600S137-43	33	12-1	10-6 e	8-7 e	12-2 i	10-6 i	8-7 i	10-11	9-11	8-7 e	12-2 i	10-6 i	8-7 i
600S162-43	33	12-7	11-2 e	9-2 e	12-11 i	11-2 i	9-2 i	11-5	10-5 e	9-1 e	12-10 i	11-2 i	9-2 i
600S200-43	33	13-0	11-3 e	9-2 e	13-0 i	11-3 i	9-2 a	11-11	10-10 e	9-2 e	13-0 i	11-3 i	9-2 a
600S250-43	33	13-10 e	12-2 e	9-11 e	14-1 i	12-2 i	9-11 a	12-7	11-5 e	9-11 e	14-1 i	12-2 i	9-11 a
600S300-43	33	14-5 e	12-11 e	10-6 e	14-11 i	12-11 i	10-6 a	13-1	11-11 e	10-5 e	14-9 i	12-11 i	10-6 a
600S137-54	33	12-11	11-8	9-7	13-6	11-8 i	9-7 i	11-9	10-8	9-4	13-3	11-8 i	9-7 i
600S137-54	50	12-11	11-9	10-3	14-7	13-3	11-6 i	11-9	10-8	9-4	13-3	12-0	10-6 i
600S162-54	33	13-6	12-3	10-2	14-5	12-6 i	10-2 i	12-3	11-2	9-9	13-9	12-6 i	10-2 i
600S162-54	50	13-6	12-3	10-9	15-2	13-9	12-1 i	12-3	11-2	9-9	13-9	12-6	10-11 i
600S200-54	33	14-1	12-10	10-8	15-1 i	13-1 i	10-8 i	12-10	11-7	10-2	14-4	13-1 i	10-8 i
600S200-54	50	14-1	12-10	11-2	15-10	14-4	12-4 i	12-10	11-7	10-2	14-4	13-1	11-5 i
600S250-54	33	14-11	13-6	11-3	15-11 i	13-9 i	11-3 i	13-6	12-3	10-9	15-2 i	13-9 i	11-3 i
600S250-54	50	14-10	13-5	11-9	16-8	15-1 i	13-2 i	13-5	12-3	10-8	15-1	13-9	12-0 i
600S300-54	33	15-7	14-2	11-11 e	16-10 i	14-7 i	11-11 i	14-2	12-11	11-3	15-11 i	14-6 i	11-11 i
600S300-54	50	15-5	14-0	12-3	17-4	15-9 i	13-9 i	14-0	12-9	11-1	15-9	14-3	12-6 i
600S137-68	33	13-11	12-8	10-7	15-1	13-0	10-7	12-8	11-6	10-0	14-2	12-11	10-7
600S137-68	50	13-11	12-8	11-0	15-8	14-2	12-5	12-8	11-6	10-0	14-2	12-11	11-3
600S162-68	33	14-6	13-2	11-4	16-1	13-11	11-4	13-2	12-0	10-6	14-10	13-6	11-4
600S162-68	50	14-6	13-2	11-6	16-4	14-10	12-11	13-2	12-0	10-6	14-10	13-6	11-9
600S200-68	33	15-2	13-9	12-0	17-0	14-9	12-1 i	13-9	12-6	10-11	15-5	14-0	12-1 i
600S200-68	50	15-2	13-9	12-0	17-0	15-5	13-6	13-9	12-6	10-11	15-5	14-0	12-3
600S250-68	33	16-0	14-7	12-8	18-0	15-10	12-11 i	14-7	13-3	11-7	16-4	14-10	12-11 i
600S250-68	50	16-0	14-7	12-8	18-0	16-4	14-3	14-7	13-3	11-7	16-4	14-10	13-0
600S300-68	33	16-10	15-3	13-4	18-10	16-5	13-5 i	15-3	13-10	12-1	17-2	15-7	13-5 i
600S300-68	50	16-9	15-2	13-3	18-10	17-1	14-11	15-2	13-10	12-1	17-1	15-6	13-7
600S162-97	33	16-2	14-8	12-10	18-2	16-4	13-4	14-8	13-4	11-8	16-6	15-0	13-1
600S162-97	50	16-2	14-8	12-10	18-2	16-6	14-5	14-8	13-4	11-8	16-6	15-0	13-1
600S200-97	33	16-11	15-4	13-5	19-0	17-3	14-3	15-4	13-11	12-2	17-3	15-8	13-8
600S200-97	50	16-11	15-4	13-5	19-0	17-3	15-1	15-4	13-11	12-2	17-3	15-8	13-8
600S250-97	33	17-11	16-3	14-2	20-1	18-3	15-6	16-3	14-9	12-11	18-3	16-7	14-6
600S250-97	50	17-11	16-3	14-2	20-1	18-3	15-11	16-3	14-9	12-11	18-3	16-7	14-6
600S300-97	33	18-9	17-1	14-11	21-1	19-2	16-7	17-1	15-6	13-6	19-2	17-5	15-2
600S300-97	50	18-9	17-1	14-11	21-1	19-2	16-9	17-1	15-6	13-6	19-2	17-5	15-2

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 50 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
800S137-33	33	12-0 e	10-5 e	7-7 e	12-0 a	9-1 a	6-1 a	12-0 e	10-5 e	7-7 e	12-0 a	9-1 a	6-1 a
800S162-33	33	12-9 e	11-1 e	7-7 e	12-2 a	9-1 a	6-1 a	12-9 e	11-1 e	7-7 e	12-2 a	9-1 a	6-1 a
800S200-33	33	12-11 e	11-2 e	7-7 e	12-2 a	9-1 a	6-1 a	12-11 e	11-2 e	7-7 e	12-2 a	9-1 a	6-1 a
800S137-43	33	15-0 e	13-0 e	10-7 e	15-0 i	13-0 a	10-7 a	13-10 e	12-7 e	10-7 e	15-0 i	13-0 a	10-7 a
800S162-43	33	15-10 e	13-9 e	11-2 e	15-10 i	13-9 a	11-2 a	14-5 e	13-1 e	11-2 e	15-10 i	13-9 a	11-2 a
800S200-43	33	15-8 e	13-7 e	11-1 e	15-8 i	13-7 a	11-1 a	14-11 e	13-7 e	11-1 e	15-8 i	13-7 a	11-1 a
800S250-43	33	16-10 e	14-7 e	11-11 e	16-10 a	14-7 a	11-11 a	15-9 e	14-3 e	11-11 e	16-10 a	14-7 a	11-11 a
800S300-43	33	17-10 e	15-5 e	12-7 e	17-10 a	15-5 a	12-7 a	16-4 e	14-10 e	12-7 e	17-10 a	15-5 a	12-7 a
800S137-54	33	16-5	14-5	11-9 e	16-8 i	14-5 i	11-9 i	14-11	13-6	11-9 e	16-8 i	14-5 i	11-9 i
800S137-54	50	16-5	14-11	13-0	18-5	16-9 i	14-4 i	14-11	13-6	11-10	16-9	15-2 i	13-3 i
800S162-54	33	17-1	15-4	12-6 e	17-8 i	15-4 i	12-6 i	15-6	14-1	12-3 e	17-5 i	15-4 i	12-6 i
800S162-54	50	17-1	15-6	13-6 e	19-2 i	17-5 i	15-2 i	15-6	14-1	12-3	17-5	15-10 i	13-10 i
800S200-54	33	17-8	15-11 e	13-0 e	18-5 i	15-11 i	13-0 i	16-1	14-7	12-9 e	18-1 i	15-11 i	13-0 i
800S200-54	50	17-8	16-1	14-1 e	19-11 i	18-1 i	14-11 i	16-1	14-7	12-9	18-1	16-5 i	14-4 i
800S250-54	33	18-8	16-9 e	13-8 e	19-4 i	16-9 i	13-8 i	16-11	15-4	13-5 e	19-0 i	16-9 i	13-8 i
800S250-54	50	18-7	16-10	14-9 e	20-10 i	18-11 i	15-11 i	16-10	15-4	13-4 e	18-11 i	17-2 i	15-0 i
800S300-54	33	19-6	17-8 e	14-5 e	20-5 i	17-8 i	14-5 a	17-8	16-1 e	14-0 e	19-10 i	17-8 i	14-5 a
800S300-54	50	19-3	17-6	15-3 e	21-8 i	19-8 i	16-7 i	17-6	15-11	13-11 e	19-8 i	17-10 i	15-7 i
800S137-68	33	17-8	16-0	13-2	18-7	16-1	13-2 i	16-0	14-7	12-9	18-0	16-1	13-2 i
800S137-68	50	17-8	16-0	14-0	19-10	18-0	15-9 i	16-0	14-7	12-9	18-0	16-4	14-3
800S162-68	33	18-4	16-8	13-11	19-9	17-1 i	13-11 i	16-8	15-2	13-3	18-9	17-0 i	13-11 i
800S162-68	50	18-4	16-8	14-7	20-7	18-9	16-4 i	16-8	15-2	13-3	18-9	17-0	14-10 i
800S200-68	33	19-1	17-4	14-9	20-10	18-0 i	14-9 i	17-4	15-9	13-9	19-5	17-8 i	14-9 i
800S200-68	50	19-1	17-4	15-1	21-5	19-5	17-0 i	17-4	15-9	13-9	19-5	17-8	15-5 i
800S250-68	33	20-1	18-3	15-8	22-2 i	19-2 i	15-8 i	18-3	16-7	14-5	20-6	18-7 i	15-8 i
800S250-68	50	20-1	18-3	15-11	22-6	20-6	17-10 i	18-3	16-7	14-5	20-6	18-7	16-3 i
800S300-68	33	21-0	19-1	16-2	22-11 i	19-10 i	16-2 i	19-1	17-4	15-1	21-5	19-5 i	16-2 i
800S300-68	50	20-11	19-0	16-7	23-5	21-4	18-7 i	19-0	17-3	15-1	21-4	19-4	16-11 i
800S162-97	33	20-6	18-7	16-3	23-0	20-1	16-5	18-7	16-11	14-9	20-11	19-0	16-5
800S162-97	50	20-6	18-7	16-3	23-0	20-11	18-3	18-7	16-11	14-9	20-11	19-0	16-7
800S200-97	33	21-3	19-4	16-10	23-11	21-4	17-5	19-4	17-7	15-4	21-8	19-8	17-3
800S200-97	50	21-3	19-4	16-10	23-11	21-8	18-11	19-4	17-7	15-4	21-8	19-8	17-3
800S250-97	33	22-5	20-4	17-9	25-2	22-10	18-10	20-4	18-6	16-2	22-10	20-9	18-2
800S250-97	50	22-5	20-4	17-9	25-2	22-10	20-0	20-4	18-6	16-2	22-10	20-9	18-2
800S300-97	33	23-5	21-4	18-7	26-4	23-11	20-0	21-4	19-4	16-11	23-11	21-9	19-0
800S300-97	50	23-5	21-4	18-7	26-4	23-11	20-11	21-4	19-4	16-11	23-11	21-9	19-0

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 50 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
925S137-33	33	12-11 e	9-9 e	6-6 e	10-5 a	7-10 a	5-2 a	12-11 e	9-9 e	6-6 e	10-5 a	7-10 a	5-2 a
925S162-33	33	13-1 e	9-9 e	6-6 e	10-5 a	7-10 a	5-2 a	13-1 e	9-9 e	6-6 e	10-5 a	7-10 a	5-2 a
925S200-33	33	13-1 e	9-9 e	6-6 e	10-5 a	7-10 a	5-2 a	13-1 e	9-9 e	6-6 e	10-5 a	7-10 a	5-2 a
925S137-43	33	16-0 e	13-10 e	11-4 e	16-0 a	13-10 a	11-4 a	15-8 e	13-10 e	11-4 e	16-0 a	13-10 a	11-4 a
925S162-43	33	17-0 e	14-8 e	12-0 e	17-0 a	14-8 a	11-7 a	16-3 e	14-8 e	12-0 e	17-0 a	14-8 a	11-7 a
925S200-43	33	16-9 e	14-6 e	11-10 e	16-9 a	14-6 a	11-7 a	16-9 e	14-6 e	11-10 e	16-9 a	14-6 a	11-7 a
925S250-43	33	18-1 e	15-8 e	12-9 e	18-1 a	15-8 a	11-7 a	17-8 e	15-8 e	12-9 e	18-1 a	15-8 a	11-7 a
925S300-43	33	19-1 e	16-6 e	13-6 e	19-1 a	16-6 a	11-7 a	18-4 e	16-6 e	13-6 e	19-1 a	16-6 a	11-7 a
925S137-54	33	18-6	16-1 e	13-2 e	18-7 i	16-1 i	13-2 a	16-10	15-4 e	13-2 e	18-7 i	16-1 i	13-2 a
925S137-54	50	18-6	16-10	14-8 e	20-10 i	18-10 i	15-4 i	16-10	15-4	13-4 e	18-11 i	17-2 i	15-0 i
925S162-54	33	19-3	17-0 e	13-11 e	19-8 i	17-0 i	13-11 a	17-6	15-10 e	13-10 e	19-7 i	17-0 i	13-11 a
925S162-54	50	19-3	17-6	15-3 e	21-7 i	19-7 i	16-3 i	17-6	15-10	13-10 e	19-7 i	17-10 i	15-7 i
925S200-54	33	19-11 e	17-8 e	14-5 e	20-5 i	17-8 i	14-5 a	18-1	16-5 e	14-4 e	20-4 i	17-8 i	14-5 a
925S200-54	50	19-11	18-1	15-9 e	22-4 i	19-7 i	15-11 i	18-1	16-5	14-4 e	20-4 i	18-5 i	15-11 i
925S250-54	33	20-11 e	18-6 e	15-1 e	21-5 i	18-6 i	15-1 a	19-0	17-3 e	15-1 e	21-4 i	18-6 i	15-1 a
925S250-54	50	20-10	18-11 e	16-7 e	23-5 i	20-10 i	17-0 a	18-11	17-3	15-0 e	21-3 i	19-4 i	16-11 a
925S300-54	33	21-10 e	19-6 e	15-11 e	22-7 i	19-6 i	15-11 a	19-10 e	18-0 e	15-9 e	22-3 i	19-6 i	15-11 a
925S300-54	50	21-8	19-8 e	17-2 e	24-3 i	21-10 i	17-10 a	19-8	17-10	15-7 e	22-1 i	20-1 i	17-6 a
925S137-68	33	19-11	18-0	14-8	20-9	18-0 i	14-8 i	18-1	16-5	14-4	20-4	18-0 i	14-8 i
925S137-68	50	19-11	18-1	15-10	22-5	20-4	17-9 i	18-1	16-5	14-4	20-4	18-6	16-2 i
925S162-68	33	20-8	18-9	15-6	21-11 i	19-0 i	15-6 i	18-9	17-1	14-11	21-1	19-0 i	15-6 i
925S162-68	50	20-8	18-9	16-5	23-3	21-1	18-5 i	18-9	17-1	14-11	21-1	19-2	16-9 i
925S200-68	33	21-5	19-5	16-4	23-1 i	20-0 i	16-4 i	19-5	17-8	15-5	21-10 i	19-10 i	16-4 i
925S200-68	50	21-5	19-5	17-0	24-1	21-10 i	19-1 i	19-5	17-8	15-5	21-10	19-10	17-4 i
925S250-68	33	22-6	20-5	17-4 e	24-6 i	21-3 i	17-4 i	20-5	18-7	16-3	22-11 i	20-10 i	17-4 i
925S250-68	50	22-6	20-5	17-10	25-3	22-11 i	20-1 i	20-5	18-7	16-3	22-11	20-10	18-3 i
925S300-68	33	23-6	21-4	17-11 e	25-4 i	21-11 i	17-11 i	21-4	19-4	16-11 e	23-11 i	21-9 i	17-11 i
925S300-68	50	23-5	21-3	18-7	26-3	23-10 i	20-10 i	21-3	19-3	16-10	23-10	21-8 i	18-11 i
925S162-97	33	23-1	21-0	18-4	25-11	22-5	18-4	21-0	19-1	16-8	23-7	21-5	18-4
925S162-97	50	23-1	21-0	18-4	25-11	23-7	20-7	21-0	19-1	16-8	23-7	21-5	18-8
925S200-97	33	23-11	21-9	19-0	26-10	23-8	19-4	21-9	19-9	17-3	24-5	22-2	19-4
925S200-97	50	23-11	21-9	19-0	26-10	24-5	21-4	21-9	19-9	17-3	24-5	22-2	19-4
925S250-97	33	25-2	22-10	20-0	28-3	25-6	20-10	22-10	20-9	18-2	25-8	23-4	20-4
925S250-97	50	25-2	22-10	20-0	28-3	25-8	22-5	22-10	20-9	18-2	25-8	23-4	20-4
925S300-97	33	26-3	23-10	20-10	29-6	26-10	22-1 i	23-10	21-8	18-11	26-10	24-4	21-3
925S300-97	50	26-3	23-10	20-10	29-6	26-10	23-5	23-10	21-8	18-11	26-10	24-4	21-3

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 50 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1000S137-33	33	12-1 e	9-0 e	6-0 e	9-8 a	7-3 a	4-10 a	12-1 e	9-0 e	6-0 e	9-8 a	7-3 a	4-10 a
1000S162-33	33	12-1 e	9-0 e	6-0 e	9-8 a	7-3 a	4-10 a	12-1 e	9-0 e	6-0 e	9-8 a	7-3 a	4-10 a
1000S200-33	33	12-1 e	9-0 e	6-0 e	9-8 a	7-3 a	4-10 a	12-1 e	9-0 e	6-0 e	9-8 a	7-3 a	4-10 a
1000S137-43	33	16-7 e	14-4 e	11-8 e	16-7 a	14-4 a	10-8 a	16-7 e	14-4 e	11-8 e	16-7 a	14-4 a	10-8 a
1000S162-43	33	17-7 e	15-3 e	12-5 e	17-7 a	15-3 a	10-8 a	17-4 e	15-3 e	12-5 e	17-7 a	15-3 a	10-8 a
1000S200-43	33	17-4 e	15-0 e	12-3 e	17-4 a	15-0 a	10-8 a	17-4 e	15-0 e	12-3 e	17-4 a	15-0 a	10-8 a
1000S250-43	33	18-9 e	16-3 e	13-3 e	18-9 a	16-1 a	10-8 a	18-9 e	16-3 e	13-3 e	18-9 a	16-1 a	10-8 a
1000S300-43	33	19-10 e	17-2 e	13-5 e	19-10 a	16-1 a	10-8 a	19-6 e	17-2 e	13-5 e	19-10 a	16-1 a	10-8 a
1000S137-54	33	19-9 e	17-1 e	14-0 e	19-9 i	17-1 i	14-0 a	18-0	16-4 e	14-0 e	19-9 i	17-1 i	14-0 a
1000S137-54	50	19-10	18-0 e	15-8 e	22-3 i	19-6 i	15-11 i	18-0	16-4	14-3 e	20-2 i	18-4 i	15-11 i
1000S162-54	33	20-6 e	18-0 e	14-9 e	20-10 i	18-0 i	14-9 a	18-8	16-11 e	14-9 e	20-10 i	18-0 i	14-9 a
1000S162-54	50	20-6	18-8 e	16-3 e	23-0 i	20-8 i	16-10 a	18-8	16-11	14-9 e	20-11 i	19-0 i	16-7 a
1000S200-54	33	21-2 e	18-8 e	15-3 e	21-7 i	18-8 i	15-3 a	19-3 e	17-6 e	15-3 e	21-7 i	18-8 i	15-3 a
1000S200-54	50	21-2	19-3 e	16-6 e	23-5 i	20-3 i	16-6 a	19-3	17-6	15-3 e	21-8 i	19-8 i	16-6 a
1000S250-54	33	22-3 e	19-4 e	15-9 e	22-4 i	19-4 a	15-9 a	20-2 e	18-4 e	15-9 e	22-4 i	19-4 a	15-9 a
1000S250-54	50	22-3	20-2 e	17-8 e	24-11 i	21-7 i	17-8 a	20-2	18-4 e	16-0 e	22-8 i	20-7 i	17-8 a
1000S300-54	33	23-2 e	20-4 e	16-7 e	23-5 i	20-4 a	16-7 a	21-1 e	19-1 e	16-7 e	23-5 i	20-4 a	16-7 a
1000S300-54	50	23-0	20-11 e	18-3 e	25-10 i	22-8 i	18-6 a	20-11	19-0 e	16-7 e	23-6 i	21-4 i	18-6 a
1000S137-68	33	21-4	19-1	15-7	22-1 i	19-1 i	15-7 i	19-4	17-7	15-4	21-9 i	19-1 i	15-7 i
1000S137-68	50	21-4	19-4	16-11	23-11	21-9 i	19-0 i	19-4	17-7	15-4	21-9	19-9	17-3 i
1000S162-68	33	22-1	20-1	16-5 e	23-3 i	20-2 i	16-5 i	20-1	18-3	15-11	22-6 i	20-2 i	16-5 i
1000S162-68	50	22-1	20-1	17-6	24-9	22-6 i	19-8 i	20-1	18-3	15-11	22-6	20-5	17-10 i
1000S200-68	33	22-10	20-9	17-3 e	24-5 i	21-2 i	17-3 i	20-9	18-10	16-5 e	23-3 i	21-2 i	17-3 i
1000S200-68	50	22-10	20-9	18-1	25-8	23-3 i	20-4 i	20-9	18-10	16-5	23-3	21-2	18-6 i
1000S250-68	33	23-11	21-9	18-4 e	25-11 i	22-5 i	18-4 i	21-9	19-9	17-3 e	24-5 i	22-2 i	18-4 i
1000S250-68	50	23-11	21-9	19-0	26-11	24-5 i	21-0 i	21-9	19-9	17-3	24-5	22-2 i	19-5 i
1000S300-68	33	25-0	22-8	18-11 e	26-9 i	23-2 i	18-11 i	22-8	20-7	18-0 e	25-6 i	23-2 i	18-11 i
1000S300-68	50	24-11	22-7	19-9	27-11	25-5 i	22-2 i	22-7	20-6	17-11	25-5	23-1 i	20-2 i
1000S162-97	33	24-8	22-5	19-5	27-6	23-9	19-5	22-5	20-4	17-9	25-2	22-10	19-5
1000S162-97	50	24-8	22-5	19-7	27-8	25-2	22-0	22-5	20-4	17-9	25-2	22-10	19-11
1000S200-97	33	25-6	23-2	20-3	28-8	25-0	20-5	23-2	21-1	18-5	26-0	23-8	20-5
1000S200-97	50	25-6	23-2	20-3	28-8	26-0	22-9	23-2	21-1	18-5	26-0	23-8	20-8
1000S250-97	33	26-9	24-4	21-3	30-1	26-11	22-0 i	24-4	22-1	19-4	27-4	24-10	21-8 i
1000S250-97	50	26-9	24-4	21-3	30-1	27-4	23-10	24-4	22-1	19-4	27-4	24-10	21-8
1000S300-97	33	27-11	25-5	22-2	31-4	28-6	23-3 i	25-5	23-1	20-2	28-6	25-11	22-7 i
1000S300-97	50	27-11	25-5	22-2	31-4	28-6	24-11	25-5	23-1	20-2	28-6	25-11	22-7

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 50 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1125S137-33	33	10-8 e	8-0 e	5-4 e	8-6 a	6-5 a	4-3 a	10-8 e	8-0 e	5-4 e	8-6 a	6-5 a	4-3 a
1125S162-33	33	10-8 e	8-0 e	5-4 e	8-6 a	6-5 a	4-3 a	10-8 e	8-0 e	5-4 e	8-6 a	6-5 a	4-3 a
1125S200-33	33	10-8 e	8-0 e	5-4 e	8-6 a	6-5 a	4-3 a	10-8 e	8-0 e	5-4 e	8-6 a	6-5 a	4-3 a
1125S137-43	33	17-5 e	15-1 e	11-10 e	17-5 a	14-3 a	9-6 a	17-5 e	15-1 e	11-10 e	17-5 a	14-3 a	9-6 a
1125S162-43	33	18-7 e	16-1 e	11-10 e	18-7 a	14-3 a	9-6 a	18-7 e	16-1 e	11-10 e	18-7 a	14-3 a	9-6 a
1125S200-43	33	18-4 e	15-11 e	11-10 e	18-4 a	14-3 a	9-6 a	18-4 e	15-11 e	11-10 e	18-4 a	14-3 a	9-6 a
1125S250-43	33	19-10 e	17-2 e	11-10 e	19-0 a	14-3 a	9-6 a	19-10 e	17-2 e	11-10 e	19-0 a	14-3 a	9-6 a
1125S300-43	33	21-0 e	17-10 e	11-10 e	19-0 a	14-3 a	9-6 a	21-0 e	17-10 e	11-10 e	19-0 a	14-3 a	9-6 a
1125S137-54	33	20-10 e	18-0 e	14-8 e	20-10 i	18-0 a	14-8 a	19-11 e	18-0 e	14-8 e	20-10 i	18-0 a	14-8 a
1125S137-54	50	21-11	19-11 e	16-9 e	23-8 i	20-6 i	16-9 a	19-11	18-1 e	15-9 e	22-4 i	20-3 i	16-9 a
1125S162-54	33	22-0 e	19-0 e	15-6 e	22-0 i	19-0 a	15-6 a	20-7 e	18-8 e	15-6 e	22-0 i	19-0 a	15-6 a
1125S162-54	50	22-8 e	20-7 e	17-9 e	25-2 i	21-9 i	17-9 a	20-7	18-8 e	16-4 e	23-1 i	21-0 i	17-9 a
1125S200-54	33	22-8 e	19-7 e	16-0 e	22-8 i	19-7 a	16-0 a	21-3 e	19-3 e	16-0 e	22-8 i	19-7 a	16-0 a
1125S200-54	50	23-4 e	21-3 e	17-6 e	24-9 i	21-5 i	17-6 a	21-3	19-3 e	16-10 e	23-10 i	21-5 i	17-6 a
1125S250-54	33	23-6 e	20-4 e	16-7 e	23-6 i	20-4 a	16-7 a	22-2 e	20-2 e	16-7 e	23-6 i	20-4 a	16-7 a
1125S250-54	50	24-5 e	22-2 e	18-8 e	26-5 i	22-10 a	18-8 a	22-2	20-2 e	17-7 e	24-11 i	22-8 a	18-8 a
1125S300-54	33	24-9 e	21-5 e	17-6 e	24-9 a	21-5 a	17-6 a	23-1 e	21-0 e	17-6 e	24-9 a	21-5 a	17-6 a
1125S300-54	50	25-4 e	23-0 e	19-7 e	27-9 i	24-0 a	18-10 a	23-0 e	20-10 e	18-3 e	25-10 i	23-5 a	18-10 a
1125S137-68	33	23-7	20-11	17-1 e	24-2 i	20-11 i	17-1 i	21-5	19-5	17-0 e	24-0 i	20-11 i	17-1 i
1125S137-68	50	23-7	21-5	18-8	26-5	24-0 i	20-5 i	21-5	19-5	17-0	24-0	21-10 i	19-1 i
1125S162-68	33	24-4	22-0	18-0 e	25-5 i	22-0 i	18-0 i	22-2	20-1	17-7 e	24-10 i	22-0 i	18-0 i
1125S162-68	50	24-4	22-2	19-4	27-4	24-10 i	21-6 i	22-2	20-1	17-7	24-10	22-7 i	19-9 i
1125S200-68	33	25-2	22-10	18-10 e	26-8 i	23-1 i	18-10 i	22-10	20-9	18-2 e	25-8 i	23-1 i	18-10 i
1125S200-68	50	25-2	22-10	19-11 e	28-3 i	25-8 i	21-11 i	22-10	20-9	18-2	25-8	23-4 i	20-4 i
1125S250-68	33	26-4	23-11 e	19-11 e	28-2 i	24-4 i	19-11 i	23-11	21-9	19-0 e	26-10 i	24-4 i	19-11 i
1125S250-68	50	26-4	23-11	20-11 e	29-7 i	26-10 i	22-2 i	23-11	21-9	19-0	26-10	24-5 i	21-4 i
1125S300-68	33	27-5	24-11 e	20-6 e	29-1 i	25-2 i	20-6 i	24-11	22-7	19-9 e	27-11 i	25-2 i	20-6 i
1125S300-68	50	27-4	24-10	21-9 e	30-9 i	27-11 i	23-5 i	24-10	22-7	19-9 e	27-11 i	25-4 i	22-2 i
1125S162-97	33	27-3	24-9	21-3	30-1	26-0	21-3 i	24-9	22-6	19-7	27-9	25-3	21-3 i
1125S162-97	50	27-3	24-9	21-7	30-7	27-9	24-3	24-9	22-6	19-7	27-9	25-3	22-0
1125S200-97	33	28-1	25-7	22-4	31-7	27-4	22-4 i	25-7	23-3	20-3	28-8	26-1	22-4 i
1125S200-97	50	28-1	25-7	22-4	31-7	28-8	25-1	25-7	23-3	20-3	28-8	26-1	22-9
1125S250-97	33	29-6	26-9	23-4	33-1	29-3	23-11 i	26-9	24-4	21-3	30-1	27-4	23-10 i
1125S250-97	50	29-6	26-9	23-4	33-1	30-1	26-3	26-9	24-4	21-3	30-1	27-4	23-10
1125S300-97	33	30-8	27-10	24-4	34-5	30-11	25-3 i	27-10	25-4	22-1	31-4	28-5	24-10 i
1125S300-97	50	30-8	27-10	24-4	34-5	31-4	27-4	27-10	25-4	22-1	31-4	28-5	24-10

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 50 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span		Two Equal Spans			
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		Spacing (in.) o.c.			
		12	16	24	12	16	24	12	16	24	12	16	24
1200S137-33	33	10-0 e	7-6 e	5-0 e	8-0 a	6-0 a	4-0 a	10-0 e	7-6 e	5-0 e	8-0 a	6-0 a	4-0 a
1200S162-33	33	10-0 e	7-6 e	5-0 e	8-0 a	6-0 a	4-0 a	10-0 e	7-6 e	5-0 e	8-0 a	6-0 a	4-0 a
1200S200-33	33	10-0 e	7-6 e	5-0 e	8-0 a	6-0 a	4-0 a	10-0 e	7-6 e	5-0 e	8-0 a	6-0 a	4-0 a
1200S137-43	33	18-0 e	15-7 e	11-1 e	17-9 a	13-4 a	8-10 a	18-0 e	15-7 e	11-1 e	17-9 a	13-4 a	8-10 a
1200S162-43	33	19-1 e	16-7 e	11-1 e	17-9 a	13-4 a	8-10 a	19-1 e	16-7 e	11-1 e	17-9 a	13-4 a	8-10 a
1200S200-43	33	18-11 e	16-4 e	11-1 e	17-9 a	13-4 a	8-10 a	18-11 e	16-4 e	11-1 e	17-9 a	13-4 a	8-10 a
1200S250-43	33	20-5 e	16-8 e	11-1 e	17-9 a	13-4 a	8-10 a	20-5 e	16-8 e	11-1 e	17-9 a	13-4 a	8-10 a
1200S300-43	33	21-8 e	16-8 e	11-1 e	17-9 a	13-4 a	8-10 a	21-8 e	16-8 e	11-1 e	17-9 a	13-4 a	8-10 a
1200S137-54	33	21-5 e	18-6 e	15-1 e	21-5 i	18-6 a	15-1 a	21-0 e	18-6 e	15-1 e	21-5 i	18-6 a	15-1 a
1200S137-54	50	23-2 e	21-0 e	17-3 e	24-5 i	21-2 i	17-3 a	21-0 e	19-1 e	16-8 e	23-7 i	21-2 i	17-3 a
1200S162-54	33	22-7 e	19-7 e	16-0 e	22-7 i	19-7 a	16-0 a	21-9 e	19-7 e	16-0 e	22-7 i	19-7 a	16-0 a
1200S162-54	50	23-11 e	21-9 e	18-4 e	25-11 i	22-5 a	17-7 a	21-9 e	19-9 e	17-3 e	24-5 i	22-2 a	17-7 a
1200S200-54	33	23-3 e	20-2 e	16-5 e	23-3 a	20-2 a	16-5 a	22-5 e	20-2 e	16-5 e	23-3 a	20-2 a	16-5 a
1200S200-54	50	24-8 e	22-1 e	18-0 e	25-6 i	22-1 a	17-7 a	22-5 e	20-4 e	17-9 e	25-2 i	22-1 a	17-7 a
1200S250-54	33	24-2 e	20-11 e	17-1 e	24-2 a	20-11 a	17-1 a	23-5 e	20-11 e	17-1 e	24-2 a	20-11 a	17-1 a
1200S250-54	50	25-9 e	23-5 e	19-3 e	27-3 i	23-7 a	17-7 a	23-5 e	21-3 e	18-7 e	26-3 i	23-7 a	17-7 a
1200S300-54	33	25-6 e	22-1 e	18-0 e	25-6 a	22-1 a	17-7 a	24-4 e	22-1 e	18-0 e	25-6 a	22-1 a	17-7 a
1200S300-54	50	26-9 e	24-3 e	20-3 e	28-8 i	24-9 a	17-7 a	24-3 e	22-1 e	19-3 e	27-3 i	24-9 a	17-7 a
1200S137-68	33	24-11	22-0	18-0 e	25-5 i	22-0 i	18-0 i	22-7	20-7	17-11 e	25-5 i	22-0 i	18-0 i
1200S137-68	50	24-11	22-7	19-9 e	28-0 i	25-5 i	20-11 i	22-7	20-7	17-11	25-5	23-1 i	20-2 i
1200S162-68	33	25-9	23-2 e	18-11 e	26-9 i	23-2 i	18-11 i	23-4	21-3	18-6 e	26-3 i	23-2 i	18-11 i
1200S162-68	50	25-9	23-4	20-5 e	28-11 i	26-3 i	22-2 i	23-4	21-3	18-6	26-3	23-10 i	20-10 i
1200S200-68	33	26-6	24-1 e	19-9 e	27-11 i	24-2 i	19-9 i	24-1	21-11	19-1 e	27-1 i	24-2 i	19-9 i
1200S200-68	50	26-6	24-1	21-1 e	29-10 i	27-1 i	22-6 i	24-1	21-11	19-1 e	27-1 i	24-7 i	21-6 i
1200S250-68	33	27-9	25-2 e	20-10 e	29-6 i	25-6 i	20-10 a	25-2	22-11 e	20-0 e	28-4 i	25-6 i	20-10 a
1200S250-68	50	27-9	25-2	22-0 e	31-2 i	27-11 i	22-9 i	25-2	22-11	20-0 e	28-4 i	25-9 i	22-5 i
1200S300-68	33	28-10	26-2 e	21-5 e	30-4 i	26-3 i	21-5 a	26-2	23-10 e	20-9 e	29-5 i	26-3 i	21-5 a
1200S300-68	50	28-10	26-2	22-11 e	32-5 i	29-5 i	24-1 i	26-2	23-10	20-9 e	29-5 i	26-9 i	23-4 i
1200S162-97	33	28-9	26-2	22-4	31-7	27-4	22-4 i	26-2	23-9	20-9	29-4	26-8	22-4 i
1200S162-97	50	28-9	26-2	22-10	32-4	29-4	25-8	26-2	23-9	20-9	29-4	26-8	23-3
1200S200-97	33	29-8	27-0	23-5	33-1	28-8	23-5 i	27-0	24-6	21-5	30-3	27-6	23-5 i
1200S200-97	50	29-8	27-0	23-7	33-4	30-3	26-5	27-0	24-6	21-5	30-3	27-6	24-0
1200S250-97	33	31-1	28-2	24-8	34-10	30-8	25-0 i	28-2	25-7	22-5	31-8	28-9	25-0 i
1200S250-97	50	31-1	28-2	24-8	34-10	31-8	27-8	28-2	25-7	22-5	31-8	28-9	25-2
1200S300-97	33	32-4	29-4	25-8	36-3	32-5 i	26-5 i	29-4	26-8	23-3	32-11	29-11	26-2 i
1200S300-97	50	32-4	29-4	25-8	36-3	32-11	28-9 i	29-4	26-8	23-3	32-11	29-11	26-2

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

10 psf Dead Load and 50 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1400S137-33	33	8-6 e	6-5 e	4-3 e	6-10 a	5-1 a	3-5 a	8-6 e	6-5 e	4-3 e	6-10 a	5-1 a	3-5 a
1400S162-33	33	8-6 e	6-5 e	4-3 e	6-10 a	5-1 a	3-5 a	8-6 e	6-5 e	4-3 e	6-10 a	5-1 a	3-5 a
1400S200-33	33	8-6 e	6-5 e	4-3 e	6-10 a	5-1 a	3-5 a	8-6 e	6-5 e	4-3 e	6-10 a	5-1 a	3-5 a
1400S137-43	33	19-0 e	14-3 e	9-6 e	15-2 a	11-4 a	7-7 a	19-0 e	14-3 e	9-6 e	15-2 a	11-4 a	7-7 a
1400S162-43	33	19-0 e	14-3 e	9-6 e	15-2 a	11-4 a	7-7 a	19-0 e	14-3 e	9-6 e	15-2 a	11-4 a	7-7 a
1400S200-43	33	19-0 e	14-3 e	9-6 e	15-2 a	11-4 a	7-7 a	19-0 e	14-3 e	9-6 e	15-2 a	11-4 a	7-7 a
1400S250-43	33	19-0 e	14-3 e	9-6 e	15-2 a	11-4 a	7-7 a	19-0 e	14-3 e	9-6 e	15-2 a	11-4 a	7-7 a
1400S300-43	33	19-0 e	14-3 e	9-6 e	15-2 a	11-4 a	7-7 a	19-0 e	14-3 e	9-6 e	15-2 a	11-4 a	7-7 a
1400S137-54	33	22-10 e	19-10 e	16-2 e	22-10 a	19-10 a	15-0 a	22-10 e	19-10 e	16-2 e	22-10 a	19-10 a	15-0 a
1400S137-54	50	25-9 e	22-9 e	18-7 e	26-3 a	22-7 a	15-0 a	23-5 e	21-3 e	18-7 e	26-3 a	22-7 a	15-0 a
1400S162-54	33	24-2 e	20-11 e	17-1 e	24-2 a	20-11 a	15-0 a	24-2 e	20-11 e	17-1 e	24-2 a	20-11 a	15-0 a
1400S162-54	50	26-7 e	24-2 e	18-9 e	27-11 a	22-7 a	15-0 a	24-2 e	21-11 e	18-9 e	27-2 a	22-7 a	15-0 a
1400S200-54	33	25-0 e	21-7 e	17-8 e	25-0 a	21-7 a	15-0 a	25-0 e	21-7 e	17-8 e	25-0 a	21-7 a	15-0 a
1400S200-54	50	27-6 e	23-10 e	18-9 e	27-6 a	22-7 a	15-0 a	25-2 e	22-11 e	18-9 e	27-6 a	22-7 a	15-0 a
1400S250-54	33	26-0 e	22-6 e	18-4 e	26-0 a	22-6 a	15-0 a	26-0 e	22-6 e	18-4 e	26-0 a	22-6 a	15-0 a
1400S250-54	50	28-11 e	25-5 e	18-9 e	29-5 a	22-7 a	15-0 a	26-3 e	23-11 e	18-9 e	29-5 a	22-7 a	15-0 a
1400S300-54	33	27-5 e	23-9 e	18-9 e	27-5 a	22-7 a	15-0 a	27-5 e	23-9 e	18-9 e	27-5 a	22-7 a	15-0 a
1400S300-54	50	30-1 e	26-9 e	18-9 e	30-1 a	22-7 a	15-0 a	27-4 e	24-10 e	18-9 e	30-1 a	22-7 a	15-0 a
1400S137-68	33	27-7	23-11 e	19-6 e	27-7 i	23-11 i	19-6 a	25-10	23-6 e	19-6 e	27-7 i	23-11 i	19-6 a
1400S137-68	50	28-6	25-10	22-5 e	31-8 i	27-5 i	22-5 i	25-10	23-6	20-6 e	29-1 i	26-5 i	22-5 i
1400S162-68	33	29-0 e	25-1 e	20-6 e	29-0 i	25-1 i	20-6 a	26-8	24-3 e	20-6 e	29-0 i	25-1 i	20-6 a
1400S162-68	50	29-4	26-8 e	23-3 e	32-11 i	29-0 i	23-8 a	26-8	24-3	21-2 e	29-11 i	27-2 i	23-8 a
1400S200-68	33	30-2 e	26-3 e	21-5 e	30-4 i	26-3 i	21-5 a	27-5	24-11 e	21-5 e	30-4 i	26-3 i	21-5 a
1400S200-68	50	30-2	27-5 e	23-11 e	33-11 i	29-7 i	24-2 a	27-5	24-11	21-9 e	30-10 i	28-0 i	24-2 a
1400S250-68	33	31-6 e	27-6 e	22-6 e	31-10 i	27-6 i	22-6 a	28-7 e	26-0 e	22-6 e	31-10 i	27-6 i	22-6 a
1400S250-68	50	31-6	28-7 e	24-6 e	34-8 i	30-0 i	24-6 a	28-7	26-0	22-8 e	32-1 i	29-2 i	24-6 a
1400S300-68	33	32-6 e	28-1 e	22-11 e	32-6 i	28-1 a	22-11 a	29-8 e	26-11 e	22-11 e	32-6 i	28-1 a	22-11 a
1400S300-68	50	32-8	29-8 e	25-11 e	36-8 i	31-9 i	25-11 a	29-8	26-11 e	23-6 e	33-4 i	30-3 i	25-11 a
1400S162-97	33	32-10	29-10	25-2	35-8	30-10 i	25-2 i	29-10	27-1	23-8	33-6	30-5 i	25-2 i
1400S162-97	50	32-10	29-10	26-1	36-10	33-6	29-3 i	29-10	27-1	23-8	33-6	30-5	26-7
1400S200-97	33	33-9	30-8	26-4	37-3	32-3 i	26-4 i	30-8	27-11	24-4	34-6	31-4 i	26-4 i
1400S200-97	50	33-9	30-8	26-10	37-11	34-6	30-1 i	30-8	27-11	24-4	34-6	31-4	27-4 i
1400S250-97	33	35-3	32-0	28-0	39-7	34-4 i	28-0 i	32-0	29-1	25-5	35-11	32-8 i	28-0 i
1400S250-97	50	35-3	32-0	28-0	39-7	35-11	31-5 i	32-0	29-1	25-5	35-11	32-8	28-6 i
1400S300-97	33	36-7	33-3	29-0	41-1 i	36-2 i	29-6 i	33-3	30-2	26-4	37-4	33-11 i	29-6 i
1400S300-97	50	36-7	33-3	29-0	41-1	37-4	32-7 i	33-3	30-2	26-4	37-4	33-11	29-7 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

15 psf Dead Load and 125 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
600S137-33	33	6-10 e	5-11 e	4-4 e	6-10 a	5-3 a	3-6 a	6-10 e	5-11 e	4-4 e	6-10 a	5-3 a	3-6 a
600S162-33	33	7-3 e	6-4 e	4-4 e	7-0 a	5-3 a	3-6 a	7-3 e	6-4 e	4-4 e	7-0 a	5-3 a	3-6 a
600S200-33	33	7-5 e	6-5 e	4-4 e	7-0 a	5-3 a	3-6 a	7-5 e	6-5 e	4-4 e	7-0 a	5-3 a	3-6 a
600S137-43	33	7-11 e	6-10 e	5-7 e	7-11 a	6-10 a	5-7 a	7-11 e	6-10 e	5-7 e	7-11 a	6-10 a	5-7 a
600S162-43	33	8-5 e	7-4 e	6-0 e	8-5 a	7-4 a	6-0 a	8-5 e	7-4 e	6-0 e	8-5 a	7-4 a	6-0 a
600S200-43	33	8-6 e	7-4 e	6-0 e	8-6 a	7-4 a	6-0 a	8-6 e	7-4 e	6-0 e	8-6 a	7-4 a	6-0 a
600S250-43	33	9-2 e	8-0 e	6-6 e	9-2 a	8-0 a	6-6 a	9-2 e	8-0 e	6-6 e	9-2 a	8-0 a	6-6 a
600S300-43	33	9-9 e	8-5 e	6-11 e	9-9 a	8-5 a	6-11 a	9-9 e	8-5 e	6-11 e	9-9 a	8-5 a	6-11 a
600S137-54	33	8-10	7-8 e	6-3 e	8-10 i	7-8 i	6-3 i	8-8	7-8 e	6-3 e	8-10 i	7-8 i	6-3 i
600S137-54	50	9-6	8-8	7-7 e	10-8 i	9-4 i	7-7 i	8-8	7-10	6-10 e	9-9 i	8-10 i	7-7 i
600S162-54	33	9-5	8-2 e	6-8 e	9-5 i	8-2 i	6-8 a	9-0	8-2 e	6-8 e	9-5 i	8-2 i	6-8 a
600S162-54	50	9-11	9-0	7-11 e	11-2 i	9-11 i	8-1 i	9-0	8-2	7-2 e	10-2 i	9-3 i	8-1 i
600S200-54	33	9-10 e	8-6 e	6-11 e	9-10 i	8-6 i	6-11 a	9-5	8-6 e	6-11 e	9-10 i	8-6 i	6-11 a
600S200-54	50	10-4	9-5 e	8-1 e	11-5 i	9-11 i	8-1 i	9-5	8-7	7-6 e	10-7 i	9-7 i	8-1 i
600S250-54	33	10-5 e	9-0 e	7-4 e	10-5 i	9-0 i	7-4 a	9-11 e	9-0 e	7-4 e	10-5 i	9-0 i	7-4 a
600S250-54	50	10-11	9-11 e	8-8 e	12-3 i	10-8 i	8-8 a	9-11	9-0	7-10 e	11-1 i	10-1 i	8-8 a
600S300-54	33	11-0 e	9-6 e	7-9 e	11-0 i	9-6 i	7-9 a	10-5 e	9-6 e	7-9 e	11-0 i	9-6 i	7-9 a
600S300-54	50	11-4	10-4 e	9-0 e	12-9 i	11-3 i	9-2 a	10-4	9-4 e	8-2 e	11-7 i	10-6 i	9-2 a
600S137-68	33	9-10	8-6	6-11	9-10	8-6 i	6-11 i	9-4	8-5	6-11	9-10	8-6 i	6-11 i
600S137-68	50	10-3	9-4	8-1	11-6	10-5 i	8-7 i	9-4	8-5	7-4	10-5	9-6	8-3 i
600S162-68	33	10-6	9-1	7-5	10-6 i	9-1 i	7-5 i	9-9	8-10	7-5	10-6 i	9-1 i	7-5 i
600S162-68	50	10-8	9-9	8-6	12-0	10-11 i	9-2 i	9-9	8-10	7-8	10-11	9-11	8-8 i
600S200-68	33	11-2	9-8	7-10 e	11-2 i	9-8 i	7-10 i	10-2	9-2	7-10 e	11-2 i	9-8 i	7-10 i
600S200-68	50	11-2	10-2	8-10	12-6	11-4 i	9-5 i	10-2	9-2	8-0	11-4	10-4 i	9-0 i
600S250-68	33	11-10	10-4	8-5 e	11-11 i	10-4 i	8-5 i	10-9	9-9	8-5 e	11-11 i	10-4 i	8-5 i
600S250-68	50	11-10	10-9	9-4	13-3	11-11 i	9-9 i	10-9	9-9	8-6	12-0	10-11 i	9-6 i
600S300-68	33	12-4	10-9	8-9 e	12-5 i	10-9 i	8-9 i	11-3	10-2	8-9 e	12-5 i	10-9 i	8-9 i
600S300-68	50	12-4	11-2	9-9	13-10 i	12-7 i	10-5 i	11-2	10-2	8-11	12-7	11-5 i	10-0 i
600S162-97	33	11-11	10-8	8-9	12-4	10-8	8-9	10-10	9-10	8-7	12-2	10-8	8-9
600S162-97	50	11-11	10-10	9-5	13-5	12-2	10-7	10-10	9-10	8-7	12-2	11-0	9-8
600S200-97	33	12-5	11-4	9-3	13-2	11-5	9-3	11-4	10-3	8-11	12-8	11-5	9-3
600S200-97	50	12-5	11-4	9-10	14-0	12-8	11-1	11-4	10-3	8-11	12-8	11-6	10-1
600S250-97	33	13-2	11-11	10-1	14-4	12-5	10-1 i	11-11	10-10	9-6	13-5	12-2	10-1 i
600S250-97	50	13-2	11-11	10-5	14-9	13-5	11-9	11-11	10-10	9-6	13-5	12-2	10-8
600S300-97	33	13-10	12-7	10-10	15-4	13-3	10-10 i	12-7	11-5	9-11	14-1	12-10	10-10 i
600S300-97	50	13-10	12-7	10-11	15-6	14-1	12-4	12-7	11-5	9-11	14-1	12-10	11-2

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

15 psf Dead Load and 125 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
800S137-33	33	6-6 e	4-10 e	3-3 e	5-2 a	3-10 a	2-7 a	6-6 e	4-10 e	3-3 e	5-2 a	3-10 a	2-7 a
800S162-33	33	6-6 e	4-10 e	3-3 e	5-2 a	3-10 a	2-7 a	6-6 e	4-10 e	3-3 e	5-2 a	3-10 a	2-7 a
800S200-33	33	6-6 e	4-10 e	3-3 e	5-2 a	3-10 a	2-7 a	6-6 e	4-10 e	3-3 e	5-2 a	3-10 a	2-7 a
800S137-43	33	9-9 e	8-6 e	6-11 e	9-9 a	8-6 a	5-9 a	9-9 e	8-6 e	6-11 e	9-9 a	8-6 a	5-9 a
800S162-43	33	10-4 e	9-0 e	7-2 e	10-4 a	8-8 a	5-9 a	10-4 e	9-0 e	7-2 e	10-4 a	8-8 a	5-9 a
800S200-43	33	10-3 e	8-10 e	7-2 e	10-3 a	8-8 a	5-9 a	10-3 e	8-10 e	7-2 e	10-3 a	8-8 a	5-9 a
800S250-43	33	11-0 e	9-7 e	7-2 e	11-0 a	8-8 a	5-9 a	11-0 e	9-7 e	7-2 e	11-0 a	8-8 a	5-9 a
800S300-43	33	11-8 e	10-1 e	7-2 e	11-7 a	8-8 a	5-9 a	11-8 e	10-1 e	7-2 e	11-7 a	8-8 a	5-9 a
800S137-54	33	10-11 e	9-5 e	7-8 e	10-11 i	9-5 a	7-8 a	10-11 e	9-5 e	7-8 e	10-11 i	9-5 a	7-8 a
800S137-54	50	12-1 e	11-0 e	9-5 e	13-3 i	11-6 a	9-5 a	11-0 e	10-0 e	8-8 e	12-4 i	11-2 i	9-5 a
800S162-54	33	11-7 e	10-0 e	8-2 e	11-7 i	10-0 a	8-2 a	11-5 e	10-0 e	8-2 e	11-7 i	10-0 a	8-2 a
800S162-54	50	12-7 e	11-5 e	9-11 e	14-1 i	12-2 a	9-11 a	11-5 e	10-4 e	9-1 e	12-10 i	11-8 a	9-11 a
800S200-54	33	12-0 e	10-5 e	8-6 e	12-0 a	10-5 a	8-6 a	11-10 e	10-5 e	8-6 e	12-0 a	10-5 a	8-6 a
800S200-54	50	13-0 e	11-10 e	9-9 e	13-10 i	12-0 a	9-9 a	11-10 e	10-9 e	9-5 e	13-4 i	12-0 a	9-9 a
800S250-54	33	12-8 e	10-11 e	8-11 e	12-8 a	10-11 a	8-11 a	12-6 e	10-11 e	8-11 e	12-8 a	10-11 a	8-11 a
800S250-54	50	13-8 e	12-5 e	10-5 e	14-8 i	12-9 a	10-5 a	12-5 e	11-3 e	9-10 e	13-11 i	12-8 a	10-5 a
800S300-54	33	13-4 e	11-7 e	9-5 e	13-4 a	11-7 a	9-5 a	13-0 e	11-7 e	9-5 e	13-4 a	11-7 a	9-5 a
800S300-54	50	14-2 e	12-11 e	10-10 e	15-5 a	13-4 a	10-10 a	12-11 e	11-8 e	10-3 e	14-6 i	13-2 a	10-10 a
800S137-68	33	12-2	10-6	8-7 e	12-2 i	10-6 i	8-7 i	11-10	10-6	8-7 e	12-2 i	10-6 i	8-7 i
800S137-68	50	13-0	11-10	10-4 e	14-7 i	13-0 i	10-7 i	11-10	10-9	9-4 e	13-3 i	12-0 i	10-6 i
800S162-68	33	12-11	11-2 e	9-1 e	12-11 i	11-2 i	9-1 i	12-3	11-2 e	9-1 e	12-11 i	11-2 i	9-1 i
800S162-68	50	13-6	12-3	10-9 e	15-2 i	13-9 i	11-3 i	12-3	11-2	9-9 e	13-9 i	12-6 i	10-11 i
800S200-68	33	13-7	11-9 e	9-7 e	13-7 i	11-9 i	9-7 i	12-9	11-7 e	9-7 e	13-7 i	11-9 i	9-7 i
800S200-68	50	14-0	12-9	11-1 e	15-9 i	14-2 i	11-7 i	12-9	11-7	10-1 e	14-4 i	13-0 i	11-4 i
800S250-68	33	14-6	12-7 e	10-3 e	14-6 i	12-7 i	10-3 a	13-5	12-2 e	10-3 e	14-6 i	12-7 i	10-3 a
800S250-68	50	14-9	13-5	11-9 e	16-7 i	14-7 i	11-11 i	13-5	12-2	10-8 e	15-1 i	13-8 i	11-11 i
800S300-68	33	15-0 e	13-0 e	10-7 e	15-0 i	13-0 i	10-7 a	14-0	12-9 e	10-7 e	15-0 i	13-0 i	10-7 a
800S300-68	50	15-4	14-0 e	12-2 e	17-3 i	15-6 i	12-8 a	14-0	12-8	11-1 e	15-8 i	14-3 i	12-5 a
800S162-97	33	15-1	13-2	10-9	15-2	13-2	10-9 i	13-8	12-5	10-9	15-2	13-2	10-9 i
800S162-97	50	15-1	13-8	11-11	16-11	15-5	13-3 i	13-8	12-5	10-10	15-5	14-0	12-2
800S200-97	33	15-8	13-11	11-4	16-1	13-11	11-4 i	14-3	12-11	11-3	16-0	13-11	11-4 i
800S200-97	50	15-8	14-3	12-5	17-7	16-0	13-11 i	14-3	12-11	11-3	16-0	14-6	12-8
800S250-97	33	16-6	15-0	12-4	17-5	15-1 i	12-4 i	15-0	13-7	11-11	16-10	15-1 i	12-4 i
800S250-97	50	16-6	15-0	13-1	18-6	16-10	14-8 i	15-0	13-7	11-11	16-10	15-4	13-4 i
800S300-97	33	17-3	15-8	13-1	18-6	16-0 i	13-1 i	15-8	14-3	12-5	17-7	16-0 i	13-1 i
800S300-97	50	17-3	15-8	13-8	19-5	17-7	15-5 i	15-8	14-3	12-5	17-7	16-0	14-0 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

15 psf Dead Load and 125 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
925S137-33	33	5-7 e	4-2 e	2-9 e	4-5 a	3-4 a	2-2 a	5-7 e	4-2 e	2-9 e	4-5 a	3-4 a	2-2 a
925S162-33	33	5-7 e	4-2 e	2-9 e	4-5 a	3-4 a	2-2 a	5-7 e	4-2 e	2-9 e	4-5 a	3-4 a	2-2 a
925S200-33	33	5-7 e	4-2 e	2-9 e	4-5 a	3-4 a	2-2 a	5-7 e	4-2 e	2-9 e	4-5 a	3-4 a	2-2 a
925S137-43	33	10-5 e	9-1 e	6-2 e	9-11 a	7-5 a	4-11 a	10-5 e	9-1 e	6-2 e	9-11 a	7-5 a	4-11 a
925S162-43	33	11-1 e	9-4 e	6-2 e	9-11 a	7-5 a	4-11 a	11-1 e	9-4 e	6-2 e	9-11 a	7-5 a	4-11 a
925S200-43	33	10-11 e	9-4 e	6-2 e	9-11 a	7-5 a	4-11 a	10-11 e	9-4 e	6-2 e	9-11 a	7-5 a	4-11 a
925S250-43	33	11-10 e	9-4 e	6-2 e	9-11 a	7-5 a	4-11 a	11-10 e	9-4 e	6-2 e	9-11 a	7-5 a	4-11 a
925S300-43	33	12-5 e	9-4 e	6-2 e	9-11 a	7-5 a	4-11 a	12-5 e	9-4 e	6-2 e	9-11 a	7-5 a	4-11 a
925S137-54	33	12-2 e	10-6 e	8-7 e	12-2 a	10-6 a	8-7 a	12-2 e	10-6 e	8-7 e	12-2 a	10-6 a	8-7 a
925S137-54	50	13-8 e	12-4 e	10-1 e	14-3 a	12-4 a	9-10 a	12-5 e	11-3 e	9-10 e	13-11 i	12-4 a	9-10 a
925S162-54	33	12-10 e	11-2 e	9-1 e	12-10 a	11-2 a	9-1 a	12-10 e	11-2 e	9-1 e	12-10 a	11-2 a	9-1 a
925S162-54	50	14-2 e	12-10 e	10-8 e	15-1 a	13-0 a	9-10 a	12-10 e	11-8 e	10-2 e	14-5 a	13-0 a	9-10 a
925S200-54	33	13-4 e	11-7 e	9-5 e	13-4 a	11-7 a	9-5 a	13-4 e	11-7 e	9-5 e	13-4 a	11-7 a	9-5 a
925S200-54	50	14-8 e	12-9 e	10-5 e	14-9 a	12-9 a	9-10 a	13-4 e	12-1 e	10-5 e	14-9 a	12-9 a	9-10 a
925S250-54	33	14-0 e	12-1 e	9-11 e	14-0 a	12-1 a	9-10 a	14-0 e	12-1 e	9-11 e	14-0 a	12-1 a	9-10 a
925S250-54	50	15-4 e	13-7 e	11-1 e	15-9 a	13-7 a	9-10 a	13-11 e	12-8 e	11-1 e	15-8 a	13-7 a	9-10 a
925S300-54	33	14-9 e	12-9 e	10-5 e	14-9 a	12-9 a	9-10 a	14-7 e	12-9 e	10-5 e	14-9 a	12-9 a	9-10 a
925S300-54	50	15-11 e	14-3 e	11-8 e	16-6 a	14-3 a	9-10 a	14-6 e	13-2 e	11-6 e	16-3 a	14-3 a	9-10 a
925S137-68	33	13-7	11-9 e	9-7 e	13-7 i	11-9 i	9-7 a	13-4	11-9 e	9-7 e	13-7 i	11-9 i	9-7 a
925S137-68	50	14-8	13-4	11-8 e	16-6 i	14-6 i	11-10 i	13-4	12-1	10-7 e	15-0 i	13-7 i	11-10 i
925S162-68	33	14-4 e	12-5 e	10-2 e	14-4 i	12-5 i	10-2 a	13-10	12-5 e	10-2 e	14-4 i	12-5 i	10-2 a
925S162-68	50	15-3	13-10 e	12-1 e	17-1 i	15-4 i	12-6 a	13-10	12-7	11-0 e	15-6 i	14-1 i	12-4 a
925S200-68	33	15-1 e	13-1 e	10-8 e	15-1 i	13-1 i	10-8 a	14-4 e	13-0 e	10-8 e	15-1 i	13-1 i	10-8 a
925S200-68	50	15-9	14-4 e	12-6 e	17-9 i	15-9 i	12-10 a	14-4	13-0	11-4 e	16-1 i	14-7 i	12-9 a
925S250-68	33	16-0 e	13-11 e	11-4 e	16-0 i	13-11 i	11-4 a	15-1 e	13-8 e	11-4 e	16-0 i	13-11 i	11-4 a
925S250-68	50	16-7	15-1 e	13-2 e	18-7 i	16-2 i	13-3 a	15-1	13-8 e	11-11 e	16-11 i	15-4 i	13-3 a
925S300-68	33	16-7 e	14-4 e	11-8 e	16-7 i	14-4 a	11-8 a	15-8 e	14-3 e	11-8 e	16-7 i	14-4 a	11-8 a
925S300-68	50	17-3	15-8 e	13-8 e	19-4 i	17-2 i	14-0 a	15-8	14-2 e	12-5 e	17-7 i	15-11 i	13-11 a
925S162-97	33	16-11	14-8	12-0	16-11	14-8 i	12-0 i	15-5	14-0	12-0	16-11	14-8 i	12-0 i
925S162-97	50	17-0	15-5	13-6	19-1	17-4	14-9 i	15-5	14-0	12-3	17-4	15-9	13-9 i
925S200-97	33	17-7	15-6	12-7	17-10	15-6 i	12-7 i	16-0	14-6	12-7	17-10	15-6 i	12-7 i
925S200-97	50	17-7	16-0	14-0	19-9	18-0	15-6 i	16-0	14-6	12-8	18-0	16-4	14-3 i
925S250-97	33	18-6	16-8	13-7	19-3 i	16-8 i	13-7 i	16-10	15-3	13-4	18-11 i	16-8 i	13-7 i
925S250-97	50	18-6	16-10	14-8	20-10	18-11 i	16-5 i	16-10	15-3	13-4	18-11	17-2	15-0 i
925S300-97	33	19-4	17-7	14-5	20-5 i	17-8 i	14-5 i	17-7	16-0	13-11	19-9 i	17-8 i	14-5 i
925S300-97	50	19-4	17-7	15-4	21-9	19-9 i	17-2 i	17-7	16-0	13-11	19-9	17-11	15-8 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

15 psf Dead Load and 125 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1000S137-33	33	5-2 e	3-10 e	2-7 e	4-1 a	3-1 a	2-0 a	5-2 e	3-10 e	2-7 e	4-1 a	3-1 a	2-0 a
1000S162-33	33	5-2 e	3-10 e	2-7 e	4-1 a	3-1 a	2-0 a	5-2 e	3-10 e	2-7 e	4-1 a	3-1 a	2-0 a
1000S200-33	33	5-2 e	3-10 e	2-7 e	4-1 a	3-1 a	2-0 a	5-2 e	3-10 e	2-7 e	4-1 a	3-1 a	2-0 a
1000S137-43	33	10-10 e	8-7 e	5-9 e	9-2 a	6-10 a	4-7 a	10-10 e	8-7 e	5-9 e	9-2 a	6-10 a	4-7 a
1000S162-43	33	11-6 e	8-7 e	5-9 e	9-2 a	6-10 a	4-7 a	11-6 e	8-7 e	5-9 e	9-2 a	6-10 a	4-7 a
1000S200-43	33	11-4 e	8-7 e	5-9 e	9-2 a	6-10 a	4-7 a	11-4 e	8-7 e	5-9 e	9-2 a	6-10 a	4-7 a
1000S250-43	33	11-6 e	8-7 e	5-9 e	9-2 a	6-10 a	4-7 a	11-6 e	8-7 e	5-9 e	9-2 a	6-10 a	4-7 a
1000S300-43	33	11-6 e	8-7 e	5-9 e	9-2 a	6-10 a	4-7 a	11-6 e	8-7 e	5-9 e	9-2 a	6-10 a	4-7 a
1000S137-54	33	12-11 e	11-2 e	9-2 e	12-11 a	11-2 a	9-1 a	12-11 e	11-2 e	9-2 e	12-11 a	11-2 a	9-1 a
1000S137-54	50	14-7 e	12-9 e	10-5 e	14-8 a	12-9 a	9-1 a	13-3 e	12-0 e	10-5 e	14-8 a	12-9 a	9-1 a
1000S162-54	33	13-8 e	11-10 e	9-7 e	13-8 a	11-10 a	9-1 a	13-8 e	11-10 e	9-7 e	13-8 a	11-10 a	9-1 a
1000S162-54	50	15-1 e	13-6 e	11-0 e	15-7 a	13-6 a	9-1 a	13-9 e	12-5 e	10-11 e	15-5 a	13-6 a	9-1 a
1000S200-54	33	14-1 e	12-2 e	9-11 e	14-1 a	12-2 a	9-1 a	14-1 e	12-2 e	9-11 e	14-1 a	12-2 a	9-1 a
1000S200-54	50	15-4 e	13-3 e	10-10 e	15-4 a	13-3 a	9-1 a	14-2 e	12-11 e	10-10 e	15-4 a	13-3 a	9-1 a
1000S250-54	33	14-7 e	12-8 e	10-4 e	14-7 a	12-8 a	9-1 a	14-7 e	12-8 e	10-4 e	14-7 a	12-8 a	9-1 a
1000S250-54	50	16-4 e	14-2 e	11-4 e	16-4 a	13-8 a	9-1 a	14-10 e	13-6 e	11-4 e	16-4 a	13-8 a	9-1 a
1000S300-54	33	15-4 e	13-3 e	10-10 e	15-4 a	13-3 a	9-1 a	15-4 e	13-3 e	10-10 e	15-4 a	13-3 a	9-1 a
1000S300-54	50	16-11 e	14-10 e	11-4 e	17-2 a	13-8 a	9-1 a	15-5 e	14-0 e	11-4 e	17-2 a	13-8 a	9-1 a
1000S137-68	33	14-5 e	12-6 e	10-2 e	14-5 i	12-6 i	10-2 a	14-3 e	12-6 e	10-2 e	14-5 i	12-6 i	10-2 a
1000S137-68	50	15-8	14-3 e	12-5 e	17-7 i	15-5 i	12-7 a	14-3	12-11	11-4 e	16-0 i	14-6 i	12-7 a
1000S162-68	33	15-3 e	13-2 e	10-9 e	15-3 i	13-2 i	10-9 a	14-9 e	13-2 e	10-9 e	15-3 i	13-2 i	10-9 a
1000S162-68	50	16-3	14-9 e	12-11 e	18-3 i	16-3 i	13-3 a	14-9	13-5 e	11-8 e	16-7 i	15-1 i	13-2 a
1000S200-68	33	16-0 e	13-10 e	11-3 e	16-0 i	13-10 a	11-3 a	15-3 e	13-10 e	11-3 e	16-0 i	13-10 a	11-3 a
1000S200-68	50	16-10	15-3 e	13-4 e	18-11 i	16-8 i	13-7 a	15-3	13-10 e	12-1 e	17-2 i	15-7 i	13-7 a
1000S250-68	33	16-11 e	14-8 e	12-0 e	16-11 i	14-8 a	12-0 a	16-0 e	14-7 e	12-0 e	16-11 i	14-8 a	12-0 a
1000S250-68	50	17-8 e	16-0 e	13-9 e	19-5 i	16-10 i	13-9 a	16-0	14-7 e	12-8 e	18-0 i	16-4 i	13-9 a
1000S300-68	33	17-6 e	15-2 e	12-4 e	17-6 i	15-2 a	12-4 a	16-8 e	15-2 e	12-4 e	17-6 i	15-2 a	12-4 a
1000S300-68	50	18-4 e	16-8 e	14-6 e	20-6 i	17-9 a	14-6 a	16-8	15-1 e	13-2 e	18-8 i	17-0 i	14-6 a
1000S162-97	33	18-0	15-7	12-8	18-0	15-7 i	12-8 i	16-6	15-0	12-8	18-0	15-7 i	12-8 i
1000S162-97	50	18-2	16-6	14-5	20-5	18-6	15-8 i	16-6	15-0	13-1	18-6	16-10	14-8 i
1000S200-97	33	18-9	16-4	13-4	18-11 i	16-4 i	13-4 i	17-1	15-6	13-4	18-11 i	16-4 i	13-4 i
1000S200-97	50	18-9	17-1	14-11	21-1	19-2 i	16-5 i	17-1	15-6	13-6	19-2	17-5	15-2 i
1000S250-97	33	19-9	17-7	14-4	20-4 i	17-7 i	14-4 i	17-11	16-3	14-3	20-1 i	17-7 i	14-4 i
1000S250-97	50	19-9	17-11	15-8	22-2	20-1 i	17-4 i	17-11	16-3	14-3	20-1	18-3	16-0 i
1000S300-97	33	20-7	18-8	15-3 e	21-7 i	18-8 i	15-3 i	18-8	17-0	14-10 e	21-0 i	18-8 i	15-3 i
1000S300-97	50	20-7	18-8	16-4	23-1	21-0 i	18-1 i	18-8	17-0	14-10	21-0	19-1 i	16-8 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

15 psf Dead Load and 125 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1125S137-33	33	4-7 e	3-5 e	2-3 e	3-8 a	2-9 a	1-10 a	4-7 e	3-5 e	2-3 e	3-8 a	2-9 a	1-10 a
1125S162-33	33	4-7 e	3-5 e	2-3 e	3-8 a	2-9 a	1-10 a	4-7 e	3-5 e	2-3 e	3-8 a	2-9 a	1-10 a
1125S200-33	33	4-7 e	3-5 e	2-3 e	3-8 a	2-9 a	1-10 a	4-7 e	3-5 e	2-3 e	3-8 a	2-9 a	1-10 a
1125S137-43	33	10-2 e	7-7 e	5-1 e	8-1 a	6-1 a	4-0 a	10-2 e	7-7 e	5-1 e	8-1 a	6-1 a	4-0 a
1125S162-43	33	10-2 e	7-7 e	5-1 e	8-1 a	6-1 a	4-0 a	10-2 e	7-7 e	5-1 e	8-1 a	6-1 a	4-0 a
1125S200-43	33	10-2 e	7-7 e	5-1 e	8-1 a	6-1 a	4-0 a	10-2 e	7-7 e	5-1 e	8-1 a	6-1 a	4-0 a
1125S250-43	33	10-2 e	7-7 e	5-1 e	8-1 a	6-1 a	4-0 a	10-2 e	7-7 e	5-1 e	8-1 a	6-1 a	4-0 a
1125S300-43	33	10-2 e	7-7 e	5-1 e	8-1 a	6-1 a	4-0 a	10-2 e	7-7 e	5-1 e	8-1 a	6-1 a	4-0 a
1125S137-54	33	13-7 e	11-9 e	9-7 e	13-7 a	11-9 a	8-0 a	13-7 e	11-9 e	9-7 e	13-7 a	11-9 a	8-0 a
1125S137-54	50	15-6 e	13-5 e	10-1 e	15-6 a	12-1 a	8-0 a	14-8 e	13-4 e	10-1 e	15-6 a	12-1 a	8-0 a
1125S162-54	33	14-4 e	12-5 e	10-1 e	14-4 a	12-1 a	8-0 a	14-4 e	12-5 e	10-1 e	14-4 a	12-1 a	8-0 a
1125S162-54	50	16-5 e	14-3 e	10-1 e	16-1 a	12-1 a	8-0 a	15-2 e	13-9 e	10-1 e	16-1 a	12-1 a	8-0 a
1125S200-54	33	14-10 e	12-10 e	10-1 e	14-10 a	12-1 a	8-0 a	14-10 e	12-10 e	10-1 e	14-10 a	12-1 a	8-0 a
1125S200-54	50	16-2 e	14-0 e	10-1 e	16-1 a	12-1 a	8-0 a	15-8 e	14-0 e	10-1 e	16-1 a	12-1 a	8-0 a
1125S250-54	33	15-4 e	13-4 e	10-1 e	15-4 a	12-1 a	8-0 a	15-4 e	13-4 e	10-1 e	15-4 a	12-1 a	8-0 a
1125S250-54	50	17-3 e	14-11 e	10-1 e	16-1 a	12-1 a	8-0 a	16-4 e	14-10 e	10-1 e	16-1 a	12-1 a	8-0 a
1125S300-54	33	16-2 e	14-0 e	10-1 e	16-1 a	12-1 a	8-0 a	16-2 e	14-0 e	10-1 e	16-1 a	12-1 a	8-0 a
1125S300-54	50	18-2 e	15-1 e	10-1 e	16-1 a	12-1 a	8-0 a	16-11 e	15-1 e	10-1 e	16-1 a	12-1 a	8-0 a
1125S137-68	33	15-10 e	13-8 e	11-2 e	15-10 i	13-8 a	11-2 a	15-9 e	13-8 e	11-2 e	15-10 i	13-8 a	11-2 a
1125S137-68	50	17-4 e	15-9 e	13-4 e	18-11 i	16-4 i	13-4 a	15-9 e	14-4 e	12-6 e	17-8 i	16-1 i	13-4 a
1125S162-68	33	16-8 e	14-5 e	11-9 e	16-8 i	14-5 a	11-9 a	16-4 e	14-5 e	11-9 e	16-8 i	14-5 a	11-9 a
1125S162-68	50	17-11 e	16-4 e	14-1 e	19-11 i	17-3 a	14-1 a	16-4 e	14-10 e	12-11 e	18-4 i	16-7 a	14-1 a
1125S200-68	33	17-5 e	15-1 e	12-4 e	17-5 i	15-1 a	12-4 a	16-10 e	15-1 e	12-4 e	17-5 i	15-1 a	12-4 a
1125S200-68	50	18-6 e	16-10 e	14-4 e	20-3 i	17-7 a	14-4 a	16-10 e	15-3 e	13-4 e	18-11 i	17-2 a	14-4 a
1125S250-68	33	18-5 e	15-11 e	13-0 e	18-5 a	15-11 a	13-0 a	17-7 e	15-11 e	13-0 e	18-5 a	15-11 a	13-0 a
1125S250-68	50	19-5 e	17-7 e	14-6 e	20-6 i	17-9 a	14-6 a	17-7 e	16-0 e	14-0 e	19-9 i	17-9 a	14-6 a
1125S300-68	33	19-0 e	16-5 e	13-5 e	19-0 a	16-5 a	13-5 a	18-4 e	16-5 e	13-5 e	19-0 a	16-5 a	13-5 a
1125S300-68	50	20-2 e	18-4 e	15-4 e	21-8 i	18-9 a	15-4 a	18-4 e	16-8 e	14-6 e	20-7 i	18-8 a	15-4 a
1125S162-97	33	19-8	17-0	13-11	19-8 i	17-0 i	13-11 i	18-3	16-7	13-11	19-8 i	17-0 i	13-11 i
1125S162-97	50	20-1	18-3	15-11	22-6	20-5 i	17-1 i	18-3	16-7	14-5	20-5	18-7 i	16-3 i
1125S200-97	33	20-8	17-10	14-7 e	20-8 i	17-10 i	14-7 i	18-10	17-1	14-7 e	20-8 i	17-10 i	14-7 i
1125S200-97	50	20-9	18-10	16-5	23-3	21-2 i	17-11 i	18-10	17-1	14-11	21-2	19-2 i	16-9 i
1125S250-97	33	21-8	19-2	15-8 e	22-2 i	19-2 i	15-8 i	19-8	17-11	15-8 e	22-2 i	19-2 i	15-8 i
1125S250-97	50	21-8	19-8	17-3	24-4	22-2 i	18-11 i	19-8	17-11	15-8	22-2	20-1 i	17-7 i
1125S300-97	33	22-7	20-3	16-6 e	23-5 i	20-3 i	16-6 i	20-6	18-8	16-3 e	23-1 i	20-3 i	16-6 i
1125S300-97	50	22-7	20-6	17-11 e	25-4 i	23-1 i	19-8 i	20-6	18-8	16-3	23-1	20-11 i	18-3 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

15 psf Dead Load and 125 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1200S137-33	33	4-3 e	3-2 e	2-1 e	3-5 a	2-6 a	1-8 a	4-3 e	3-2 e	2-1 e	3-5 a	2-6 a	1-8 a
1200S162-33	33	4-3 e	3-2 e	2-1 e	3-5 a	2-6 a	1-8 a	4-3 e	3-2 e	2-1 e	3-5 a	2-6 a	1-8 a
1200S200-33	33	4-3 e	3-2 e	2-1 e	3-5 a	2-6 a	1-8 a	4-3 e	3-2 e	2-1 e	3-5 a	2-6 a	1-8 a
1200S137-43	33	9-6 e	7-1 e	4-9 e	7-7 a	5-8 a	3-9 a	9-6 e	7-1 e	4-9 e	7-7 a	5-8 a	3-9 a
1200S162-43	33	9-6 e	7-1 e	4-9 e	7-7 a	5-8 a	3-9 a	9-6 e	7-1 e	4-9 e	7-7 a	5-8 a	3-9 a
1200S200-43	33	9-6 e	7-1 e	4-9 e	7-7 a	5-8 a	3-9 a	9-6 e	7-1 e	4-9 e	7-7 a	5-8 a	3-9 a
1200S250-43	33	9-6 e	7-1 e	4-9 e	7-7 a	5-8 a	3-9 a	9-6 e	7-1 e	4-9 e	7-7 a	5-8 a	3-9 a
1200S300-43	33	9-6 e	7-1 e	4-9 e	7-7 a	5-8 a	3-9 a	9-6 e	7-1 e	4-9 e	7-7 a	5-8 a	3-9 a
1200S137-54	33	14-0 e	12-1 e	9-5 e	14-0 a	11-4 a	7-6 a	14-0 e	12-1 e	9-5 e	14-0 a	11-4 a	7-6 a
1200S137-54	50	16-0 e	13-10 e	9-5 e	15-1 a	11-4 a	7-6 a	15-6 e	13-10 e	9-5 e	15-1 a	11-4 a	7-6 a
1200S162-54	33	14-9 e	12-9 e	9-5 e	14-9 a	11-4 a	7-6 a	14-9 e	12-9 e	9-5 e	14-9 a	11-4 a	7-6 a
1200S162-54	50	16-11 e	14-2 e	9-5 e	15-1 a	11-4 a	7-6 a	16-0 e	14-2 e	9-5 e	15-1 a	11-4 a	7-6 a
1200S200-54	33	15-3 e	13-2 e	9-5 e	15-1 a	11-4 a	7-6 a	15-3 e	13-2 e	9-5 e	15-1 a	11-4 a	7-6 a
1200S200-54	50	16-8 e	14-2 e	9-5 e	15-1 a	11-4 a	7-6 a	16-6 e	14-2 e	9-5 e	15-1 a	11-4 a	7-6 a
1200S250-54	33	15-10 e	13-8 e	9-5 e	15-1 a	11-4 a	7-6 a	15-10 e	13-8 e	9-5 e	15-1 a	11-4 a	7-6 a
1200S250-54	50	17-10 e	14-2 e	9-5 e	15-1 a	11-4 a	7-6 a	17-3 e	14-2 e	9-5 e	15-1 a	11-4 a	7-6 a
1200S300-54	33	16-8 e	14-2 e	9-5 e	15-1 a	11-4 a	7-6 a	16-8 e	14-2 e	9-5 e	15-1 a	11-4 a	7-6 a
1200S300-54	50	18-9 e	14-2 e	9-5 e	15-1 a	11-4 a	7-6 a	17-10 e	14-2 e	9-5 e	15-1 a	11-4 a	7-6 a
1200S137-68	33	16-8 e	14-5 e	11-9 e	16-8 i	14-5 a	11-9 a	16-8 e	14-5 e	11-9 e	16-8 i	14-5 a	11-9 a
1200S137-68	50	18-4 e	16-8 e	13-8 e	19-5 i	16-9 a	13-8 a	16-8 e	15-2 e	13-3 e	18-8 i	16-9 a	13-8 a
1200S162-68	33	17-6 e	15-2 e	12-4 e	17-6 a	15-2 a	12-4 a	17-3 e	15-2 e	12-4 e	17-6 a	15-2 a	12-4 a
1200S162-68	50	18-11 e	17-3 e	14-6 e	20-6 i	17-9 a	14-6 a	17-3 e	15-8 e	13-8 e	19-4 i	17-7 a	14-6 a
1200S200-68	33	18-3 e	15-10 e	12-11 e	18-3 a	15-10 a	12-11 a	17-9 e	15-10 e	12-11 e	18-3 a	15-10 a	12-11 a
1200S200-68	50	19-6 e	17-9 e	14-9 e	20-10 i	18-1 a	14-9 a	17-9 e	16-1 e	14-1 e	19-11 i	18-1 a	14-9 a
1200S250-68	33	19-4 e	16-8 e	13-8 e	19-4 a	16-8 a	13-8 a	18-7 e	16-8 e	13-8 e	19-4 a	16-8 a	13-8 a
1200S250-68	50	20-5 e	18-3 e	14-11 e	21-1 i	18-3 a	14-11 a	18-7 e	16-10 e	14-9 e	20-10 i	18-3 a	14-11 a
1200S300-68	33	19-10 e	17-2 e	14-0 e	19-10 a	17-2 a	14-0 a	19-4 e	17-2 e	14-0 e	19-10 a	17-2 a	14-0 a
1200S300-68	50	21-3 e	19-4 e	15-9 e	22-4 a	19-4 a	15-1 a	19-4 e	17-6 e	15-4 e	21-8 a	19-4 a	15-1 a
1200S162-97	33	20-8	17-11	14-7 e	20-8 i	17-11 i	14-7 i	19-3	17-6	14-7 e	20-8 i	17-11 i	14-7 i
1200S162-97	50	21-2	19-3	16-10	23-9	21-7 i	18-0 i	19-3	17-6	15-3	21-7	19-8 i	17-2 i
1200S200-97	33	21-8	18-9	15-4 e	21-8 i	18-9 i	15-4 i	19-10	18-0	15-4 e	21-8 i	18-9 i	15-4 i
1200S200-97	50	21-10	19-10	17-4	24-7 i	22-4 i	18-10 i	19-10	18-0	15-9	22-4	20-3 i	17-8 i
1200S250-97	33	22-10	20-1	16-5 e	23-2 i	20-1 i	16-5 i	20-9	18-10	16-5 e	23-2 i	20-1 i	16-5 i
1200S250-97	50	22-10	20-9	18-2 e	25-8 i	23-4 i	19-10 i	20-9	18-10	16-6	23-4	21-2 i	18-6 i
1200S300-97	33	23-9	21-2 e	17-3 e	24-6 i	21-2 i	17-3 i	21-7	19-8	17-2 e	24-3 i	21-2 i	17-3 i
1200S300-97	50	23-9	21-7	18-10 e	26-9 i	24-3 i	20-7 i	21-7	19-8	17-2	24-3 i	22-1 i	19-3 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

15 psf Dead Load and 125 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1400S137-33	33	3-8 e	2-9 e	1-10 e	2-11 a	2-2 a	1-5 a	3-8 e	2-9 e	1-10 e	2-11 a	2-2 a	1-5 a
1400S162-33	33	3-8 e	2-9 e	1-10 e	2-11 a	2-2 a	1-5 a	3-8 e	2-9 e	1-10 e	2-11 a	2-2 a	1-5 a
1400S200-33	33	3-8 e	2-9 e	1-10 e	2-11 a	2-2 a	1-5 a	3-8 e	2-9 e	1-10 e	2-11 a	2-2 a	1-5 a
1400S137-43	33	8-1 e	6-1 e	4-0 e	6-6 a	4-10 a	3-3 a	8-1 e	6-1 e	4-0 e	6-6 a	4-10 a	3-3 a
1400S162-43	33	8-1 e	6-1 e	4-0 e	6-6 a	4-10 a	3-3 a	8-1 e	6-1 e	4-0 e	6-6 a	4-10 a	3-3 a
1400S200-43	33	8-1 e	6-1 e	4-0 e	6-6 a	4-10 a	3-3 a	8-1 e	6-1 e	4-0 e	6-6 a	4-10 a	3-3 a
1400S250-43	33	8-1 e	6-1 e	4-0 e	6-6 a	4-10 a	3-3 a	8-1 e	6-1 e	4-0 e	6-6 a	4-10 a	3-3 a
1400S300-43	33	8-1 e	6-1 e	4-0 e	6-6 a	4-10 a	3-3 a	8-1 e	6-1 e	4-0 e	6-6 a	4-10 a	3-3 a
1400S137-54	33	14-11 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a	14-11 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a
1400S137-54	50	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a
1400S162-54	33	15-10 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a	15-10 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a
1400S162-54	50	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a
1400S200-54	33	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a
1400S200-54	50	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a
1400S250-54	33	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a
1400S250-54	50	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a
1400S300-54	33	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a
1400S300-54	50	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a	16-1 e	12-1 e	8-0 e	12-10 a	9-8 a	6-5 a
1400S137-68	33	18-1 e	15-8 e	12-9 e	18-1 a	15-8 a	12-9 a	18-1 e	15-8 e	12-9 e	18-1 a	15-8 a	12-9 a
1400S137-68	50	20-9 e	17-11 e	14-8 e	20-9 a	17-11 a	12-11 a	19-1 e	17-4 e	14-8 e	20-9 a	17-11 a	12-11 a
1400S162-68	33	19-0 e	16-5 e	13-5 e	19-0 a	16-5 a	12-11 a	19-0 e	16-5 e	13-5 e	19-0 a	16-5 a	12-11 a
1400S162-68	50	21-7 e	19-0 e	15-6 e	21-11 a	19-0 a	12-11 a	19-8 e	17-10 e	15-6 e	21-11 a	19-0 a	12-11 a
1400S200-68	33	19-10 e	17-2 e	14-0 e	19-10 a	17-2 a	12-11 a	19-10 e	17-2 e	14-0 e	19-10 a	17-2 a	12-11 a
1400S200-68	50	22-3 e	19-4 e	15-9 e	22-4 a	19-4 a	12-11 a	20-2 e	18-4 e	15-9 e	22-4 a	19-4 a	12-11 a
1400S250-68	33	20-10 e	18-0 e	14-8 e	20-10 a	18-0 a	12-11 a	20-10 e	18-0 e	14-8 e	20-10 a	18-0 a	12-11 a
1400S250-68	50	22-8 e	19-8 e	16-0 e	22-8 a	19-4 a	12-11 a	21-1 e	19-2 e	16-0 e	22-8 a	19-4 a	12-11 a
1400S300-68	33	21-3 e	18-5 e	15-0 e	21-3 a	18-5 a	12-11 a	21-3 e	18-5 e	15-0 e	21-3 a	18-5 a	12-11 a
1400S300-68	50	24-0 e	20-9 e	16-2 e	24-0 a	19-4 a	12-11 a	21-10 e	19-10 e	16-2 e	24-0 a	19-4 a	12-11 a
1400S162-97	33	23-4	20-2 e	16-6 e	23-4 i	20-2 i	16-6 i	22-0	19-11	16-6 e	23-4 i	20-2 i	16-6 i
1400S162-97	50	24-2	22-0	19-2 e	27-2 i	24-8 i	20-4 i	22-0	19-11	17-5 e	24-8 i	22-5 i	19-7 i
1400S200-97	33	24-4	21-1 e	17-3 e	24-4 i	21-1 i	17-3 i	22-7	20-6 e	17-3 e	24-4 i	21-1 i	17-3 i
1400S200-97	50	24-11	22-7	19-9 e	27-11 i	25-5 i	21-2 i	22-7	20-6	17-11 e	25-5 i	23-1 i	20-2 i
1400S250-97	33	25-11	22-6 e	18-4 e	25-11 i	22-6 i	18-4 a	23-7	21-5 e	18-4 e	25-11 i	22-6 i	18-4 a
1400S250-97	50	25-11	23-7	20-7 e	29-2 i	26-6 i	22-2 i	23-7	21-5	18-8 e	26-6 i	24-1 i	21-0 i
1400S300-97	33	26-11 e	23-8 e	19-4 e	27-4 i	23-8 i	19-4 a	24-6	22-3 e	19-4 e	27-4 i	23-8 i	19-4 a
1400S300-97	50	26-11	24-6	21-5 e	30-3 i	27-6 i	23-1 a	24-6	22-3	19-5 e	27-6 i	25-0 i	21-10 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- Spans are based on continuous lateral support of compression flange
- Web crippling based on 3.5" bearing length
- Joists must be braced against rotation at all supports by track or blocking
- Live load deflection checked for unbalanced condition
- Total deflection = $L/240$
- Web punchouts were not considered for shear or web crippling. Shear and web crippling reduction factors required for web punchouts.
- For two equal spans, the listed span is the distance from either end support to the center support.
Joists must be continuous over the center support.
- Bridging recommendations:

up to 14' span	1 row at mid-span
14' to 20' span	2 rows at 1/3 points
20' to 26' span	3 rows at 1/4 points

"e" requires web stiffeners at end supports
 "i" requires web stiffeners at interior supports
 "a" requires web stiffeners at all supports

25 psf Dead Load and 155 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1400S137-33	33	2-10 e	2-1 e	1-5 e	2-3 a	1-8 a	1-1 a	2-10 e	2-1 e	1-5 e	2-3 a	1-8 a	1-1 a
1400S162-33	33	2-10 e	2-1 e	1-5 e	2-3 a	1-8 a	1-1 a	2-10 e	2-1 e	1-5 e	2-3 a	1-8 a	1-1 a
1400S200-33	33	2-10 e	2-1 e	1-5 e	2-3 a	1-8 a	1-1 a	2-10 e	2-1 e	1-5 e	2-3 a	1-8 a	1-1 a
1400S137-43	33	6-4 e	4-9 e	3-2 e	5-0 a	3-9 a	2-6 a	6-4 e	4-9 e	3-2 e	5-0 a	3-9 a	2-6 a
1400S162-43	33	6-4 e	4-9 e	3-2 e	5-0 a	3-9 a	2-6 a	6-4 e	4-9 e	3-2 e	5-0 a	3-9 a	2-6 a
1400S200-43	33	6-4 e	4-9 e	3-2 e	5-0 a	3-9 a	2-6 a	6-4 e	4-9 e	3-2 e	5-0 a	3-9 a	2-6 a
1400S250-43	33	6-4 e	4-9 e	3-2 e	5-0 a	3-9 a	2-6 a	6-4 e	4-9 e	3-2 e	5-0 a	3-9 a	2-6 a
1400S300-43	33	6-4 e	4-9 e	3-2 e	5-0 a	3-9 a	2-6 a	6-4 e	4-9 e	3-2 e	5-0 a	3-9 a	2-6 a
1400S137-54	33	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a
1400S137-54	50	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a
1400S162-54	33	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a
1400S162-54	50	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a
1400S200-54	33	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a
1400S200-54	50	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a
1400S250-54	33	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a
1400S250-54	50	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a
1400S300-54	33	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a
1400S300-54	50	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a	12-6 e	9-4 e	6-3 e	10-0 a	7-6 a	5-0 a
1400S137-68	33	15-11 e	13-9 e	11-3 e	15-11 a	13-9 a	10-0 a	15-11 e	13-9 e	11-3 e	15-11 a	13-9 a	10-0 a
1400S137-68	50	18-3 e	15-10 e	12-6 e	18-3 a	15-1 a	10-0 a	17-9 e	15-10 e	12-6 e	18-3 a	15-1 a	10-0 a
1400S162-68	33	16-9 e	14-6 e	11-10 e	16-9 a	14-6 a	10-0 a	16-9 e	14-6 e	11-10 e	16-9 a	14-6 a	10-0 a
1400S162-68	50	19-4 e	16-9 e	12-6 e	19-4 a	15-1 a	10-0 a	18-3 e	16-7 e	12-6 e	19-4 a	15-1 a	10-0 a
1400S200-68	33	17-6 e	15-2 e	12-4 e	17-6 a	15-1 a	10-0 a	17-6 e	15-2 e	12-4 e	17-6 a	15-1 a	10-0 a
1400S200-68	50	19-8 e	17-1 e	12-6 e	19-8 a	15-1 a	10-0 a	18-10 e	17-1 e	12-6 e	19-8 a	15-1 a	10-0 a
1400S250-68	33	18-4 e	15-11 e	12-6 e	18-4 a	15-1 a	10-0 a	18-4 e	15-11 e	12-6 e	18-4 a	15-1 a	10-0 a
1400S250-68	50	20-0 e	17-4 e	12-6 e	20-0 a	15-1 a	10-0 a	19-7 e	17-4 e	12-6 e	20-0 a	15-1 a	10-0 a
1400S300-68	33	18-9 e	16-3 e	12-6 e	18-9 a	15-1 a	10-0 a	18-9 e	16-3 e	12-6 e	18-9 a	15-1 a	10-0 a
1400S300-68	50	21-2 e	18-4 e	12-6 e	20-1 a	15-1 a	10-0 a	20-4 e	18-4 e	12-6 e	20-1 a	15-1 a	10-0 a
1400S162-97	33	20-7	17-10 e	14-6 e	20-7 i	17-10 i	14-6 a	20-5	17-10 e	14-6 e	20-7 i	17-10 i	14-6 a
1400S162-97	50	22-6	20-5 e	17-10 e	25-3 i	21-11 i	17-11 a	20-5	18-7	16-3 e	22-11 i	20-10 i	17-11 a
1400S200-97	33	21-6 e	18-7 e	15-2 e	21-6 i	18-7 i	15-2 a	21-0 e	18-7 e	15-2 e	21-6 i	18-7 i	15-2 a
1400S200-97	50	23-2	21-0 e	18-4 e	26-0 i	22-10 i	18-8 a	21-0	19-1	16-8 e	23-8 i	21-6 i	18-8 a
1400S250-97	33	22-11 e	19-10 e	16-2 e	22-11 i	19-10 i	16-2 a	21-11 e	19-10 e	16-2 e	22-11 i	19-10 i	16-2 a
1400S250-97	50	24-2	21-11 e	19-2 e	27-2 i	24-0 i	19-7 a	21-11	19-11 e	17-5 e	24-8 i	22-5 i	19-7 a
1400S300-97	33	24-1 e	20-10 e	17-0 e	24-1 i	20-10 a	17-0 a	22-9 e	20-8 e	17-0 e	24-1 i	20-10 a	17-0 a
1400S300-97	50	25-1	22-9 e	19-11 e	28-2 i	24-11 i	20-4 a	22-9	20-8 e	18-1 e	25-7 i	23-3 i	20-4 a

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

40 psf Dead Load and 125 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
600S137-33	33	6-4 e	5-6 e	3-8 e	5-11 a	4-5 a	2-11 a	6-4 e	5-6 e	3-8 e	5-11 a	4-5 a	2-11 a
600S162-33	33	6-8 e	5-7 e	3-8 e	5-11 a	4-5 a	2-11 a	6-8 e	5-7 e	3-8 e	5-11 a	4-5 a	2-11 a
600S200-33	33	6-10 e	5-7 e	3-8 e	5-11 a	4-5 a	2-11 a	6-10 e	5-7 e	3-8 e	5-11 a	4-5 a	2-11 a
600S137-43	33	7-4 e	6-4 e	5-2 e	7-4 a	6-4 a	5-2 a	7-4 e	6-4 e	5-2 e	7-4 a	6-4 a	5-2 a
600S162-43	33	7-9 e	6-9 e	5-6 e	7-9 a	6-9 a	5-6 a	7-9 e	6-9 e	5-6 e	7-9 a	6-9 a	5-6 a
600S200-43	33	7-10 e	6-9 e	5-6 e	7-10 a	6-9 a	5-6 a	7-10 e	6-9 e	5-6 e	7-10 a	6-9 a	5-6 a
600S250-43	33	8-6 e	7-4 e	6-0 e	8-6 a	7-4 a	6-0 a	8-6 e	7-4 e	6-0 e	8-6 a	7-4 a	6-0 a
600S300-43	33	9-0 e	7-9 e	6-4 e	9-0 a	7-9 a	6-4 a	9-0 e	7-9 e	6-4 e	9-0 a	7-9 a	6-4 a
600S137-54	33	8-2	7-0 e	5-9 e	8-2 i	7-0 i	5-9 a	8-2	7-0 e	5-9 e	8-2 i	7-0 i	5-9 a
600S137-54	50	9-6	8-7 e	7-0 e	9-11 i	8-7 i	7-0 a	8-8	7-10 e	6-10 e	9-9 i	8-7 i	7-0 a
600S162-54	33	8-8 e	7-6 e	6-1 e	8-8 i	7-6 i	6-1 a	8-8 e	7-6 e	6-1 e	8-8 i	7-6 i	6-1 a
600S162-54	50	9-11	9-0 e	7-5 e	10-6 i	9-1 i	7-5 a	9-0	8-2 e	7-2 e	10-2 i	9-1 i	7-5 a
600S200-54	33	9-1 e	7-10 e	6-5 e	9-1 i	7-10 i	6-5 a	9-1 e	7-10 e	6-5 e	9-1 i	7-10 i	6-5 a
600S200-54	50	10-4 e	9-2 e	7-5 e	10-7 i	9-2 i	7-5 a	9-5	8-7 e	7-5 e	10-7 i	9-2 i	7-5 a
600S250-54	33	9-7 e	8-3 e	6-9 e	9-7 i	8-3 a	6-9 a	9-7 e	8-3 e	6-9 e	9-7 i	8-3 a	6-9 a
600S250-54	50	10-11 e	9-10 e	8-0 e	11-4 i	9-10 i	8-0 a	9-11	9-0 e	7-10 e	11-1 i	9-10 i	8-0 a
600S300-54	33	10-2 e	8-9 e	7-2 e	10-2 i	8-9 a	7-2 a	10-2 e	8-9 e	7-2 e	10-2 i	8-9 a	7-2 a
600S300-54	50	11-4 e	10-4 e	8-5 e	11-11 i	10-4 i	8-5 a	10-4	9-4 e	8-2 e	11-7 i	10-4 i	8-5 a
600S137-68	33	9-1	7-10	6-5	9-1 i	7-10 i	6-5 i	9-1	7-10	6-5	9-1 i	7-10 i	6-5 i
600S137-68	50	10-3	9-4	7-11	11-2	9-8 i	7-11 i	9-4	8-5	7-4	10-5	9-6 i	7-11 i
600S162-68	33	9-8	8-4	6-10 e	9-8 i	8-4 i	6-10 i	9-8	8-4	6-10 e	9-8 i	8-4 i	6-10 i
600S162-68	50	10-8	9-9	8-5 e	11-11 i	10-4 i	8-5 i	9-9	8-10	7-8	10-11	9-11 i	8-5 i
600S200-68	33	10-3	8-11	7-3 e	10-3 i	8-11 i	7-3 i	10-2	8-11	7-3 e	10-3 i	8-11 i	7-3 i
600S200-68	50	11-2	10-2	8-8 e	12-4 i	10-8 i	8-8 i	10-2	9-2	8-0	11-4 i	10-4 i	8-8 i
600S250-68	33	11-0	9-6	7-9 e	11-0 i	9-6 i	7-9 i	10-9	9-6	7-9 e	11-0 i	9-6 i	7-9 i
600S250-68	50	11-10	10-9	9-0 e	12-8 i	11-0 i	9-0 i	10-9	9-9	8-6 e	12-0 i	10-11 i	9-0 i
600S300-68	33	11-5	9-10	8-1 e	11-5 i	9-10 i	8-1 i	11-3	9-10	8-1 e	11-5 i	9-10 i	8-1 i
600S300-68	50	12-4	11-2	9-7 e	13-7 i	11-9 i	9-7 i	11-2	10-2	8-11 e	12-7 i	11-5 i	9-7 i
600S162-97	33	11-4	9-10	8-0	11-4	9-10	8-0	10-10	9-10	8-0	11-4	9-10	8-0
600S162-97	50	11-11	10-10	9-5	13-5	12-1	9-11	10-10	9-10	8-7	12-2	11-0	9-8
600S200-97	33	12-1	10-6	8-7	12-1	10-6	8-7 i	11-4	10-3	8-7	12-1	10-6	8-7 i
600S200-97	50	12-5	11-4	9-10	14-0	12-8	10-6	11-4	10-3	8-11	12-8	11-6	10-1
600S250-97	33	13-2	11-5	9-4	13-2	11-5	9-4 i	11-11	10-10	9-4	13-2	11-5	9-4 i
600S250-97	50	13-2	11-11	10-5	14-9	13-5	11-3 i	11-11	10-10	9-6	13-5	12-2	10-8
600S300-97	33	13-10	12-3	10-0	14-1	12-3	10-0 i	12-7	11-5	9-11	14-1	12-3	10-0 i
600S300-97	50	13-10	12-7	10-11	15-6	14-1	11-10 i	12-7	11-5	9-11	14-1	12-10	11-2

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

40 psf Dead Load and 125 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
800S137-33	33	5-6 e	4-1 e	2-9 e	4-5 a	3-3 a	2-2 a	5-6 e	4-1 e	2-9 e	4-5 a	3-3 a	2-2 a
800S162-33	33	5-6 e	4-1 e	2-9 e	4-5 a	3-3 a	2-2 a	5-6 e	4-1 e	2-9 e	4-5 a	3-3 a	2-2 a
800S200-33	33	5-6 e	4-1 e	2-9 e	4-5 a	3-3 a	2-2 a	5-6 e	4-1 e	2-9 e	4-5 a	3-3 a	2-2 a
800S137-43	33	9-0 e	7-10 e	6-1 e	9-0 a	7-4 a	4-11 a	9-0 e	7-10 e	6-1 e	9-0 a	7-4 a	4-11 a
800S162-43	33	9-7 e	8-3 e	6-1 e	9-7 a	7-4 a	4-11 a	9-7 e	8-3 e	6-1 e	9-7 a	7-4 a	4-11 a
800S200-43	33	9-5 e	8-2 e	6-1 e	9-5 a	7-4 a	4-11 a	9-5 e	8-2 e	6-1 e	9-5 a	7-4 a	4-11 a
800S250-43	33	10-2 e	8-10 e	6-1 e	9-10 a	7-4 a	4-11 a	10-2 e	8-10 e	6-1 e	9-10 a	7-4 a	4-11 a
800S300-43	33	10-9 e	9-2 e	6-1 e	9-10 a	7-4 a	4-11 a	10-9 e	9-2 e	6-1 e	9-10 a	7-4 a	4-11 a
800S137-54	33	10-1 e	8-8 e	7-1 e	10-1 i	8-8 a	7-1 a	10-1 e	8-8 e	7-1 e	10-1 i	8-8 a	7-1 a
800S137-54	50	12-1 e	10-7 e	8-8 e	12-3 i	10-7 a	8-8 a	11-0 e	10-0 e	8-8 e	12-3 i	10-7 a	8-8 a
800S162-54	33	10-8 e	9-3 e	7-6 e	10-8 a	9-3 a	7-6 a	10-8 e	9-3 e	7-6 e	10-8 a	9-3 a	7-6 a
800S162-54	50	12-7 e	11-2 e	9-2 e	12-11 a	11-2 a	9-2 a	11-5 e	10-4 e	9-1 e	12-10 a	11-2 a	9-2 a
800S200-54	33	11-1 e	9-7 e	7-10 e	11-1 a	9-7 a	7-10 a	11-1 e	9-7 e	7-10 e	11-1 a	9-7 a	7-10 a
800S200-54	50	12-9 e	11-0 e	9-0 e	12-9 a	11-0 a	9-0 a	11-10 e	10-9 e	9-0 e	12-9 a	11-0 a	9-0 a
800S250-54	33	11-8 e	10-1 e	8-3 e	11-8 a	10-1 a	8-3 a	11-8 e	10-1 e	8-3 e	11-8 a	10-1 a	8-3 a
800S250-54	50	13-6 e	11-9 e	9-7 e	13-6 a	11-9 a	9-7 a	12-5 e	11-3 e	9-7 e	13-6 a	11-9 a	9-7 a
800S300-54	33	12-4 e	10-8 e	8-8 e	12-4 a	10-8 a	8-8 a	12-4 e	10-8 e	8-8 e	12-4 a	10-8 a	8-8 a
800S300-54	50	14-2 e	12-3 e	10-0 e	14-2 a	12-3 a	9-8 a	12-11 e	11-8 e	10-0 e	14-2 a	12-3 a	9-8 a
800S137-68	33	11-2	9-8 e	7-11 e	11-2 i	9-8 i	7-11 i	11-2	9-8 e	7-11 e	11-2 i	9-8 i	7-11 i
800S137-68	50	13-0	11-10	9-9 e	13-10 i	11-11 i	9-9 i	11-10	10-9	9-4 e	13-3 i	11-11 i	9-9 i
800S162-68	33	11-11	10-3 e	8-5 e	11-11 i	10-3 i	8-5 a	11-11	10-3 e	8-5 e	11-11 i	10-3 i	8-5 a
800S162-68	50	13-6	12-3 e	10-4 e	14-8 i	12-8 i	10-4 i	12-3	11-2	9-9 e	13-9 i	12-6 i	10-4 i
800S200-68	33	12-6 e	10-10 e	8-10 e	12-6 i	10-10 i	8-10 a	12-6 e	10-10 e	8-10 e	12-6 i	10-10 i	8-10 a
800S200-68	50	14-0	12-9 e	10-8 e	15-1 i	13-1 i	10-8 a	12-9	11-7	10-1 e	14-4 i	13-0 i	10-8 a
800S250-68	33	13-4 e	11-7 e	9-5 e	13-4 i	11-7 i	9-5 a	13-4 e	11-7 e	9-5 e	13-4 i	11-7 i	9-5 a
800S250-68	50	14-9	13-5 e	11-0 e	15-6 i	13-5 i	11-0 a	13-5	12-2 e	10-8 e	15-1 i	13-5 i	11-0 a
800S300-68	33	13-10 e	11-11 e	9-9 e	13-10 i	11-11 i	9-9 a	13-10 e	11-11 e	9-9 e	13-10 i	11-11 i	9-9 a
800S300-68	50	15-4	14-0 e	11-8 e	16-6 i	14-3 i	11-8 a	14-0	12-8 e	11-1 e	15-8 i	14-3 i	11-8 a
800S162-97	33	14-0	12-1	9-11	14-0	12-1	9-11 i	13-8	12-1	9-11	14-0	12-1	9-11 i
800S162-97	50	15-1	13-8	11-11	16-11	14-11	12-2 i	13-8	12-5	10-10	15-5	14-0	12-2 i
800S200-97	33	14-10	12-10	10-6	14-10	12-10 i	10-6 i	14-3	12-10	10-6	14-10	12-10 i	10-6 i
800S200-97	50	15-8	14-3	12-5	17-7	15-9	12-11 i	14-3	12-11	11-3	16-0	14-6	12-8 i
800S250-97	33	16-0	13-11	11-4	16-0	13-11 i	11-4 i	15-0	13-7	11-4	16-0	13-11 i	11-4 i
800S250-97	50	16-6	15-0	13-1	18-6	16-9 i	13-8 i	15-0	13-7	11-11	16-10	15-4	13-4 i
800S300-97	33	17-1	14-9	12-1	17-1 i	14-9 i	12-1 i	15-8	14-3	12-1	17-1 i	14-9 i	12-1 i
800S300-97	50	17-3	15-8	13-8	19-5	17-6 i	14-4 i	15-8	14-3	12-5	17-7	16-0	14-0 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

40 psf Dead Load and 125 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
925S137-33	33	4-9 e	3-6 e	2-4 e	3-9 a	2-10 a	1-10 a	4-9 e	3-6 e	2-4 e	3-9 a	2-10 a	1-10 a
925S162-33	33	4-9 e	3-6 e	2-4 e	3-9 a	2-10 a	1-10 a	4-9 e	3-6 e	2-4 e	3-9 a	2-10 a	1-10 a
925S200-33	33	4-9 e	3-6 e	2-4 e	3-9 a	2-10 a	1-10 a	4-9 e	3-6 e	2-4 e	3-9 a	2-10 a	1-10 a
925S137-43	33	9-8 e	7-11 e	5-3 e	8-5 a	6-4 a	4-2 a	9-8 e	7-11 e	5-3 e	8-5 a	6-4 a	4-2 a
925S162-43	33	10-3 e	7-11 e	5-3 e	8-5 a	6-4 a	4-2 a	10-3 e	7-11 e	5-3 e	8-5 a	6-4 a	4-2 a
925S200-43	33	10-1 e	7-11 e	5-3 e	8-5 a	6-4 a	4-2 a	10-1 e	7-11 e	5-3 e	8-5 a	6-4 a	4-2 a
925S250-43	33	10-6 e	7-11 e	5-3 e	8-5 a	6-4 a	4-2 a	10-6 e	7-11 e	5-3 e	8-5 a	6-4 a	4-2 a
925S300-43	33	10-6 e	7-11 e	5-3 e	8-5 a	6-4 a	4-2 a	10-6 e	7-11 e	5-3 e	8-5 a	6-4 a	4-2 a
925S137-54	33	11-3 e	9-8 e	7-11 e	11-3 a	9-8 a	7-11 a	11-3 e	9-8 e	7-11 e	11-3 a	9-8 a	7-11 a
925S137-54	50	13-1 e	11-4 e	9-3 e	13-1 a	11-4 a	8-4 a	12-5 e	11-3 e	9-3 e	13-1 a	11-4 a	8-4 a
925S162-54	33	11-10 e	10-3 e	8-4 e	11-10 a	10-3 a	8-4 a	11-10 e	10-3 e	8-4 e	11-10 a	10-3 a	8-4 a
925S162-54	50	13-10 e	12-0 e	9-9 e	13-10 a	12-0 a	8-4 a	12-10 e	11-8 e	9-9 e	13-10 a	12-0 a	8-4 a
925S200-54	33	12-3 e	10-8 e	8-8 e	12-3 a	10-8 a	8-4 a	12-3 e	10-8 e	8-8 e	12-3 a	10-8 a	8-4 a
925S200-54	50	13-7 e	11-9 e	9-7 e	13-7 a	11-9 a	8-4 a	13-4 e	11-9 e	9-7 e	13-7 a	11-9 a	8-4 a
925S250-54	33	12-11 e	11-2 e	9-1 e	12-11 a	11-2 a	8-4 a	12-11 e	11-2 e	9-1 e	12-11 a	11-2 a	8-4 a
925S250-54	50	14-6 e	12-7 e	10-3 e	14-6 a	12-6 a	8-4 a	13-11 e	12-7 e	10-3 e	14-6 a	12-6 a	8-4 a
925S300-54	33	13-7 e	11-9 e	9-7 e	13-7 a	11-9 a	8-4 a	13-7 e	11-9 e	9-7 e	13-7 a	11-9 a	8-4 a
925S300-54	50	15-2 e	13-2 e	10-5 e	15-2 a	12-6 a	8-4 a	14-6 e	13-2 e	10-5 e	15-2 a	12-6 a	8-4 a
925S137-68	33	12-6 e	10-10 e	8-10 e	12-6 i	10-10 i	8-10 a	12-6 e	10-10 e	8-10 e	12-6 i	10-10 i	8-10 a
925S137-68	50	14-8	13-4 e	10-11 e	15-5 i	13-4 i	10-11 a	13-4	12-1 e	10-7 e	15-0 i	13-4 i	10-11 a
925S162-68	33	13-3 e	11-5 e	9-4 e	13-3 i	11-5 i	9-4 a	13-3 e	11-5 e	9-4 e	13-3 i	11-5 i	9-4 a
925S162-68	50	15-3 e	13-10 e	11-6 e	16-3 i	14-1 i	11-6 a	13-10	12-7 e	11-0 e	15-6 i	14-1 i	11-6 a
925S200-68	33	13-11 e	12-0 e	9-10 e	13-11 i	12-0 a	9-10 a	13-11 e	12-0 e	9-10 e	13-11 i	12-0 a	9-10 a
925S200-68	50	15-9 e	14-4 e	11-10 e	16-9 i	14-6 i	11-10 a	14-4	13-0 e	11-4 e	16-1 i	14-6 i	11-10 a
925S250-68	33	14-9 e	12-9 e	10-5 e	14-9 i	12-9 a	10-5 a	14-9 e	12-9 e	10-5 e	14-9 i	12-9 a	10-5 a
925S250-68	50	16-7 e	14-11 e	12-2 e	17-3 i	14-11 i	12-2 a	15-1	13-8 e	11-11 e	16-11 i	14-11 i	12-2 a
925S300-68	33	15-3 e	13-2 e	10-9 e	15-3 i	13-2 a	10-9 a	15-3 e	13-2 e	10-9 e	15-3 i	13-2 a	10-9 a
925S300-68	50	17-3 e	15-8 e	12-10 e	18-3 i	15-9 a	12-10 a	15-8 e	14-2 e	12-5 e	17-7 i	15-9 a	12-10 a
925S162-97	33	15-7	13-6	11-0	15-7	13-6 i	11-0 i	15-5	13-6	11-0	15-7	13-6 i	11-0 i
925S162-97	50	17-0	15-5	13-6	19-1	16-8 i	13-7 i	15-5	14-0	12-3	17-4	15-9	13-7 i
925S200-97	33	16-5	14-3	11-7	16-5 i	14-3 i	11-7 i	16-0	14-3	11-7	16-5 i	14-3 i	11-7 i
925S200-97	50	17-7	16-0	14-0	19-9	17-6 i	14-4 i	16-0	14-6	12-8	18-0	16-4 i	14-3 i
925S250-97	33	17-9	15-4	12-6	17-9 i	15-4 i	12-6 i	16-10	15-3	12-6	17-9 i	15-4 i	12-6 i
925S250-97	50	18-6	16-10	14-8	20-10	18-6 i	15-1 i	16-10	15-3	13-4	18-11	17-2 i	15-0 i
925S300-97	33	18-10	16-3	13-4 e	18-10 i	16-3 i	13-4 i	17-7	16-0	13-4 e	18-10 i	16-3 i	13-4 i
925S300-97	50	19-4	17-7	15-4	21-9 i	19-4 i	15-10 i	17-7	16-0	13-11	19-9	17-11 i	15-8 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

40 psf Dead Load and 125 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1000S137-33	33	4-4 e	3-3 e	2-2 e	3-6 a	2-7 a	1-9 a	4-4 e	3-3 e	2-2 e	3-6 a	2-7 a	1-9 a
1000S162-33	33	4-4 e	3-3 e	2-2 e	3-6 a	2-7 a	1-9 a	4-4 e	3-3 e	2-2 e	3-6 a	2-7 a	1-9 a
1000S200-33	33	4-4 e	3-3 e	2-2 e	3-6 a	2-7 a	1-9 a	4-4 e	3-3 e	2-2 e	3-6 a	2-7 a	1-9 a
1000S137-43	33	9-9 e	7-3 e	4-10 e	7-9 a	5-10 a	3-10 a	9-9 e	7-3 e	4-10 e	7-9 a	5-10 a	3-10 a
1000S162-43	33	9-9 e	7-3 e	4-10 e	7-9 a	5-10 a	3-10 a	9-9 e	7-3 e	4-10 e	7-9 a	5-10 a	3-10 a
1000S200-43	33	9-9 e	7-3 e	4-10 e	7-9 a	5-10 a	3-10 a	9-9 e	7-3 e	4-10 e	7-9 a	5-10 a	3-10 a
1000S250-43	33	9-9 e	7-3 e	4-10 e	7-9 a	5-10 a	3-10 a	9-9 e	7-3 e	4-10 e	7-9 a	5-10 a	3-10 a
1000S300-43	33	9-9 e	7-3 e	4-10 e	7-9 a	5-10 a	3-10 a	9-9 e	7-3 e	4-10 e	7-9 a	5-10 a	3-10 a
1000S137-54	33	11-11 e	10-4 e	8-5 e	11-11 a	10-4 a	7-8 a	11-11 e	10-4 e	8-5 e	11-11 a	10-4 a	7-8 a
1000S137-54	50	13-7 e	11-9 e	9-7 e	13-7 a	11-7 a	7-8 a	13-3 e	11-9 e	9-7 e	13-7 a	11-7 a	7-8 a
1000S162-54	33	12-7 e	10-10 e	8-10 e	12-7 a	10-10 a	7-8 a	12-7 e	10-10 e	8-10 e	12-7 a	10-10 a	7-8 a
1000S162-54	50	14-4 e	12-5 e	9-8 e	14-4 a	11-7 a	7-8 a	13-9 e	12-5 e	9-8 e	14-4 a	11-7 a	7-8 a
1000S200-54	33	13-0 e	11-3 e	9-2 e	13-0 a	11-3 a	7-8 a	13-0 e	11-3 e	9-2 e	13-0 a	11-3 a	7-8 a
1000S200-54	50	14-1 e	12-2 e	9-8 e	14-1 a	11-7 a	7-8 a	14-1 e	12-2 e	9-8 e	14-1 a	11-7 a	7-8 a
1000S250-54	33	13-5 e	11-8 e	9-6 e	13-5 a	11-7 a	7-8 a	13-5 e	11-8 e	9-6 e	13-5 a	11-7 a	7-8 a
1000S250-54	50	15-0 e	13-0 e	9-8 e	15-0 a	11-7 a	7-8 a	14-10 e	13-0 e	9-8 e	15-0 a	11-7 a	7-8 a
1000S300-54	33	14-1 e	12-3 e	9-8 e	14-1 a	11-7 a	7-8 a	14-1 e	12-3 e	9-8 e	14-1 a	11-7 a	7-8 a
1000S300-54	50	15-9 e	13-8 e	9-8 e	15-5 a	11-7 a	7-8 a	15-5 e	13-8 e	9-8 e	15-5 a	11-7 a	7-8 a
1000S137-68	33	13-3 e	11-6 e	9-5 e	13-3 i	11-6 i	9-5 a	13-3 e	11-6 e	9-5 e	13-3 i	11-6 i	9-5 a
1000S137-68	50	15-8 e	14-2 e	11-7 e	16-4 i	14-2 i	11-7 a	14-3	12-11 e	11-4 e	16-0 i	14-2 i	11-7 a
1000S162-68	33	14-0 e	12-2 e	9-11 e	14-0 i	12-2 a	9-11 a	14-0 e	12-2 e	9-11 e	14-0 i	12-2 a	9-11 a
1000S162-68	50	16-3 e	14-9 e	12-2 e	17-3 i	14-11 a	12-2 a	14-9 e	13-5 e	11-8 e	16-7 i	14-11 a	12-2 a
1000S200-68	33	14-9 e	12-9 e	10-5 e	14-9 i	12-9 a	10-5 a	14-9 e	12-9 e	10-5 e	14-9 i	12-9 a	10-5 a
1000S200-68	50	16-10 e	15-3 e	12-6 e	17-9 i	15-4 a	12-6 a	15-3 e	13-10 e	12-1 e	17-2 i	15-4 a	12-6 a
1000S250-68	33	15-7 e	13-6 e	11-0 e	15-7 i	13-6 a	11-0 a	15-7 e	13-6 e	11-0 e	15-7 i	13-6 a	11-0 a
1000S250-68	50	17-8 e	15-6 e	12-8 e	17-11 i	15-6 a	12-8 a	16-0 e	14-7 e	12-8 e	17-11 i	15-6 a	12-8 a
1000S300-68	33	16-1 e	13-11 e	11-5 e	16-1 a	13-11 a	11-5 a	16-1 e	13-11 e	11-5 e	16-1 a	13-11 a	11-5 a
1000S300-68	50	18-4 e	16-4 e	13-4 e	18-11 i	16-4 a	13-4 a	16-8 e	15-1 e	13-2 e	18-8 i	16-4 a	13-4 a
1000S162-97	33	16-7	14-4	11-8	16-7 i	14-4 i	11-8 i	16-6	14-4	11-8	16-7 i	14-4 i	11-8 i
1000S162-97	50	18-2	16-6	14-5	20-4	17-8 i	14-5 i	16-6	15-0	13-1	18-6	16-10 i	14-5 i
1000S200-97	33	17-5	15-1	12-4	17-5 i	15-1 i	12-4 i	17-1	15-1	12-4	17-5 i	15-1 i	12-4 i
1000S200-97	50	18-9	17-1	14-11	21-1	18-7 i	15-2 i	17-1	15-6	13-6	19-2	17-5 i	15-2 i
1000S250-97	33	18-9	16-3	13-3 e	18-9 i	16-3 i	13-3 i	17-11	16-3	13-3 e	18-9 i	16-3 i	13-3 i
1000S250-97	50	19-9	17-11	15-8 e	22-2 i	19-7 i	16-0 i	17-11	16-3	14-3	20-1	18-3 i	16-0 i
1000S300-97	33	19-10	17-2	14-0 e	19-10 i	17-2 i	14-0 i	18-8	17-0	14-0 e	19-10 i	17-2 i	14-0 i
1000S300-97	50	20-7	18-8	16-4 e	23-1 i	20-5 i	16-8 i	18-8	17-0	14-10	21-0	19-1 i	16-8 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

40 psf Dead Load and 125 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1125S137-33	33	3-10 e	2-11 e	1-11 e	3-1 a	2-4 a	1-6 a	3-10 e	2-11 e	1-11 e	3-1 a	2-4 a	1-6 a
1125S162-33	33	3-10 e	2-11 e	1-11 e	3-1 a	2-4 a	1-6 a	3-10 e	2-11 e	1-11 e	3-1 a	2-4 a	1-6 a
1125S200-33	33	3-10 e	2-11 e	1-11 e	3-1 a	2-4 a	1-6 a	3-10 e	2-11 e	1-11 e	3-1 a	2-4 a	1-6 a
1125S137-43	33	8-7 e	6-5 e	4-3 e	6-11 a	5-2 a	3-5 a	8-7 e	6-5 e	4-3 e	6-11 a	5-2 a	3-5 a
1125S162-43	33	8-7 e	6-5 e	4-3 e	6-11 a	5-2 a	3-5 a	8-7 e	6-5 e	4-3 e	6-11 a	5-2 a	3-5 a
1125S200-43	33	8-7 e	6-5 e	4-3 e	6-11 a	5-2 a	3-5 a	8-7 e	6-5 e	4-3 e	6-11 a	5-2 a	3-5 a
1125S250-43	33	8-7 e	6-5 e	4-3 e	6-11 a	5-2 a	3-5 a	8-7 e	6-5 e	4-3 e	6-11 a	5-2 a	3-5 a
1125S200-43	33	8-7 e	6-5 e	4-3 e	6-11 a	5-2 a	3-5 a	8-7 e	6-5 e	4-3 e	6-11 a	5-2 a	3-5 a
1125S137-54	33	12-6 e	10-10 e	8-6 e	12-6 a	10-3 a	6-10 a	12-6 e	10-10 e	8-6 e	12-6 a	10-3 a	6-10 a
1125S137-54	50	14-3 e	12-4 e	8-6 e	13-8 a	10-3 a	6-10 a	14-3 e	12-4 e	8-6 e	13-8 a	10-3 a	6-10 a
1125S162-54	33	13-3 e	11-5 e	8-6 e	13-3 a	10-3 a	6-10 a	13-3 e	11-5 e	8-6 e	13-3 a	10-3 a	6-10 a
1125S162-54	50	15-2 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a	15-2 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a
1125S200-54	33	13-8 e	11-10 e	8-6 e	13-8 a	10-3 a	6-10 a	13-8 e	11-10 e	8-6 e	13-8 a	10-3 a	6-10 a
1125S200-54	50	14-11 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a	14-11 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a
1125S250-54	33	14-2 e	12-3 e	8-6 e	13-8 a	10-3 a	6-10 a	14-2 e	12-3 e	8-6 e	13-8 a	10-3 a	6-10 a
1125S250-54	50	15-11 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a	15-11 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a
1125S300-54	33	14-11 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a	14-11 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a
1125S300-54	50	16-9 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a	16-9 e	12-10 e	8-6 e	13-8 a	10-3 a	6-10 a
1125S137-68	33	14-7 e	12-7 e	10-3 e	14-7 i	12-7 a	10-3 a	14-7 e	12-7 e	10-3 e	14-7 i	12-7 a	10-3 a
1125S137-68	50	17-4 e	15-1 e	12-3 e	17-5 i	15-1 a	12-3 a	15-9 e	14-4 e	12-3 e	17-5 i	15-1 a	12-3 a
1125S162-68	33	15-4 e	13-3 e	10-10 e	15-4 a	13-3 a	10-10 a	15-4 e	13-3 e	10-10 e	15-4 a	13-3 a	10-10 a
1125S162-68	50	17-11 e	15-11 e	13-0 e	18-4 i	15-11 a	13-0 a	16-4 e	14-10 e	12-11 e	18-4 i	15-11 a	13-0 a
1125S200-68	33	16-1 e	13-11 e	11-4 e	16-1 a	13-11 a	11-4 a	16-1 e	13-11 e	11-4 e	16-1 a	13-11 a	11-4 a
1125S200-68	50	18-6 e	16-2 e	13-2 e	18-8 i	16-2 a	13-2 a	16-10 e	15-3 e	13-2 e	18-8 i	16-2 a	13-2 a
1125S250-68	33	17-0 e	14-8 e	12-0 e	17-0 a	14-8 a	12-0 a	17-0 e	14-8 e	12-0 e	17-0 a	14-8 a	12-0 a
1125S250-68	50	18-10 e	16-4 e	13-4 e	18-10 a	16-4 a	13-4 a	17-7 e	16-0 e	13-4 e	18-10 a	16-4 a	13-4 a
1125S300-68	33	17-6 e	15-2 e	12-4 e	17-6 a	15-2 a	12-4 a	17-6 e	15-2 e	12-4 e	17-6 a	15-2 a	12-4 a
1125S300-68	50	19-11 e	17-3 e	14-1 e	19-11 a	17-3 a	13-8 a	18-4 e	16-8 e	14-1 e	19-11 a	17-3 a	13-8 a
1125S162-97	33	18-1	15-8	12-9 e	18-1 i	15-8 i	12-9 i	18-1	15-8	12-9 e	18-1 i	15-8 i	12-9 i
1125S162-97	50	20-1	18-3	15-9 e	22-4 i	19-4 i	15-9 i	18-3	16-7	14-5	20-5	18-7 i	15-9 i
1125S200-97	33	19-0	16-5	13-5 e	19-0 i	16-5 i	13-5 i	18-10	16-5	13-5 e	19-0 i	16-5 i	13-5 i
1125S200-97	50	20-9	18-10	16-5 e	23-3 i	20-3 i	16-6 i	18-10	17-1	14-11	21-2 i	19-2 i	16-6 i
1125S250-97	33	20-5	17-8	14-5 e	20-5 i	17-8 i	14-5 i	19-8	17-8	14-5 e	20-5 i	17-8 i	14-5 i
1125S250-97	50	21-8	19-8	17-3 e	24-4 i	21-4 i	17-5 i	19-8	17-11	15-8 e	22-2 i	20-1 i	17-5 i
1125S300-97	33	21-6	18-8 e	15-3 e	21-6 i	18-8 i	15-3 i	20-6	18-8 e	15-3 e	21-6 i	18-8 i	15-3 i
1125S300-97	50	22-7	20-6	17-11 e	25-4 i	22-3 i	18-2 i	20-6	18-8	16-3 e	23-1 i	20-11 i	18-2 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

40 psf Dead Load and 125 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1200S137-33	33	3-7 e	2-8 e	1-9 e	2-11 a	2-2 a	1-5 a	3-7 e	2-8 e	1-9 e	2-11 a	2-2 a	1-5 a
1200S162-33	33	3-7 e	2-8 e	1-9 e	2-11 a	2-2 a	1-5 a	3-7 e	2-8 e	1-9 e	2-11 a	2-2 a	1-5 a
1200S200-33	33	3-7 e	2-8 e	1-9 e	2-11 a	2-2 a	1-5 a	3-7 e	2-8 e	1-9 e	2-11 a	2-2 a	1-5 a
1200S137-43	33	8-1 e	6-0 e	4-0 e	6-5 a	4-10 a	3-2 a	8-1 e	6-0 e	4-0 e	6-5 a	4-10 a	3-2 a
1200S162-43	33	8-1 e	6-0 e	4-0 e	6-5 a	4-10 a	3-2 a	8-1 e	6-0 e	4-0 e	6-5 a	4-10 a	3-2 a
1200S200-43	33	8-1 e	6-0 e	4-0 e	6-5 a	4-10 a	3-2 a	8-1 e	6-0 e	4-0 e	6-5 a	4-10 a	3-2 a
1200S250-43	33	8-1 e	6-0 e	4-0 e	6-5 a	4-10 a	3-2 a	8-1 e	6-0 e	4-0 e	6-5 a	4-10 a	3-2 a
1200S300-43	33	8-1 e	6-0 e	4-0 e	6-5 a	4-10 a	3-2 a	8-1 e	6-0 e	4-0 e	6-5 a	4-10 a	3-2 a
1200S137-54	33	12-10 e	11-2 e	8-0 e	12-9 a	9-7 a	6-4 a	12-10 e	11-2 e	8-0 e	12-9 a	9-7 a	6-4 a
1200S137-54	50	14-9 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a	14-9 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a
1200S162-54	33	13-7 e	11-9 e	8-0 e	12-9 a	9-7 a	6-4 a	13-7 e	11-9 e	8-0 e	12-9 a	9-7 a	6-4 a
1200S162-54	50	15-7 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a	15-7 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a
1200S200-54	33	14-0 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a	14-0 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a
1200S200-54	50	15-4 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a	15-4 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a
1200S250-54	33	14-7 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a	14-7 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a
1200S250-54	50	16-0 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a	16-0 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a
1200S300-54	33	15-4 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a	15-4 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a
1200S300-54	50	16-0 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a	16-0 e	12-0 e	8-0 e	12-9 a	9-7 a	6-4 a
1200S137-68	33	15-4 e	13-3 e	10-10 e	15-4 a	13-3 a	10-10 a	15-4 e	13-3 e	10-10 e	15-4 a	13-3 a	10-10 a
1200S137-68	50	17-10 e	15-6 e	12-7 e	17-10 i	15-6 a	12-7 a	16-8 e	15-2 e	12-7 e	17-10 i	15-6 a	12-7 a
1200S162-68	33	16-1 e	13-11 e	11-4 e	16-1 a	13-11 a	11-4 a	16-1 e	13-11 e	11-4 e	16-1 a	13-11 a	11-4 a
1200S162-68	50	18-10 e	16-4 e	13-4 e	18-10 a	16-4 a	12-10 a	17-3 e	15-8 e	13-4 e	18-10 a	16-4 a	12-10 a
1200S200-68	33	16-10 e	14-7 e	11-11 e	16-10 a	14-7 a	11-11 a	16-10 e	14-7 e	11-11 e	16-10 a	14-7 a	11-11 a
1200S200-68	50	19-2 e	16-8 e	13-7 e	19-2 a	16-8 a	12-10 a	17-9 e	16-1 e	13-7 e	19-2 a	16-8 a	12-10 a
1200S250-68	33	17-9 e	15-5 e	12-7 e	17-9 a	15-5 a	12-7 a	17-9 e	15-5 e	12-7 e	17-9 a	15-5 a	12-7 a
1200S250-68	50	19-5 e	16-10 e	13-9 e	19-5 a	16-10 a	12-10 a	18-7 e	16-10 e	13-9 e	19-5 a	16-10 a	12-10 a
1200S300-68	33	18-3 e	15-10 e	12-11 e	18-3 a	15-10 a	12-10 a	18-3 e	15-10 e	12-11 e	18-3 a	15-10 a	12-10 a
1200S300-68	50	20-7 e	17-9 e	14-6 e	20-7 a	17-9 a	12-10 a	19-4 e	17-6 e	14-6 e	20-7 a	17-9 a	12-10 a
1200S162-97	33	19-0	16-6	13-5 e	19-0 i	16-6 i	13-5 i	19-0	16-6	13-5 e	19-0 i	16-6 i	13-5 i
1200S162-97	50	21-2	19-3	16-7 e	23-5 i	20-3 i	16-7 i	19-3	17-6	15-3 e	21-7 i	19-8 i	16-7 i
1200S200-97	33	19-11	17-3	14-1 e	19-11 i	17-3 i	14-1 i	19-10	17-3	14-1 e	19-11 i	17-3 i	14-1 i
1200S200-97	50	21-10	19-10	17-4 e	24-6 i	21-3 i	17-4 i	19-10	18-0	15-9 e	22-4 i	20-3 i	17-4 i
1200S250-97	33	21-4	18-6 e	15-1 e	21-4 i	18-6 i	15-1 i	20-9	18-6 e	15-1 e	21-4 i	18-6 i	15-1 i
1200S250-97	50	22-10	20-9	18-2 e	25-8 i	22-4 i	18-3 i	20-9	18-10	16-6 e	23-4 i	21-2 i	18-3 i
1200S300-97	33	22-6	19-6 e	15-11 e	22-6 i	19-6 i	15-11 a	21-7	19-6 e	15-11 e	22-6 i	19-6 i	15-11 a
1200S300-97	50	23-9	21-7	18-10 e	26-9 i	23-3 i	19-0 i	21-7	19-8	17-2 e	24-3 i	22-1 i	19-0 i

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.

Steel Stud Solutions

Floor Joist Span Tables (feet - inches)

notes:

- "e" requires web stiffeners at end supports
- "i" requires web stiffeners at interior supports
- "a" requires web stiffeners at all supports

40 psf Dead Load and 125 psf Live Load													
Section Designation	Fy ksi	Live Load Deflection L/360						Live Load Deflection L/480					
		Single Span			Two Equal Spans			Single Span			Two Equal Spans		
		Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.			Spacing (in.) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1400S137-33	33	3-1 e	2-4 e	1-6 e	2-5 a	1-10 a	1-2 a	3-1 e	2-4 e	1-6 e	2-5 a	1-10 a	1-2 a
1400S162-33	33	3-1 e	2-4 e	1-6 e	2-5 a	1-10 a	1-2 a	3-1 e	2-4 e	1-6 e	2-5 a	1-10 a	1-2 a
1400S200-33	33	3-1 e	2-4 e	1-6 e	2-5 a	1-10 a	1-2 a	3-1 e	2-4 e	1-6 e	2-5 a	1-10 a	1-2 a
1400S137-43	33	6-11 e	5-2 e	3-5 e	5-6 a	4-1 a	2-9 a	6-11 e	5-2 e	3-5 e	5-6 a	4-1 a	2-9 a
1400S162-43	33	6-11 e	5-2 e	3-5 e	5-6 a	4-1 a	2-9 a	6-11 e	5-2 e	3-5 e	5-6 a	4-1 a	2-9 a
1400S200-43	33	6-11 e	5-2 e	3-5 e	5-6 a	4-1 a	2-9 a	6-11 e	5-2 e	3-5 e	5-6 a	4-1 a	2-9 a
1400S250-43	33	6-11 e	5-2 e	3-5 e	5-6 a	4-1 a	2-9 a	6-11 e	5-2 e	3-5 e	5-6 a	4-1 a	2-9 a
1400S300-43	33	6-11 e	5-2 e	3-5 e	5-6 a	4-1 a	2-9 a	6-11 e	5-2 e	3-5 e	5-6 a	4-1 a	2-9 a
1400S137-54	33	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a
1400S137-54	50	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a
1400S162-54	33	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a
1400S162-54	50	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a
1400S200-54	33	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a
1400S200-54	50	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a
1400S250-54	33	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a
1400S250-54	50	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a
1400S300-54	33	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a
1400S300-54	50	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a	13-8 e	10-3 e	6-10 e	10-11 a	8-2 a	5-5 a
1400S137-68	33	16-8 e	14-5 e	11-9 e	16-8 a	14-5 a	10-11 a	16-8 e	14-5 e	11-9 e	16-8 a	14-5 a	10-11 a
1400S137-68	50	19-1 e	16-6 e	13-6 e	19-1 a	16-5 a	10-11 a	19-1 e	16-6 e	13-6 e	19-1 a	16-5 a	10-11 a
1400S162-68	33	17-6 e	15-2 e	12-4 e	17-6 a	15-2 a	10-11 a	17-6 e	15-2 e	12-4 e	17-6 a	15-2 a	10-11 a
1400S162-68	50	20-2 e	17-6 e	13-8 e	20-2 a	16-5 a	10-11 a	19-8 e	17-6 e	13-8 e	20-2 a	16-5 a	10-11 a
1400S200-68	33	18-3 e	15-10 e	12-11 e	18-3 a	15-10 a	10-11 a	18-3 e	15-10 e	12-11 e	18-3 a	15-10 a	10-11 a
1400S200-68	50	20-7 e	17-10 e	13-8 e	20-7 a	16-5 a	10-11 a	20-2 e	17-10 e	13-8 e	20-7 a	16-5 a	10-11 a
1400S250-68	33	19-2 e	16-7 e	13-6 e	19-2 a	16-5 a	10-11 a	19-2 e	16-7 e	13-6 e	19-2 a	16-5 a	10-11 a
1400S250-68	50	20-11 e	18-1 e	13-8 e	20-11 a	16-5 a	10-11 a	20-11 e	18-1 e	13-8 e	20-11 a	16-5 a	10-11 a
1400S300-68	33	19-7 e	16-11 e	13-8 e	19-7 a	16-5 a	10-11 a	19-7 e	16-11 e	13-8 e	19-7 a	16-5 a	10-11 a
1400S300-68	50	22-1 e	19-2 e	13-8 e	21-11 a	16-5 a	10-11 a	21-10 e	19-2 e	13-8 e	21-11 a	16-5 a	10-11 a
1400S162-97	33	21-6	18-7 e	15-2 e	21-6 i	18-7 i	15-2 a	21-6	18-7 e	15-2 e	21-6 i	18-7 i	15-2 a
1400S162-97	50	24-2	22-0 e	18-8 e	26-5 i	22-11 i	18-8 i	22-0	19-11	17-5 e	24-8 i	22-5 i	18-8 i
1400S200-97	33	22-5	19-5 e	15-10 e	22-5 i	19-5 i	15-10 a	22-5	19-5 e	15-10 e	22-5 i	19-5 i	15-10 a
1400S200-97	50	24-11	22-7 e	19-6 e	27-7 i	23-11 i	19-6 a	22-7	20-6	17-11 e	25-5 i	23-1 i	19-6 a
1400S250-97	33	23-11 e	20-8 e	16-11 e	23-11 i	20-8 i	16-11 a	23-7 e	20-8 e	16-11 e	23-11 i	20-8 i	16-11 a
1400S250-97	50	25-11	23-7 e	20-5 e	28-11 i	25-1 i	20-5 a	23-7	21-5 e	18-8 e	26-6 i	24-1 i	20-5 a
1400S300-97	33	25-2 e	21-9 e	17-9 e	25-2 i	21-9 i	17-9 a	24-6 e	21-9 e	17-9 e	25-2 i	21-9 i	17-9 a
1400S300-97	50	26-11	24-6 e	21-3 e	30-0 i	26-0 i	21-3 a	24-6	22-3 e	19-5 e	27-6 i	25-0 i	21-3 a

This data was compiled from the 1996 edition of American Iron and Steel Institutes Cold Formed Steel Design Manual. It is FOR REFERENCE ONLY. No warranty is expressed or implied in reference to this data. If you require design data as shown above, we suggest you secure the services of an engineering firm.